HONIDA

SERVICE MANUAL



© HONDA MOTOR CO., LTD. 1986

Thank you for your patronage.

This CD was purchased from @home backup. If it was purchased or obtained by any other means, you have illegally obtained this CD and are in violation of it copyrights.

Report copyright violations to:

@home backup

Attn: Manual Backups 2902 Grasmere St. Garland, TX 75040

Unauthorized duplication or distribution is strictly prohibited.

IMPORTANT SAFETY NOTICE

WARNING Indicates a strong possibility of severe personal injury or loss of life if instructions are not followed.

CAUTION: Indicates a possibility of personal injury or equipment damage if instructions are not followed.

NOTE:

Gives helpful information.

Detailed descriptions of standard workshop procedures, safety principles and service operations are not included. It is important to note that this manual contains some warnings and cautions against some specific service methods which could cause PERSONAL INJURY to service personnel or could damage a vehicle or render it unsafe. Please understand that those warnings could not cover all conceivable ways in which service, whether or not recommended by Honda might be done or of the possibly hazardous consequences of each conceivable way, nor could Honda investigate all such ways.

Anyone using service procedures or tools, whether or not recommended by Honda must satisfy himself thoroughly that neither personal safety nor vehicle safety will be jeopardized by the service method or tools selected.

HOW TO USE THIS MANUAL

Sections 1 through 3 apply to the whole ATC, while sections 4 through 16 describe parts of the ATC, grouped according to location.

Find the section you want on this page, then turn to the table of contents on page 1 of that section.

Most sections start with an assembly or system illustration and all the required specifications, torque values, general instructions, tools and troubleshooting for the section. The subsequent pages give detailed procedures.

If you don't know what the source of a problem is, refer to section 17, TROUBLESHOOT-ING.

All information, illustrations, directions and specifications included in this publication are based on the latest product information available at the time of approval for printing.

Honda Motor CO., LTD. reserves the right to make changes at any time without notice and without incurring any obligation whatever.

No part of this publication may be reproduced without written permission.

Honda Motor CO., LTD. Service Publications Office

CONTENTS

| | GENERAL INFORMATION | 1 |
|---------|--|----|
| | LUBRICATION | 2 |
| | MAINTENANCE | 3 |
| | FUEL SYSTEM | 4 |
| ENGINE | ENGINE REMOVAL/INSTALLATION | 5 |
| | CYLINDER HEAD/VALVES | 6 |
| | CYLINDER/PISTON | 7 |
| ⅲ | CLUTCH/OIL PUMP/KICK STARTER/ GEARSHIFT LINKAGE | 8 |
| | ALTERNATOR | 9 |
| | CRANKCASE/TRANSMISSION/ CRANKSHAFT | 10 |
| | FRONT WHEEL/SUSPENSION/STEERING | 11 |
| SIS | REAR WHEELS | 12 |
| CHASSIS | REAR SUSPENSION | 13 |
| ਹ | HYDRAULIC BRAKES | 14 |
| | REAR FENDER/SEAT/EXHAUST SYSTEM | 15 |
| | ELECTRICAL SYSTEM | 16 |
| | TROUBLESHOOTING | 17 |
| | INDEX | 18 |

1. GENERAL INFORMATION

| OLIVIOL HOLLS | & HARNESS ROUTING 1-10 EMISSION CONTROL SYSTEM only) 1-15 |
|---------------|---|
|---------------|---|

GENERAL SAFETY

WWARNING

If the engine must be running to do some work, make sure that area is well-ventilated. Never run the engine in a closed area. The exhaust contains poisonous carbon monoxide gas that may cause loss of consciousness and lead to death.

WWARNING


Gasoline is extremely flammable and is explosive under certain conditions. Do not smoke or allow flames or sparks in your work area.

SERVICE RULES


- 1. Use genuine HONDA or HONDA-recommended parts and lubricants or their equivalent. Parts that don't meet HONDA's design specifications may cause damage to the ATC.
- 2. Use the special tools designed for this product to avoid damage and incorrect assembly.
- 3. Use only metric tools when servicing this ATC. Metric bolts, nuts, and screws are not interchangeable with English fasteners.
- 4. Install new gasket, O-rings, cotter pins, lock plates, etc. when reassembling.
- 5. When tightening bolts or nuts, begin with the larger-diameter or inner bolt first. Then tighten to the specified torque diagonally in 2 or 3 steps, unless a particular sequence is specified.
- 6. Clean parts in non-flammable or high flash point solvent upon disassembly.
- 7. Lubricate any sliding surfaces before reassembly.
- 8. After reassembly, check all parts for proper installation and operation.

MODEL IDENTIFICATION






The frame serial number is stamped on the right side of the steering head.



The engine serial number is stamped on the lower left side of the crankcase.



The carburetor identification number is on the carburetor body right side.

SPECIFICATIONS

| DIMENSIONS | Overall length Overall width Overall height Wheel base Rear tread Seat height Footpeg height Ground clearance Dry weight | | 1,860 mm (73.2 in) 1,080 mm (42.5 in) 1,050 mm (41.3 in) 1,210 mm (47.6 in) 830 mm (32.7 in) 730 mm (28.7 in) 320 mm (12.6 in) 120 mm (4.7 in) 126 kg (278 lb) |
|------------|---|--|---|
| FRAME | Type Front suspension, travel Rear suspension, travel Rim size Front tire size, pressure Rear tire size, pressure Front brake Rear brake Fuel tank capacity Fuel reserve capacity Caster Trail Front fork oil capacity | Front Rear | Semi-double cradle Telescopic air fork, 195 mm (7.7 in) Swingarm, 185 mm (7.3 in) 11 in 9 in 23.5 x 8-11, 25 kPa (0.25 kg/cm², 3.6 psi) '86: 22 x 10-9, 17 kPa (0.17 kg/cm², 2.5 psi) After '86: 22 x 10-9, 17.5 kPa (0.175 kg/cm², 2.5 psi) Single disc Single disc 10.5 lit (2.78 US gal, 2.31 lmp gal) 1.5 lit (0.40 US gal, 0.33 lmp gal) 21°30' 30 mm (1.2 in) '86: 216-221 cc (7.3-7.5 US oz) After '86: 226-231 cc (7.6-7.8 US oz) |
| ENGINE | Type Cylinder arrangement Bore x stroke Displacement Compression ratio Valve train Maximum horsepower Maximum torque Oil capacity Lubrication system Cylinder compession Intake valve Exhaust valve Valve clearance | Opens Closes Opens Closes IN (cold) EX (cold) | Gasoline, air-cooled 4-stroke Single cylinder inclined 25° 65.0 x 60.0 mm (2.56 x 2.36 in) 199 cm³ (12.14 cu in) 9.5:1 Overhead camshaft chain drive 19 ps/7,500 rpm '86: 1.9 kg-m/6,000 rpm After '86: 1.9 kg-m/6,500 rpm 1.8 lit (1.90 US qt, 1.59 lmp qt) at disassembly 1.5 lit (1.59 US qt, 1.32 lmp qt) after draining Forced pressure and wet sump 1,300 ± 100 kPa (13.0 ± 1 kg/cm², 184.7 ± 14.2 psi) 8° BTDC 35° ABDC 40° BBDC 5° ATDC 0.08 mm (0.003 in) 0.08 mm (0.003 in) |

GENERAL INFORMATION

| | | ′86 | | After '86 | |
|-------------|------------------------------------|------------------------------|-------------|-----------|--|
| CARBURETOR | Identification number | PD64A A | PD64A B , C | PD3AA A | |
| | Type | Piston valve | ← | ← | |
| | Venturi diameter | 24 mm (0.94 in) | ← | ← | |
| | Main jet | #122 | #112 | ← | |
| | Pilot screw opening | 2 turns out | ← | ← | |
| | Jet needle | 2nd groove | 3rd groove | ← | |
| | Float level | 14.0 ± 0.5 mm | ← | ← | |
| | | $(0.55 \pm 0.02 \text{ in})$ | | | |
| | Idle speed | 1,400 ± 100 rpm | ← | ← | |
| DRIVE TRAIN | Clutch | Wet multi-plate | | | |
| | Transmission | 6-speed constant mes | h | | |
| | Primary reduction | 3.087:1 | | | |
| | Gear ratio I | 3.455:1 | | | |
| | Gear ratio II | 2.333:1 | | | |
| | Gear ratio III | ′86: 1.778:1 | | | |
| | | After '86: 1.750:1 | | | |
| | Gear ratio IV | 1.450 | | | |
| | Gear ratio V | 1.227 | | | |
| | Gear ratio VI | 1.083 | | | |
| | Final reduction | 2.923 | | | |
| | Gearshift pattern | 1-N-2-3-4-5-6 | | | |
| | Drive chain size/links | 520/86 | | | |
| ELECTRICAL | Ignition system | CDI | | | |
| | Initial ignition timing ("F" mark) | 10° BTDC at 1,400 ± | | | |
| | Full advance ("II" mark) | 28° BTDC at 3,500 ± | • | | |
| | Alternator | AC generator 135W/5 | ,000 rpm | | |
| | Spark plug | NGK: DR8ES-L | | | |
| | | ND: X24ESR-U | | | |
| | Spark plug gap | 0.6-0.7 mm (0.024- | -0.028 in) | | |
| | Headlight | 12V 60/55W | | | |
| | Taillight | ′86: 12V 5W | | | |
| | | After '86: 12V 8W | | | |

TORQUE VALUES

ENGINE

]: '86

| | Thread | Torque | | |
|-------------------------------|-----------|---------|-----------|-----------|
| Item | dia. (mm) | N∙m | kg-m | ft-lb |
| Oil drain bolt | 12 | 35-40 | 3.5-4.0 | 25-29 |
| Fuel strainer cup | 24 | 3-5 | 0.3-0.5 | 2.2 - 3.6 |
| Valve adjuster lock bolt | 6 | 10-14 | 1.0-1.4 | 7.2 - 10 |
| Fuel valve lock nut | 16 | 20-25 | 2.0-2.5 | 15-18 |
| Carburetor mounting nut | 6 | 6-9 | 0.6-0.9 | 4.3 - 6.5 |
| Drive sprocket bolt | 6 | 10-14 | 1.0-1.4 | 7.2 - 10 |
| Exhaust pipe joint nut | 6 | 10-14 | 1.0-1.4 | 7.2-10 |
| Exhaust pipe clamp bolt | 8 | 18-28 | 1.8-2.8 | 13-20 |
| Exhaust muffler mounting bolt | [8] | [40-45] | [4.0-4.5] | [29 - 33] |
| _ | 10 | 60-70 | 6.0-7.0 | 43-51 |
| Cylinder head cover bolt | 6 | 10-14 | 1.0-1.4 | 7.2 - 10 |
| Cylinder head cap nut | 6 | 10-14 | 1.0-1.4 | 7.2 - 10 |
| Cylinder head nut | 8 | 28-30 | 2.8-3.0 | 20-22 |
| Breather cover bolt | 6 | 10-14 | 1.0-1.4 | 7.2-10 |
| Kick starter arm pinch bolt | 8 | 30-35 | 3.0 - 3.5 | 22-25 |
| Clutch center lock nut | 14 | 50-60 | 5.0-6.0 | 36-43 |
| Oil filter rotor lock nut | 16 | 50-60 | 5.0-6.0 | 36-43 |
| Drum stopper bolt | 6 | 10-14 | 1.0-1.4 | 7.2-10 |
| Shifter plate bolt | 6 | 10-14 | 1.0 - 1.4 | 7.2-10 |
| Gearshift pedal bolt | 6 | 14-18 | 1.4-1.8 | 10-13 |
| Flywheel bolt | 8 | 45-55 | 4.5-5.5 | 33-40 |
| Camshaft bearing holder bolt | 6 | 10-14 | 1.0-1.4 | 7.2-10 |
| Crankcase bolt | 6 | 10-14 | 1.0-1.4 | 7.2-10 |
| Camshaft inspection hole cap | 14 | 2.5-4.5 | 0.25-0.45 | 1.8-3.3 |

FRAME

| | Thread | Torque | | |
|----------------------------------|-----------|--------|-----------|-------|
| Item | dia. (mm) | N•m | kg-m | ft-lb |
| Drive chain adjuster lock bolts | 8 | 18-24 | 1.8-2.4 | 13-17 |
| Parking brake adjusting lock nut | 8 | 15-20 | 1.5-2.0 | 11-15 |
| Top engine hanger plate bolt | 8 | 24-30 | 2.4-3.0 | 17-22 |
| | 10 | 60-70 | 6.0-7.0 | 43-51 |
| Front engine hanger plate bolt | 8 | 30-36 | 3.0-3.6 | 22-26 |
| | 10 | 60-70 | 6.0-7.0 | 43-51 |
| Rear engine hanger plate bolt | 8 | 30-36 | 3.0-3.6 | 22-26 |
| | 10 | 60-70 | 6.0 - 7.0 | 43-51 |
| Engine lower mounting bolt | 10 | 60-70 | 6.0 - 7.0 | 43-51 |
| Footpeg bolt | 10 | 60-70 | 6.0-7.0 | 43-51 |
| Handlebar upper holder bolt | 8 | 18-30 | 1.8-3.0 | 13-22 |
| Brake disc nut (front, rear) | 8 | 20-30 | 2.0-3.0 | 15-22 |
| Engine guard plate bolt | 8 | 30-35 | 3.0-3.5 | 22-25 |

| ltem | Thread | Torque | | |
|---|-----------|----------|-----------|---------|
| Item | dia. (mm) | N∙m | kg-m | ft-lb |
| Front axle | 14 | 70-110 | 7.0-11.0 | 51-80 |
| Front axle holder nut | 6 | 10-14 | 1.0-1.4 | 7.2-10 |
| Wheel nut (front, rear) | 10 | 60-70 | 6.0-7.0 | 43-51 |
| Fork tube cap bolt | 28 | 15-30 | 1.5-3.0 | 11-22 |
| Fork socket bolt | 8 | 15-25 | 1.5-2.5 | 11-18 |
| Fork pinch bolt | 8 | 18-25 | 1.8-2.5 | 13-18 |
| Brake hose stay nut | 8 | 24-30 | 2.4 - 3.0 | 17-22 |
| Brake hose clamp bolt | 6 | 10-14 | 1.0-1.4 | 7.2-10 |
| Fork boot band screw | 3 | 0.6-0.12 | 0.06-0.12 | 0.4-0.9 |
| Steering bearing adjustment nut (initial) | 26 | 25-35 | 2.5-3.5 | 18-25 |
| (final) | | 7-8 | 0.7-0.8 | 5.1-5.8 |
| Steering stem nut | 24 | 90-120 | 9.0-12.0 | 65-87 |
| Rear axle outer lock nut | 40 | 80-100 | 8.0-10.0 | 58-72 |
| Rear axle inner lock nut | 40 | 100-120 | 10.0-12.0 | 72-87 |
| Driven sprocket nut | 8 | 30-40 | 3.0-4.0 | 22-29 |
| Rear axle nut | 18 | 120-170 | 12.0-17.0 | 87-123 |
| Bearing holder stopper bolt | 8 | 8-11 | 0.8-1.1 | 5.8-8.0 |
| Shock absorber mounting bolt (upper, lower) | 10 | 40-50 | 4.0-5.0 | 29-36 |
| Swing arm pivot bolt | 14 | 70-110 | 7.0-11.0 | 51-80 |
| Shock absorber adjusting lock nut | 54 | 80-100 | 8.0-10.0 | 58-72 |
| Air bleed valve (front, rear) | 8 | 4-7 | 0.4-0.7 | 3-5 |
| Brake pad pin bolt (front, rear) | 8 | 15-20 | 1.5-2.0 | 11-15 |
| Caliper mounting bolt (front, rear) | 8 | 20-30 | 2.0-3.0 | 15-22 |
| Caliper socket bolt (front, rear) | 8 | 15-20 | 1.5-2.0 | 11-15 |
| Oil bolt | 10 | 25-35 | 2.5-3.5 | 18-25 |
| Shock absorber oil hose joint bolt | 10 | 20-25 | 2.0-2.5 | 15-18 |
| Parking brake base bolt | 8 | 20-25 | 2.0-2.5 | 15-18 |
| Rear master cylinder mounting bolt | 6 | 10-14 | 1.0-1.4 | 7.2-10 |
| Steering stop cover | 4 | 1-2 | 0.1 - 0.2 | 0.7-2.9 |

Torque specifications listed above are for specific tightening points. If a torque specification is not listed, follow the standards given below.

STANDARD TORQUE VALUES

| Туре | Torque N∙m (kg-m, ft-lb) | Туре | Torque N•m (kg-m, ft-lb) |
|-----------------|-----------------------------|------------------------|-----------------------------|
| 5 mm bolt, nut | 4.5-6.0 (0.45-0.6, 3.3-4.3) | 5 mm screw | 3.5-5.0 (0.35-0.5, 2.5-3.6) |
| 6 mm bolt, nut | 8-12 (0.8-1.2, 6-9) | 6 mm screw, SH bolt | 7-11 (0.7-1.1, 5-8) |
| 8 mm bolt, nut | 18-25 (1.8-2.5, 13-18) | 6 mm flange bolt, nut | 10-14 (1.0-1.4, 7-10) |
| 10 mm bolt, nut | 30-40 (3.0-4.0, 22-29) | 8 mm flange bolt, nut | 24-30 (2.4-3.0, 17-22) |
| 12 mm bolt, nut | 50-60 (5.0-6.0, 36-43) | 10 mm flange bolt, nut | 35-45 (3.5-4.5, 25-32) |

TOOLS

SPECIAL

| DESCRIPTION | NUMBER | ALTERNATIVE TOOL | NUMBER | REF. SEC. |
|--|---------------|-------------------------|---------------|-----------|
| Valve guide reamer, 5.5 mm | 07984-2000000 | Valve guide reamer | 07984-200000A | 6 |
| Clutch center holder | 07923-9580000 | | | 8 |
| Universal bearing puller | 07631-0010000 | Commercially available | | 10 |
| | | in U.S.A. | | |
| Assembly collar | 07965-VM00100 | | | 10 |
| Assembly shaft | 07965-VM00200 | Assembly shaft | 07931-ME4000A | 10 |
| Thread adaptor | 07GMF-HB50100 | Thread adapter | 07965-HB3000A | 10 |
| Bearing remover set, 15 mm | 07936-KC10000 | Not available in U.S.A. | | 10 |
| Bearing remover, 15 mm | 07936-KC10500 | | | 10 |
| -Remover weight | 07741-0010201 | Remover weight | 07936-3710200 | 10 |
| Attachment | 07946-6920100 | | | 10 |
| Snap ring pliers | 07914-3230001 | Commercially available | | 11, 14 |
| | | in U.S.A. | | |
| Steering stem socket | 07916-3710100 | | | 11 |
| Ball race remover | 07953-3330000 | | | 11 |
| Ball race driver | 07946-3290000 | | | 11 |
| Steering stem driver | 07946-4300101 | Steering stem driver | 07946-MB00000 | 11 |
| Universal bead breaker | GN-AH-958-BB1 | U.S.A. only | with GN-HT-54 | 11 |
| Lock nut wrench, 45 mm | 07916-1870101 | Commercially available | | 12 |
| (2 pieces) | | in U.S.A. | | |
| Bearing remover set, 20 mm | 07936-3710001 | Not available in U.S.A. | | 13 |
| Spindle assy, 20 mm | 07936-3710600 | | | |
| Remover handle | 07936-3710100 | | | |
| Remover weight | 07741-0010201 | Remover weight | 07936-3710200 | |
| Sanwa Electric Tester | 07308-0020000 | Kowa Tester | TH-5H | 16 |
| Kowa Digital Multimeter | 07411-0020000 | | KS-AHM-32-003 | 16 |

GENERAL INFORMATION

COMMON

| DESCRIPTION | NUMBER | ALTERNATIVE TOOL | NUMBER | REF. SEC. |
|--|-----------------|---------------------------|---------------|-----------|
| Float level gauge | 07401-0010000 | | | 4 |
| Valve guide remover, 5.5 mm | 07742-0010100 | Valve guide remover | 07942-3290100 | 6 |
| Valve spring compressor | 07757-0010000 | -Valve spring | 07957-3290001 | 6 |
| | | compressor | | |
| Inner driver | 07746-0020100 | -Not available in U.S.A. | | 6 |
| Attachment, 15 mm (inner) | 07746 - 0020200 | FNot available in 0.5.A. | | 6 |
| Pin driver, 3 mm | 07744-0010200 | -Commercially available | | 8 |
| | | in U.S.A. | | |
| Gear holder | 07724-0010100 | Not available in U.S.A. | | 8, 9 |
| Rotor puller | 07733-0020001 | Rotor puller | 07933-2160000 | 9 |
| Driver | 07749-0010000 | | | |
| Attachment, 62 x 68 mm | 07746 - 0010500 | | | 10, 12 |
| Pilot, 28 mm | 07746-0041100 | | | 10 |
| Attachment, 42 x 47 mm | 07746-0010300 | | | 10, 11 |
| Pilot, 20 mm | 07746 - 0040500 | | | 10, 13 |
| Attachment, 32 x 35 mm | 07746-0010100 | | | 10, 13 |
| Pilot, 15 mm | 07746 - 0040300 | | | 10, 11 |
| Pilot, 22 mm | 07746-0041000 | | | 10 |
| Bearing remover shaft | 00746 - 0050100 | _T Commercially | | 11 |
| Bearing remover head, 15 mm | 07746 - 0050400 | available in U.S.A. | | 11 |
| Tire bead breaker set | 07772 - 0050000 | -Not available in U.S.A. | , | 11 |
| Breaker arm compressor | 07772-0050100 | | | 11 |
| — Breaker arm | 07772 - 0050200 | | | 11 |
| Fork seal driver | 07747-0010100 | ⊤Fork seal driver | 07947-3330000 | 11 |
| Fork seal driver attachment (D) | 07747-0010501 | H | | 11 |
| Extension | 07716 - 0020500 | _T Commercially | | 11 |
| Lock nut wrench, 30 x 32 mm | 07716-0020400 | available in U.S.A. | | 11 |
| Pilot, 35 mm | 07746-0040800 | | | 12 |

VALVE SEAT CUTTER

Valve seat cutters are commercially available in the U.S.A. Therefore in the U.S.A., the following cutters are not required and not available.

| DESCRIPTION | TOOL NUMBER | REF. SEC. |
|--------------------------------------|---------------|-----------|
| Valve seat cutter, 27.5 mm (EX 45°) | 07780-0010200 | 6 |
| Valve seat cutter, 33 mm (IN 45°) | 07780-0010800 | 6 |
| Valve seat cutter, 28 mm (EX 32°) | 07780-0012100 | 6 |
| Valve seat cutter, 33 mm (IN 32°) | 07780-0012900 | 6 |
| Valve seat cutter, 30 mm (IN/EX 60°) | 07780-0014000 | 6 |
| Valve seat cutter holder, 5.5 mm | 07781-0010101 | 6 |


OPTIONAL TOOLS

| DESCRIPTION | TOOL NUMBER | REF. SEC. |
|-------------|---------------|-----------|
| Pin spanner | 89201-KA4-820 | 13 |
| Pin spanner | 89202-KA4-820 | 13 |

CABLE & HARNESS ROUTING


Note the following when routing cables and wire harnesses:


- A loose wire, harness or cable can be a safety hazard.
 After clamping, check each wire to be sure it is secure.
- Do not squeeze wires against the weld or end of a clamp when a weld-on clamp is used.
- Secure wires and wire harnesses to the frame with their respective wire bands at the designated locations.
 Tighten the bands so that only the insulated surfaces contact the wires or wire harnesses.
- Route harnesses so they are not pulled tout or have excessive slack.
- Protect wires and harnesses with electrical tape or tubing if they are in contact with a sharp edge or corner.
 Clean the attaching surface thoroughly before applying tape.
- Do not use wires or harnesses with broken insulators.
 Repair by wrapping them with protective tape or replace them.
- Route wire harnesses to avoid sharp edges or corners.
 Also avoid the projected ends of bolts and screws.
- Keep wire harnesses away from the exhaust pipes and other hot parts.
- Be sure grommets are seated in their grooves properly.
- After clamping, check each harness to be certain that it does not interfere with any moving or sl ding parts.
- Wire harnesses routed along the handlebars should not be pulled tight, have excessive slack, be pinched, or interfere with adjacent or surrounding parts in all steering positions.
- After routing, check that the wire harnesses are not twisted or kinked.
- Do not bend or twist control cables.
 Damaged control cables will not operate smoothly and may stick or bind.




O: CORRECT ×: INCORRECT


′86:















NOISE EMISSION CONTROL SYSTEM (U.S.A. only)

The U.S. Environmental Protection Agency requires manufacturers to certify that vehicles built after January 1, 1983 will comply with applicable noise emission standards for one year or 1,865 miles (3,000 km) after the time of sale to the ultimate purchaser, when operated and maintained according to the instructions provided. Compliance with the terms of the Distributor's Warranty for the Honda Vehicle Noise Emission Control System is necessary in order to keep the noise emission control system in effect.

TAMPERING WITH THE NOISE CONTROL SYSTEM IS PROHIBITED: Federal law prohibits the following acts or the causing thereof: (1) The removal or rendering inoperative by any person, other than for purposes of maintenance, repair, or replacement, of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use; or (2) the use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.

AMONG THOSE ACTS PRESUMED TO CONSTITUTE TAMPERING ARE THE ACTS LISTED BELOW:

- 1. Removal of, or puncturing the muffler, baffle, header pipes or any other component which conducts exhaust gases.
- 2. Removal of, or puncturing of any parts of the intake system.
- 3. Lack of proper maintenance.
- 4. Replacing any moving parts of the vehicle, or parts of the exhaust or intake system, with parts other than those specified by the manufacturer.



2. LUBRICATION

| SERVICE INFORMATION | 2-1 | ENGINE OIL STRAINER SCREEN | 2-2 |
|---------------------|-----|----------------------------|-----|
| TROUBLESHOOTING | 2-1 | ENGINE OIL FILTER ROTOR | 2-2 |
| ENGINE OIL LEVEL | 2-2 | CONTROL CABLE LUBRICATION | 2-3 |
| ENGINE OIL CHANGE | 2-2 | LUBRICATION POINTS | 2-3 |
| | | | |

SERVICE INFORMATION

GENERAL

• Section 8 shows how to service the oil pump.

SPECIFICATIONS

Engine oil capacity 1.8 liter (1.90 US qt, 1.59 lmp qt) at disassembly


1.5 liter (1.59 US qt, 1.32 lmp qt) after draining

Engine oil recommendation Use Honda 4-stroke oil or equivalent.

API Service Classification: SE or SF

Viscosity: SAE 10 W-40

Other viscosities shown in the chart may be used when the average temperature in your riding area is within the indicated range.



TORQUE VALUE

Oil drain bolt

35-40 N·m (3.5-4.0 kg-m, 25-29 ft-lb)

TROUBLESHOOTING

Oil level too low - high oil consumption

- External oil leaks
- · Worn piston rings
- · Worn valve guide or seal


Oil contamination

- · Oil not changed often enough
- Head gasket faulty
- Worn piston rings

ENGINE OIL LEVEL

Place the ATC on level ground. Check the oil level with the oil filler cap/dipstick. Do not screw it in when making this check.

If the oil level is below or near the lower level line on the dipstick, add the recommended oil (page 2-1) up to the upper level line.



ENGINE OIL CHANGE

NOTE

Drain the oil with the engine warm.

Remove the oil filler cap and drain bolt and drain the oil.

Operate the kick starter several times to completely drain any residual oil.

Check that the sealing washer on the drain bolt is in good condition and install the drain bolt.

TORQUE: 35-40 N·m (3.5-4.0 kg-m, 25-29 ft-lb)

Fill the crankcase with the recommended oil.

ENGINE OIL CAPACITY:

1.5 liters (1.59 US qt, 1.32 Imp qt) after draining

Install the oil filler cap/dipstick.

Start the engine and let it idle for 2 or 3 minutes. Stop the engine and check that the oil level is at the upper level line on the dipstick. Add more oil if necessary. Make sure there are no oil leaks.

ENGINE OIL STRAINER SCREEN

Remove the right crankcase cover (page 8-3). Remove the oil strainer screen and clean it.

Install the oil strainer screen with the thick end to the right crankcase cover side.


Install the right crankcase cover (page 8-5).


ENGINE OIL FILTER ROTOR


Remove the right crankcase cover (page 8-3). Remove the oil filter rotor cover and clean the rotor.

Make sure that the rotor cover gasket is in good condition and install the oil filter rotor cover.

Install the right crankcase cover (page 8-5).







CONTROL CABLE LUBRICATION

Periodically disconnect the throttle, clutch, parking brake and decompressor cables at their upper ends.

Throughly lubricate the cables and their pivot points with a commercially available lubricant.

LUBRICATION POINTS

Use general purpose grease when no other specification is given. Apply oil or grease to any 2 sliding surfaces.



MEMO

3. MAINTENANCE

| SERVICE INFORMATION 3-1 DRIVE CHAIN 3-10 MAINTENANCE SCHEDULE 3-2 DRIVE CHAIN SLIDER AND ROLLER 3-12 FUEL LINE 3-4 BRAKE FLUID 3-12 FUEL STRAINER SCREEN 3-4 BRAKE PADS 3-13 FUEL STRAINER CLEANING 3-4 BRAKE SYSTEM 3-13 THROTTLE OPERATION 3-4 SKID PLATE, GUARD PLATE 3-15 AIR CLEANER 3-5 CLUTCH SYSTEM 3-15 AIR CLEANER 3-7 SUSPENSION 3-15 SPARK PLUG 3-7 NUTS, BOLTS, FASTENERS 3-16 IGNITION TIMING 3-8 WHEELS/TIRES 3-16 CYLINDER COMPRESSION 3-8 STEERING HEAD BEARINGS 3-17 VALVE CLEARANCE 3-8 SPARK ARRESTER 3-17 CARBURETOR IDLE SPEED 3-10 | | | | |
|---|-----------------------------|------|-------------------------------|------|
| FUEL LINE 3-4 BRAKE FLUID 3-12 FUEL STRAINER SCREEN 3-4 BRAKE PADS 3-13 FUEL STRAINER CLEANING 3-4 BRAKE SYSTEM 3-13 THROTTLE OPERATION 3-4 SKID PLATE, GUARD PLATE 3-15 AIR CLEANER 3-5 CLUTCH SYSTEM 3-15 AIR CLEANER CASE DRAIN TUBE 3-7 SUSPENSION 3-15 SPARK PLUG 3-7 NUTS, BOLTS, FASTENERS 3-16 IGNITION TIMING 3-8 WHEELS/TIRES 3-16 CYLINDER COMPRESSION 3-8 STEERING HEAD BEARINGS 3-17 VALVE CLEARANCE 3-8 SPARK ARRESTER 3-17 | SERVICE INFORMATION | 3-1 | DRIVE CHAIN | 3-10 |
| FUEL STRAINER SCREEN FUEL STRAINER CLEANING THROTTLE OPERATION AIR CLEANER AIR CLEANER SPARK PLUG IGNITION TIMING CYLINDER COMPRESSION 3-4 BRAKE SYSTEM 3-13 SHAKE SYSTEM 3-15 CLUTCH SYSTEM 3-15 SUSPENSION 3-15 SUSPENSION 3-16 CYLINDER COMPRESSION 3-8 WHEELS/TIRES 3-16 SPARK ARRESTER 3-17 | MAINTENANCE SCHEDULE | 3-2 | DRIVE CHAIN SLIDER AND ROLLER | 3-12 |
| FUEL STRAINER CLEANING THROTTLE OPERATION 3-4 SKID PLATE, GUARD PLATE 3-15 AIR CLEANER 3-5 CLUTCH SYSTEM 3-15 AIR CLEANER CASE DRAIN TUBE 3-7 SUSPENSION 3-15 SPARK PLUG 3-7 NUTS, BOLTS, FASTENERS 3-16 IGNITION TIMING 3-8 WHEELS/TIRES 3-17 VALVE CLEARANCE 3-8 SPARK ARRESTER 3-17 | FUEL LINE | 3-4 | BRAKE FLUID | 3-12 |
| THROTTLE OPERATION 3-4 SKID PLATE, GUARD PLATE 3-15 AIR CLEANER 3-5 CLUTCH SYSTEM 3-15 AIR CLEANER CASE DRAIN TUBE 3-7 SUSPENSION 3-15 SPARK PLUG 3-7 NUTS, BOLTS, FASTENERS 3-16 IGNITION TIMING 3-8 WHEELS/TIRES 3-16 CYLINDER COMPRESSION 3-8 STEERING HEAD BEARINGS 3-17 VALVE CLEARANCE 3-8 SPARK ARRESTER 3-15 3-15 3-17 | FUEL STRAINER SCREEN | 3-4 | BRAKE PADS | 3-13 |
| AIR CLEANER CASE DRAIN TUBE 3-7 SUSPENSION 3-15 SPARK PLUG 3-7 NUTS, BOLTS, FASTENERS 3-16 IGNITION TIMING 3-8 WHEELS/TIRES 3-16 CYLINDER COMPRESSION 3-8 STEERING HEAD BEARINGS 3-17 VALVE CLEARANCE 3-8 SPARK ARRESTER 3-17 | FUEL STRAINER CLEANING | 3-4 | BRAKE SYSTEM | 3-13 |
| AIR CLEANER CASE DRAIN TUBE 3-7 SUSPENSION 3-15 SPARK PLUG 3-7 NUTS, BOLTS, FASTENERS 3-16 IGNITION TIMING 3-8 WHEELS/TIRES 3-16 CYLINDER COMPRESSION 3-8 STEERING HEAD BEARINGS 3-17 VALVE CLEARANCE 3-8 SPARK ARRESTER 3-17 | THROTTLE OPERATION | 3-4 | SKID PLATE, GUARD PLATE | 3-15 |
| SPARK PLUG 3-7 NUTS, BOLTS, FASTENERS 3-16 IGNITION TIMING 3-8 WHEELS/TIRES 3-16 CYLINDER COMPRESSION 3-8 STEERING HEAD BEARINGS 3-17 VALVE CLEARANCE 3-8 SPARK ARRESTER 3-17 | AIR CLEANER | 3-5 | CLUTCH SYSTEM | 3-15 |
| IGNITION TIMING3-8WHEELS/TIRES3-16CYLINDER COMPRESSION3-8STEERING HEAD BEARINGS3-17VALVE CLEARANCE3-8SPARK ARRESTER3-17 | AIR CLEANER CASE DRAIN TUBE | 3-7 | SUSPENSION | 3-15 |
| CYLINDER COMPRESSION 3-8 STEERING HEAD BEARINGS 3-17 VALVE CLEARANCE 3-8 SPARK ARRESTER 3-17 | SPARK PLUG | 3-7 | NUTS, BOLTS, FASTENERS | 3-16 |
| VALVE CLEARANCE 3-8 SPARK ARRESTER 3-17 | IGNITION TIMING | 3-8 | WHEELS/TIRES | 3-16 |
| | CYLINDER COMPRESSION | 3-8 | STEERING HEAD BEARINGS | 3-17 |
| CARBURETOR IDLE SPEED 3-10 | VALVE CLEARANCE | 3-8 | SPARK ARRESTER | 3-17 |
| | CARBURETOR IDLE SPEED | 3-10 | | |

SERVICE INFORMATION

SPECIFICATIONS

ENGINE

Ignition timing Initial 10° BTDC at 1,400 \pm 100 rpm

Full advance 28° BTDC at 3,500 ±200 rpm

Spark plug Spark plug gap 0.6-0.7 mm (0.024-0.028 in)

Recommended spark plugs NGK: DR8ES-L

Valve clearance IN (cold)

ND: X24ESR-U
0.08 mm (0.003 in)

 $\begin{array}{ccc} \text{EX (cold)} & \text{0.08 mm (0.003 in)} \\ \text{Throttle lever free play} & 3-8 \text{ mm (1/8}-5/16 \text{ in)} \end{array}$

Idle speed $1,400 \pm 100 \text{ rpm}$

Cylinder compression $1,300 \pm 100 \text{ kPa } (13.0 \pm 1 \text{ kg/cm}^2, 184.7 \pm 14.2 \text{ psi})$

Decompressor cam follower shaft arm free play 0.5-1.5 mm (0.02-0.06 in)

CHASSIS

Drive chain slack 25-35 mm (1.0-1.4 in)

Drive chain slider wear limit 6 mm (0.24 in) Rear brake pedal height 20 mm (3/4 in)

Parking brake lever free play '86: 31-39 mm (1-3/16-1-1/2 in)After '86: 25-30 mm (1-1-1/8 in)

10-20 mm (3/8-3/4 in)

Front tire size, pressure $23.5 \times 8-11$, 25 kPa (0.25 kg/cm², 3.6 psi)

Rear tire size, pressure '86: 17 kPa (0.17 kg/cm², 2.5 psi)
After '86: 17.5 kPa (0.175 kg/cm², 2.5 psi)

Front tire circumference ('86 only)

Rear tire circumference ('86 only)

Front suspension air pressure

1,890 mm (74.4 in)

1,720 mm (67.7 in)

6 kPa (0 kg/cm², 0 psi)

TORQUE VALUES

Clutch lever free play

Fuel strainer cup $3-5 \text{ N} \cdot \text{m} (0.3-0.5 \text{ kg-m}, 2.2-3.6 \text{ ft-lb})$ Drive chain adjuster lock bolts $18-24 \text{ N} \cdot \text{m} (1.8-2.4 \text{ kg-m}, 13-17 \text{ ft-lb})$ Valve adjuster lock bolts $10-14 \text{ N} \cdot \text{m} (1.0-1.4 \text{ kg-m}, 7.2-10 \text{ ft-lb})$ Parking brake adjusting lock nut $15-20 \text{ N} \cdot \text{m} (1.5-2.0 \text{ kg-m}, 11-15 \text{ ft-lb})$ Camshaft inspection hole cap $2.5-4.5 \text{ N} \cdot \text{m} (0.25-0.45 \text{ kg-m}, 1.8-3.3 \text{ ft-lb})$

MAINTENANCE SCHEDULE

• The maintenance intervals shown in the following schedules are based upon average riding conditions. ATCs subjected to severe use, or ridden in unusually dusty areas, require more frequent servicing.

'86:

Perform the Pre-ride Inspection in the Owner's Manual at each scheduled maintenance period.

| I: Inspect and Clean, Adjust, Lubricate or Replace, if necessary C: Clean R: Replace L: Lubricate A: Adjust | | INITIAL SERVICE PERIOD (First week of | REGULAR SERVICE PERIOD (Every 30 | Refer to page |
|---|--------------------------|--|---|---------------|
| • | EVERY | operation) | operating days) | |
| * FUEL LINE | YEAR: I | | | 3-4 |
| * FUEL STRAINER SCREEN | YEAR: C | | | 3-4 |
| * THROTTLE OPERATION | | l | ı | 3-4 |
| AIR CLEANER | NOTE (1) | | I | 3-5 |
| AIR CLEANER CASE DRAIN TUBE | NOTE (2) | | I | 3-7 |
| SPARK PLUG | | | 1 | 3-7 |
| * VALVE CLEARANCE | | I | I | 3-8 |
| ENGINE OIL | | R | R | 2-2 |
| * ENGINE OIL STRAINER SCREEN | | | С | 2-2 |
| * ENGINE OIL CENTRIFUGAL FILTER | | | С | 2-2 |
| * CARBURETOR IDLE SPEED | | I | l | 3-10 |
| DRIVE CHAIN | NOTE (1), (2) | I,L | I,L | 3-10 |
| DRIVE CHAIN SLIDER AND ROLLER | | | ı | 3-12 |
| BRAKE FLUID | 2 YEARS: R, I | l | I | 3-12 |
| * BRAKE PAD WEAR | YEAR: I NOTE (1), (2) | | | 3-13 |
| BRAKE SYSTEM | | I | ı | 3-13 |
| * CLUTCH SYSTEM | | I | I | 3-15 |
| * SUSPENSION | | | ı | 3-15 |
| * SPARK ARRESTER | NOTE (3) | | С | 3-17 |
| * NUTS, BOLTS, FASTENERS | | I | I | 3-16 |
| ** WHEELS/TIRES | | I | ı | 3-16 |
| ** STEERING HEAD BEARINGS | YEAR: I | | | 3-17 |

^{*} Should be serviced by an authorized Honda dealer, unless the owner has proper tools and is mechanically qualified.

NOTES: (1) Service more frequently when riding in dusty areas, sand or snow.

(2) Service more frequently after riding in very wet or muddy conditions.

(3) U.S.A. only.

^{**} In the interest of safety, we recommend these items be serviced only by authorized Honda dealer.

After '86: Perform the Pre-ride Inspection in the Owner's Manual at each scheduled maintenance period.

| C: | I: Inspect and Clean, Adjust, Lubricate or Replace, if necessary C: Clean R: Replace A: Adjust | | INITIAL SERVICE PERIOD (First week of | REGULAR SERVICE PERIOD (Every 30 | Refer to page |
|-----|--|--------------------------|--|---|---------------|
| | , | EVERY | operation) | operating days) | |
| * | FUEL LINE | YEAR: I | | | 3-4 |
| * | FUEL STRAINER SCREEN | YEAR: C | | | 3-4 |
| * | THROTTLE OPERATION | | I | I | 3-4 |
| | AIR CLEANER | NOTE (1) | | С | 3-5 |
| | AIR CLEANER CASE DRAIN TUBE | NOTE (2) | | I | 3-7 |
| | SPARK PLUG | | | ı | 3-7 |
| * | VALVE CLEARANCE | | ı | ı | 3-8 |
| | ENGINE OIL | | R | R | 2-2 |
| * * | ENGINE OIL STRAINER SCREEN | NOTE (3) | | | 2-2 |
| * * | ENGINE OIL CENTRIFUGAL FILTER | NOTE (3) | | | 2-2 |
| * | CARBURETOR IDLE SPEED | | ı | 1 | 3-10 |
| | DRIVE CHAIN | NOTE (1), (2) | I,L | I,L | 3-10 |
| | DRIVE CHAIN SLIDER | | | 1 | 3-12 |
| | BRAKE FLUID | 2 YEARS: R | | I | 3-12 |
| * | BRAKE PAD WEAR | YEAR: I NOTE (1), (2) | | | 3-13 |
| | BRAKE SYSTEM | | 1 | I | 3-13 |
| | SKID PLATE, GUARD PLATE | | | 1 | 3-15 |
| * | CLUTCH SYSTEM | | I | ŀ | 3-15 |
| * | SUSPENSION | | | 1 | 3-15 |
| * | SPARK ARRESTER | NOTE (4) | | С | 3-17 |
| * | NUTS, BOLTS, FASTENERS | | 1 | I | 3-16 |
| * * | WHEELS/TIRES | | 1 | I | 3-16 |
| * * | STEERING HEAD BEARINGS | YEAR: I | | | 3-17 |

^{*} Should be serviced by an authorized Honda dealer, unless the owner has proper tools and is mechanically qualified.

NOTES: (1) Service more frequently when riding in dusty areas, sand or snow.

- (2) Service more frequently after riding in very wet or muddy conditions.
- (3) Clean at first 30 days of operation and every year.
- (4) U.S.A. only.

^{**} In the interest of safety, we recommend these items serviced only by an authorized Honda dealer.

FUEL LINE

Replace any parts which show signs of deterioration, damage or leaks.

FUEL STRAINER SCREEN

Turn the fuel valve "OFF".

Remove the fuel cup, O-ring and strainer screen, and drain the gasoline into a suitable container.

WARNING

Gasoline is flammable and is explosive under certain conditions. Do not smoke or allow flames or sparks near the equipment while draining fuel.

Wash the cup and strainer screen in clean nonflammable or high flash point solvent.

Reinstall the screen, aligning the index marks on the fuel valve body and strainer screen.

Install a new O-ring into the fuel valve body.

Reinstall the fuel cup, making sure the new O-ring is in place. Hand tighten the fuel cup and then torque it to specification.

TORQUE: 3-5 N·m (0.3-0.5 kg-m, 2.2-3.6 ft-lb)

CAUTION

• Do not overtighten the fuel cup.

After installing, turn the fuel valve ''ON'' and check that there are no fuel leaks.

FUEL STRAINER CLEANING

Disconnect the fuel tube.

Drain fuel from the fuel tank into a suitable container.

WWARNING

- · Keep gasoline away from flames or sparks.
- Wipe up spilled gasoline at once.

Remove the fuel valve by loosening the valve lock nut. Remove and clean the strainer.

Make sure the O-ring is in good condition.

Install the strainer and valve, and attach the fuel line.

TORQUE: FUEL VALVE LOCK NUT

 $20-25 \text{ N} \cdot \text{m} (2.0-2.5 \text{ kg-m}, 15-18 \text{ ft-lb})$

Fill the fuel tank, turn the fuel valve to "ON" and check for leaks.


THROTTLE OPERATION


Check for smooth throttle lever full opening and automatic full closing in all steering positions.


Make sure there is no deterioration, damage or kinking in the throttle cable. Replace any damaged parts.


Make sure the throttle lever free play is 3-8 mm (1/8-5/16 in) at the tip of the throttle lever.

THROTTLE LEVER FREE PLAY: 3-8 mm (1/8-5/16 in)










To adjust the free play slide back the rubber cap, loosen the lock nut and turn the adjuster.

Tighten the lock nut and reinstall the rubber cap.

Check that the throttle lever moves smoothly and returns completely.




Remove the throttle housing cover.

Disconnect the throttle cable at the upper end.

Thoroughly lubricate the cable and pivot point with a commercially available cable lubricant or grease.


Install the throttle cable in the reverse order of removal.



AIR CLEANER

Slide the release lever to the left and remove the seat/rear fender.

Release the four clips retaining the air cleaner cover. Remove the air cleaner cover.




′86:

Loosen the element band.

Remove the element holder stay attaching screw and element holder.

Remove the element holder stay from the holder, then remove the element from the holder.



Wash the element in non-flammable or high flash point solvent, squeeze out the solvent thoroughly, and allow the element to dry.

WARNING

 Never use gasoline or low flash point solvents for cleaning the air cleaner element. A fire or explosion could result.

Soak the element in gear oil (SAE #80-90) and squeeze out the excess.

Reinstall the air cleaner element on the element holder.

Install the element holder stay to the holder.


Apply a light coat of grease to the sealing edge (open side) of the holder.


Install the element holder into the case and tighten the element holder band.

Install the air cleaner case cover and seat/rear fender.


After '86:

Remove the screws and the air cleaner assembly from the frame air cleaner case.





Remove the foam element from the paper element.




Wash the foam element in clean soapy water and squeeze out the excess water.

CAUTION

- Do not twist or wring the foam element; the service life of the filter will be reduced.
- Do not apply oil to the foam element.

NOTE

 Replace the foam element if there are any tears or holes in it.



Remove the dust from the paper element by blowing compressed air through the filter. Direct the air from the inside out as much as possible to prevent forcing dirt into the paper. If the paper element is excessively dirty or muddy, wash it with clean water. Shake out the excess water and allow the element to dry thoroughly.

CAUTION

- Use only clean water to wash and rinse the paper element. Using dirty water will allow dirt to get inside the paper element which may cause rapid piston and ring wear.
- Do not apply oil to the paper element.

NOTE

- Engine performance will be reduced if the filter elements are wet or excessively dirty.
- If washing an excessively dirty paper element does not restore engine performance, replace the paper element with a new one.

Reinstall the foam element onto the paper element. Be sure that both open ends of the foam element seats fully against the outside edge of the paper element. Reinstall the air cleaner assembly in reverse order of removal.

CAUTION

 When installing the air cleaner elements, check that there is no dust or other foreign matter on the inside surface.

AIR CLEANER CASE DRAIN TUBE

Remove the drain tube and empty any accumulation. Install the drain tube.

NOTE

 Service more frequently when riding in rain or at full throttle.

SPARK PLUG

Disconnect the spark plug cap and remove the spark plug. Visually inspect the spark plug electrodes for wear.

The center electrode should have square edges and the side electrode should have a constant thickness.

Discard the spark plug if there is apparent wear or if the insulator is cracked or chipped. Measure the gap with a wire-type feeler gauge and adjust by carefully bending the side electrode.

SPARK PLUG GAP: 0.6-0.7 mm (0.024-0.028 in) RECOMMENDED SPARK PLUG:


| NGK | DR8ES-L |
|-----|----------|
| ND | X24ESR-U |


Make sure the sealing washer is in good condition. Install the spark plug, tighten it by hand, then tighten with a spark plug wrench.


NOTE

• Tighten a new spark plug 1/2 turn to compress the washer. If reusing a spark plug, it should only take 1/8-1/4 turn after the plug seats.

Connect the spark plug cap.







IGNITION TIMING

NOTE

 The Capacitive Discharge Ignition (CDI) system is factory pre-set and does not require adjustment. To inspect the funciton of the CDI components, ignition timing inspection procedures are given here.

Remove the timing hole cap.

Connect a tachometer and timing light.

Start the engine and allow it to idle.

IDLE SPEED: $1,400 \pm 100 \text{ rpm}$

Inspect the ignition timing.

Timing is correct if the "F" mark on the flywheel is aligned with the index mark on the left crankcase cover at idle.

Raise the engine speed and check timing advance.

At 1,800 \pm 200 rpm: Timing advance should start.

At 3,500 \pm 200 rpm: Timing advance should cease. The index mark should be between the full

advance marks.

If the ignition timing is incorrect, refer to page 16-3.



Warm up the engine.

Stop the engine and remove the spark plug.

Disconnect the decompressor cable at the cam follower shaft arm.

Insert a compression gauge in the spark plug hole.

Push the choke lever down fully.

Open the throttle lever fully and operate the kick starter pedal several times.

NOTE

Be sure compression does not leak at the gauge connection.

COMPRESSION: 1,300 ± 100 kPa

 $(13.0 \pm 1.0 \text{ kg/cm}^2, 184.7 \pm 14.2 \text{ psi})$

Low compression can be caused by:

- · Improper valve adjustment.
- Valve leakage.
- Blown cylinder head gasket.
- · Worn piston ring or cylinder.

High compression can be caused by:

• Carbon deposits in combustion chamber or on piston head.


Connect and adjust the decompressor cable (page 3-9). Install the spark plug.


VALVE CLEARANCE


NOTE


 Inspect and adjust valve clearance while the engine is cold (below 35°C/95°F).

Remove the crankshaft hole cap and timing hole cap. Rotate the crankshaft counterclockwise and align the "T" mark on the flywheel with the index mark or the left crankcase cover.









Remove the valve adjuster cover.




Remove the camshaft inspection hole cap from the cylinder head cover and check that timing mark on the camshaft is visible (facing up).

If the mark is not visible, turn the crankshaft 360° and re-align the ''T'' mark on the flywheel with the index mark on the left crankcase cover.

NOTE

 When the "T" mark is aligned with the index mark and the timing mark is visible (facing up), the piston is at top dead center on the compression stroke.



Loosen the valve adjuster lock bolts fully.

Move the intake and exhaust valve adjusters counterclockwise fully, untill resistance is felt.

Then move them clockwise the equivalent of 1/2 graduation. Tighten the adjuster lock bolts.

TORQUE: 10-14 N·m (1.0-1.4 kg-m, 7.2-10 ft-lb)

NOTE

- Make sure that the adjusters do not move when tightening the lock bolts.
- 1/2 graduation on the adjusters equals 0.08 mm (0.003 in), which is specified clearance.


Adjust the decompression system.


DECOMPRESSOR ADJUSTMENT

NOTE

 Always adjust the decompressor cable after adjusting the valve clearance.

Rotate the flywheel counterclockwise and align the "T" mark with the index mark. Make sure the piston is at TDC on the compression stroke.





Measure the free play at the tip of the cam follower shaft arm. FREE PLAY: 0.5-1.5 mm (0.02-0.06 in)

Adjust by loosening the lock nut and turning the adjusting nut.

CAUTION

- Excessive free play causes hard starting.
- Insufficient free play may cause erratic engine idle and valve damage.

Install the timing and camshaft inspection hole caps and the valve adjuster cover.

TORQUE: CAMSHAFT INSPECTION HOLE CAP

 $2.5-4.5 \text{ N}\cdot\text{m}$ (0.25-0.45 kg-m, 1.8-3.3 ft-lb)

CARBURETOR IDLE SPEED

NOTE

- Inspect and adjust the idle speed after all other maintenance items have been performed and are within specifications.
- The engine must be warm for accurate idle speed inspection and adjustment. Stop and go riding for ten minutes is sufficient.

After warming up the engine, shift the transmission into neutral and connect a tachometer.

Turn the throttle stop screw as required to obtain the specified idle speed.

IDLE SPEED: $1,400 \pm 100 \text{ rpm}$

DRIVE CHAIN

CHAIN SLACK INSPECITON

WARNING

 Never inspect or lubricate the drive chain while the engine is running.

With the engine off, shift the transmission into neutral. Measure the drive chain slack at up side midway between the sprockets.

CHAIN SLACK: 25-35 mm (1.0-1.4 in)

CHAIN SLACK ADJUSTMENT

Loosen the two lock bolts.

Turn the adjuster to decrease or increase chain slack using the adjusting tool provided in the tool kit.

INCREASE: Turn the adjuster clockwise


DECREASE: Turn the adjuster counterclockwise

Tighten the lock bolts.


TORQUE: 18-24 N·m (1.8-2.4 kg-m, 13-17 ft-lb)


NOTE

 If drive chain slack is excessive when the adjuster is moved to the limit of adjustment, the drive chain is worn out and must be replaced.










DRIVE CHAIN/SPROCKET INSPECTION/ LUBRICATION

Inspect the sprocket teeth for excessive wear or damage. Replace if necessary.

NOTE

- Never install a new drive chain on worn sprockets or a worn chain on new sprockets.
- Both chain and sprockets must be in good condition, or the new replacement chain or sprockets will wear rapidly.




Visually inspect the drive chain for kinks or damage.

Measure a section of the drive chain to determine whether the chain is worn beyond its service limit.

Remove the drive chain and measure the distance between a span of 85 pins from pin center to pin center.

In a new chain, this distance 1,356 mm (53.4 in), the chain is worn out and should be replaced.

REPLACEMENT DRIVE CHAIN: DID520 V-6 or RK520SMOZ10



Clean the chain with kerosene. Wipe dry and lubricate only with SAE #80 or #90 gear oil. Commercial chain lubricants may contain solvents which could damage the rubber O-rings.

CAUTION

 Do not use a steam cleaner, high pressure washers or aerosol chain lubricants as these will damage the O-rings.

Inspect the drive chain and O-rings for possible wear or damage. Replace the chain, if it is worn excessively or damaged.

Lubricate the drive chain with SAE #80 or #90 gear oil.

(2)LUBRICATE SAE #80-90 GEAR OIL

INSTALLATION

Install the drive chain.


Install the master link with O-rings and chain retaining clip.

Note the installation direction of the chain retaining clip. Its open end should face in the opposite direction of the wheel rotation as shown.

Adjust the drive chain slack.


CAUTION

 Do not assemble the drive chain without the four O-rings. Be sure that there is no space between the master link and chain retaining clip.




DRIVE CHAIN SLIDER AND ROLLER

Check the drive chain slider at the intervals specified in the Maintenance Schedule.



When the depth of the grooves in the slider reaches 2.0 mm (0.08 in), remove material to lower the height of the center ridge between the grooves to less than 2.0 mm (0.08 in).


Replace the slider when the depth of the grooves reaches $6.0 \,$ mm $(0.24 \, \text{in}).$



BRAKE FLUID

CAUTION


- Do not remove the cap until the handlebar has been turned so that the front reservoir is level.
- Do not mix DOT5 with DOT3 or 4 Brake Fluid.
- Avoid spilling fluid on painted, plastic or rubber parts. Place a rag over these parts whenever the system is serviced.



Check the front and rear brake fluid reservoir levels.

If the level nears the lower level mark, remove the cap and fill the reservoir with DOT-3 or 4 brake fluid to the upper level mark.

Check the entire system for leaks, if either level is low.



BRAKE PADS

Inspect the front and rear brake pads for wear.

Replace the brake pads if the wear groove on the pads reaches the edge of the brake disc.

CAUTION

Always replace the brake pads as a set to assure even disc pressure.


Refer to page 14-5 for brake pad replacement.

(2) REAR (2) REAR (3) WEAR GROOVES (3) WEAR GROOVES

BRAKE SYSTEM

Inspect the brake hoses and fittings for deterioration, cracks and signs of leakage. Tighten any loose fittings.

Replace hoses and fittings as required.




REAR BRAKE PEDAL HEIGHT

Check that the distance between the pedal and upper face of the footpeg is 20 mm (3/4 in).

CAUTION

Incorrect brake pedal height can cause brake drag.

To adjust the height, loosen the lock nut and turn the master cylinder push rod. Tighten the lock nut.



PARKING BRAKE

A parking brake adjustment may be required if the parking brake does not hold the rear wheels properly:


Disconnect the clutch cable at the lower end.

Press the parking brake button and pull in the clutch/parking brake lever.

Measure the free play at the tip of the lever.

FREE PLAY: '86: 31-39 mm (1-3/16-1-1/2 in)

After '86: 25-30 mm (1-1-1/8 in)



MAINTENANCE


'86:

Adjust as follows:

Loosen the lock nut on the rear caliper.


Screw in the adjusting bolt until you feel resistance without applying the clutch/parking brake lever, and tighten the lock nut.

TORQUE: 15-20 N·m (1.5-2.0 kg-m, 11-15 ft-lb)



Recheck the lever free play and adjust, if necessary, by loosening the lock nut and turning the adjuster.

Tighten the lock nut, and reconnect the clutch cable.



After '86:


Adjust as follows:

Temporarily adjust the clutch lever free play to more than 30 mm (1-1/8 in) (page 3-15).

Loosen the lock nut on the parking brake lever and screw in the adjuster completely.

Loosen the lock nut on the rear caliper and turn the adjusting bolt clockwise until you feel resistance.


Then turn the adjusting bolt 1/8 counterclockwise and tighten the lock nut.



Push down the parking brake button and then squeeze the parking brake lever until firm resistance is felt.

Measure the distance the parking brake lever has moved; the distance should be $25-30~{\rm mm}~(1-1-1/8~{\rm in})$.

If necessary, turn the adjuster and tighten the lock nut. Adjust the clutch lever free play to 10-20 mm (3/8-3/4 in) (page 3-15).




SKID PLATE, GUARD PLATE

The engine under guard and skid plate protect the engine and rear axle holder from rocks.

Check the under guard and plate for cracks, damage or looseness at intervals shown in the Maintenance Schedule.

Replace the under guard and plate with new ones if they are cracked or damaged.


If the under guard and plate bolts are loose, tighten them securely.



CLUTCH SYSTEM

Measure the clutch lever free play.

FREE PLAY: 10-20 mm (3/8-3/4 in)



Adjust as follows:


Perform minor adjustments with the upper adjuster. Pull the cover back.

Loosen the lock nut and turn the adjuster. Tighten the lock nut.

Perform major adjustments with the lower adjusting nut.

Loosen the lock nut and turn the adjusting nut. Tighten the lock nut.

Check the clutch operation.



SUSPENSION

FRONT SUSPENSION


Check the action of the front forks by compressing them several times.

Check the entire fork assembly for signs of leaks or damage. Replace damaged components which are unrepairable.

NOTE

· Do not repair bent fork tubes. They must be replaced.

Tighten all nuts and bolts to the specified torque values.



MAINTENANCE


Raise the front of the vehicle so that there is no weight on the front wheel.

Check air pressure in each fork tube.

STANDARD AIR PRESSURE: 0 kPa (0 kg/cm², 0 psi)

NOTE

Use of more than 70 kPa (0.7 kg/cm², 10 psi) is not recommended because fork action becomes very stiff.



REAR SUSPENSION

Check the shock absorber for a leak or damage.

Check the suspension operation. Adjust the spring preload if necessary (page 13-7).

Raise the rear wheels off the ground with a jack or block under the engine.

Move the rear axle sideways with force to see if the wheel and swingarm bearings are worn.


Replace the bearings if there is any play (section 13).



NUTS, BOLTS, FASTENERS

Tighten bolts, nuts and fasteners at regular intervals as shown in the Maintenance Schedule.

Check that all chassis nuts and bolts are tightened to their correct torque values (page 1-5). Check that all cotter pins and safety clips are in place.



WHEELS/TIRES


Check the tire for cuts, imbedded nails, or other damage.

Measure the groove depth of tires at the center as shown. Operating the vehicle with excessively worn tires will decrease traction and increase skidding.

WARNING

Replace tires before tread depth at the center of the tires reaches the minimum limit.

Minumum tread depth: 4 mm (0.16 in)



NOTE

- · Tire pressure should be checked when the tires are COLD.
- '86: Raise the wheels off the ground when measuring tire circumferences.

'86:

Check the tire pressure and measure the tire circumference. Adjust accordingly.

| | Front | Rear |
|-----------------------------|----------------------------------|----------------------------------|
| Recommended pressure | 3.6 psi (25 kPa, 0.25 kg/cm²) | 2.5 psi (17 kPa, 0.17 kg/cm²) |
| Standard tire circumference | 1,890 mm (74.4 in) | 1,720 mm (67.7 in) |
| Max. pressure | 4.1 psi (28 kPa, 0.28 kg/cm²) | 2.9 psi (20 kPa, 0.20 kg/cm²) |
| Min. pressure | 3.2 psi (22 kPa, 0.22 kg/cm²) | 2.0 psi (14 kPa, 0.14 kg/cm²) |



After '86:

Check the tire pressure and adjust accordingly.

| | | • . |
|----------------------|----------------------------------|-------------------------------------|
| | Front | Rear |
| Recommended pressure | 3.6 psi (25 kPa, 0.25 kg/cm²) | 2.5 psi (17.5 kPa, 0.175 kg/cm²) |
| Max. pressure | 4.1 psi (28 kPa, 0.28 kg/cm²) | 2.9 psi (20.5 kPa, 0.205 kg/cm²) |
| Min. pressure | 3.2 psi (22 kPa, 0.22 kg/cm²) | 2.1 psi (14.5 kPa, 0.145 kg/cm²) |

STEERING HEAD BEARINGS


NOTE

 Make sure the cables do not interfere with the rotation of the handlebar.

Raise the front wheel off the ground and make sure that the handlebar rotates freely.

If the handlebar moves unevenly, binds or has vertical play adjust the steering head bearings (page 11-25).

If the handlebar still moves unevenly binds or has vertical play after adjustment, inspect the steering head bearings and replace if necessary (page 11-23).




SPARK ARRESTER

WWARNING


- Do not remove or install the muffler lid while the exhaust pipe is hot.
- Perform this operation in a well-ventilated area, free from fire hazard.
- Use adequate eye protection.

Remove the muffler lid. Block the end of the muffler with a shop towel.



MAINTENANCE

Start the engine and rev it up to blow accumulated carbon deposits out the muffler.




Be sure that the muffler lid bolts and gasket are in good condition. Replace the bolts and gasket if necessary.


Install the muffler lid and gasket and tighten the bolts securely.

CAUTION

- Do not remove the two screws from the end of the spark arrester.
- The two mounting screws must be installed in the spark arrester body at all times for the spark arrester to be effective.



| МЕМО |
|------|
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |



| SERVICE INFORMATION | 4-1 | CARBURETOR DISASSEMBLY | 4-7 |
|---------------------|-----|--------------------------|------|
| TROUBLESHOOTING | 4-2 | CARBURETOR ASSEMBLY | 4-9 |
| FUEL TANK | 4-3 | FLOAT LEVEL INSPECTION | 4-9 |
| AIR CLEANER CASE | 4-4 | CARBURETOR INSTALLATION | 4-10 |
| THROTTLE VALVE | 4-5 | PILOT SCREW ADJUSTMENT | 4-10 |
| CARBURETOR REMOVAL | 4-6 | HIGH ALTITUDE ADJUSTMENT | 4-11 |
| ł | | | |

SERVICE INFORMATION

GENERAL

₩WARNING

· Keep gasoline away from flames or sparks. Wipe up spilled gasoline at once.

CAUTION

- · Do not bend or twist control cables. Damaged control cables will not operate smoothly and may stick or bind.
- Use caution when working with gasoline. Always work in a well ventilated area away from sparks or flames.
- When disassembling fuel system parts, note the locations of the O-rings. Replace them with new O-rings during reassembly.
- The carburetor float bowl has a drain screw that can be loosened to drain gasoline.

SPECIFICATIONS

Fuel tank capacity Fuel reserve capacity 10.5 liter (2.78 US gal, 2.31 lmp gal) 1.5 liter (0.40 US gal, 0.33 lmp gal)

Carburetor

| | ′86 | After '86 | |
|--------------------------|---|------------|----------|
| Identification number | PD64A 🖪 | PD64A B, C | PD3AA |
| Type | Piston valve | ← | ← |
| Venturi diameter | 24 mm (0.94 in) | ← | ← |
| Float level | $14.0 \pm 0.5 \text{ mm } (0.55 \pm 0.02 \text{ in})$ | ← | ← |
| Pilot screw opening | 2 turns out | ← | ← |
| Idle speed | 1,400 ± 100 rpm | ← | ← |
| Main jet | #122 | #112 | ← |
| Slow jet | #35 | ← | ← |
| Throttle lever free play | 3-8 mm (1/8-5/16 in) | ← | ← |
| Jet needle | 2nd groove | 3rd groove | ← |

TORQUE VALUES

Fuel valve lock nut Carburetor mounting nut 20-25 N·m (2.0-2.5 kg-m, 15-18 ft-lb) 6-9 N·m (0.6-0.9 kg-m, 4.3-6.5 ft-lb)

TOOL

Common

Float level gauge

 $07401\!-\!0010000$

TROUBLESHOOTING

Engine cranks but won't start

- No fuel in tank
- No fuel to carburetor
- · Too much fuel getting to cylinder
- · No spark at plug (ignition malfunction)
- · Air cleaner clogged

Engine idles roughly, stalls, or runs poorly

- · Idle speed incorrect
- · Ignition malfunction
- · Rich mixture
- Lean mixture
- Air cleaner dirty
- · Insulator leaks

Lean mixture

- Carburetor fuel jet clogged
- · Fuel cap vent blocked
- · Fuel filter clogged
- · Fuel line kinked or restricted
- · Float valve faulty
- · Float level too low

Rich mixture

- Carburetor choke stuck closed
- Float valve faulty
- · Float level too high
- · Carburetor air jet clogged
- · Air cleaner dirty

FUEL TANK

Slide the release lever to the left and remove the seat/rear fender.

Turn the fuel valve "OFF" and disconnect the fuel line at the fuel valve. Remove the fuel tank mounting bolts and the fuel tank.

WARNING

• Keep gasoline away from flames or sparks. Wipe up spilled gasoline at once.

Use a drain pan and check that fuel flows freely out of the fuel valve by turning the fuel valve "ON".

If flow is restricted, clean the fuel strainer screen and fuel strainer.

Check the vent hole in the filler cap for blockage.


Install the fuel tank in the reverse order of removal. Grease the seat latch and install the seat/rear fender. Tighten the fuel valve lock nut.


TORQUE: 20-25 N·m (2.0-2.5 kg-m, 15-18 ft-lb)

CAUTION

• Do not over-tighten the fuel valve lock nut.

Turn the fuel valve ''ON'' and make sure that there are no fuel leaks.







After '86:

Insert the breather tube into the hole of the handlebar cover and steering stem nut.

Push the tube in far enough so that the white mark on it is not visible above the surface of the handlebar cover.



After refilling the fuel tank, be sure to tighten the fuel filler cap firmly by turning it clockwise until the '' Δ '' mark on the cap faces forward.



AIR CLEANER CASE

Slide the release lever to the left and remove the seat/rear fender.

Loosen the connecting tube bands.


Remove the connecting tube (air cleaner case-to-carburetor). Loosen the inlet tube band.


Remove the air cleaner case mounting bolt and the case. For air cleaner element service, see page 3-5.

Install the air cleaner case in the reverse order of removal.

NOTE

• Be sure that the connecting and inlet tube bands are tightened securely.






THROTTLE VALVE

REMOVAL/DISASSEMBLY

Slide the release lever to the left and remove the seat/rear fender.

Remove the fuel tank (page 4-3).

Remove the carburetor top and pull out the throttle valve.




Disconnect the throttle cable from the throttle valve.

Pry out the retainer and remove the jet needle from the throttle valve.

CAUTION

• The carburetor top is an integral part of the throttle cable assembly. The carburetor top cannot be separated from the assembly without causing damage to the cable.



INSPECTION

Check the throttle valve and jet needle for wear or damage.

ASSEMBLY/INSTALLATION

Install the needle clip on the jet needle.

STANDARD SETTING:

'86:

PD64A A: 2nd groove PD64A B, C: 3rd groove

After '86: 3rd groove

Install the jet needle into the throttle valve and secure with the retainer.

Connect the throttle cable to the throttle valve.

Align the lug on carburetor body with the groove in the throttle valve.

Slide the throttle valve into the carburetor body and tighten the carburetor top.

Install the fuel tank.

Grease the seat latch and install the seat/rear fender.

Perform the following adjustments.

- Throttle lever free play (page 3-4).
- · Idle speed adjustment (page 3-10).

CARBURETOR REMOVAL

Slide the release lever to the left and remove the seat/rear fender.


Remove the fuel tank (page 4-3).


Loosen the drain screw and drain the carburetor.


Remove the carburetor top.

Loosen the connecting tube band.


Remove the carburetor mounting nuts and remove the carburetor.









CARBURETOR DISASSEMBLY



Remove the float chamber from the carburetor body.




Remove the float pin, float and float valve.



Inspect the float valve and valve seat for grooves, nicks or contamination.

Inspect the operation of the float valve.



Remove the baffle, main jet, needle jet holder and needle jet. Remove the slow jet and the throttle stop screw.

Turn the pilot screw in and record the number of turns before it seats lightly. Use this as a reference for reinstallation.


CAUTION


• Damage to the pilot screw seat will occur if the pilot screw is tightened against the seat.

Remove the pilot screw.

Inspect the pilot screw and each jet and replace them if they are worn or damaged.

Blow open all jets and body openings with compressed air.





CARBURETOR ASSEMBLY

Clean the main jet, needle jet holder, slow jet and pilot screw in cleaning solvent and blow them open with compressed air. Install the needle jet, needle jet holder and main jet. Install the slow jet.

Install the spring and throttle stop screw.

Install the O-ring (After '86: O-rings), spring seat, spring and pilot screw.


Turn the pilot screw to the original position as noted during removal.


NOTE

- · Use new-O-rings whenever the carburetor is reassembled.
- Handle all jets with care. They can easily be scored or scratched.

Install the baffle.

Install the float, float valve and float pin.





FLOAT LEVEL INSPECTION

Measure the float level with the float tang just touching the float valve.


FLOAT LEVEL: 14.0 ± 0.5 mm (0.55 ± 0.02 in)

Replace the float, if the level does not meet the specification.


TOOL:

Float level gauge


07401-0010000



Install the tube clamp and float chamber as shown.



Install the air vent tube and overflow tube as shown.




CARBURETOR INSTALLATION

Install the carburetor in the frame and tighten the carburetor mounting nuts.

TORQUE: 6-9 N·m (0.6-0.9 kg-m, 4.3-6.5 ft-lb)

Tighten the connecting tube band securely. Install the carburetor top (page 4-6). Install the fuel tank (page 4-3), and the seat/rear fender.

After installing the carburetor, make the following adjustments:



PILOT SCREW ADJUSTMENT

NOTE

The pilot screw is factory pre-set. Adjustment is not necessary unless the carburetor is overhauled or a new pilot screw is installed.

CAUTION

Damage to the pilot screw seat will occur if the pilot screw is tightened against the seat.

Turn the pilot screw clockwise until it seats lightly and back it out to the specification. This is an initial setting prior to the final pilot screw adjustment.


INITIAL OPENING: 2 turns out


Warm the engine up to operating temperature. Stop the engine and connect a tachometer.

Start the engine and adjust the idle speed with the throttle stop screw.

IDLE SPEED: 1.400 ± 100 rpm

Turn the pilot screw clockwise slowly until the engine stops, and then back it out 1 turn. Start the engine and readjust the idle speed with the throttle stop screw, if necessary.





HIGH ALTITUDE ADJUSTMENT

NOTE

The standard jetting can be used up to 6,500 ft (2,000 m) and the high altitude jetting can be used down to 5,000 ft (1,500 m). It is not recommended to exceed these limits.
 See CAUTION below.

The carburetor must be adjusted for high altitude riding (above $6,500 \, \text{ft/2,000 m}$).

STANDARD SETTING: 6,500 ft (2,000 m) max. HIGH ALTITUDE SETTING: 5,000 ft (1,500 m) min.

SPECIFICATIONS '86:


| | | Below 6,500 ft (2,000 m) | Above 5,000 ft (1,500 m) |
|---------------------|---------------------------|--------------------------------|------------------------------------|
| | PD64A 🖪 | #122 | #115 |
| Main jet | PD64A B , C | #112 | #108 |
| Pilot screw opening | | Factory pre-set | 1/4 turn in from original position |

After '86:

| | Below 6,500 ft (2,000 m) | Above 5,000 ft (1,500 m) |
|---------------------|--------------------------------|------------------------------------|
| Main jet | #112 | #108 |
| Pilot screw opening | Factory pre-set | 1/4 turn in from original position |

The high altitude carburetor adjustment is performed as follows:

Remove the carburetor (page 4-7), then remove drain plug. Replace the standard main jet with the high altitude type. Assemble and install the carburetor.




Adjust the pilot screw to the specifications.

Start the engine and adjust the idle speed at high altitude to ensure proper high altitude operation.

CAUTION

Sustained operation below 5,000 feet (1,500 m) with the high altitude settings may cause engine overheating and engine damage. Install the standard main jet and return the pilot screw to the factory pre-set position when riding below 5,000 feet (1,500 m).



E

5. ENGINE REMOVAL/INSTALLATION

| SERVICE INFORMATION | 5-1 | ENGINE INSTALLATION | 5-4 |
|---------------------|-----|---------------------|-----|
| ENGINE REMOVAL | 5-2 | | |

SERVICE INFORMATION

GENERAL

• A floor jack or other adjustable support is required to support and maneuver the engine.

• The following parts or components can be serviced with the engine installed in the frame.

Cylinder head Section 6
Cylinder/piston Section 7
Clutch/oil pump/kick starter/
gearshift linkage Section 8
Alternator Section 9

SPECIFICATIONS

Engine dry weight 29 kg (64 lb)
Engine oil capacity 1.8 liter (1.90 US qt, 1.59 lmp qt) at disassembly 1.5 liter (1.59 US qt, 1.32 lmp qt) after draining

TORQUE VALUES

| Top engine hanger plate bolt | 8 mm 10 mm | 24-30 N·m (2.4-3.0 kg-m, 17-22 ft-lb) 60-70 N·m (6.0-7.0 kg-m, 43-51 ft-lb) |
|--------------------------------|---------------|--|
| Front engine hanger plate bolt | | 30-36 N·m (3.0-3.6 kg-m, 22-26 ft-lb) |
| | 10 mm | 60-70 N·m (6.0-7.0 kg-m, 43-51 ft-lb) |
| Rear engine hanger plate bolt | 8 mm | 30-36 N·m (3.0-3.6 kg-m, 22-26 ft-lb) |
| | 10 mm | 60-70 N·m (6.0-7.0 kg-m, 43-51 ft-lb) |
| Engine lower mounting bolt | 10 mm | 60-70 N·m (6.0-7.0 kg-m, 43-51 ft-lb) |
| Drive sprocket bolt | | 10-14 N·m (1.0-1.4 kg-m, 7.2-10 ft-lb) |
| Gearshift pedal bolt | | 14-18 N·m (1.4-1.8 kg-m, 10-13 ft-lb) |
| Footpeg bolt | | 60-70 N·m (6.0-7.0 kg-m, 43-51 ft-lb) |
| Exhaust pipe joint nut | | 10-14 N·m (1.0-1.4 kg-m, 7.2-10 ft-lb) |
| Exhaust pipe clamp bolt | | 18-28 N·m (1.8-2.8 kg-m, 13-20 ft-lb) |
| Carburetor mounting nut | | 6-9 N·m (0.6-0.9 kg-m, 4.3-6.5 ft-lb) |
| Engine guard plate bolt | | 30-35 N·m (3.0-3.5 kg-m, 22-25 ft-lb) |


ENGINE REMOVAL

Slide the release lever to the left and remove the seat/rear fender.

Remove the fuel tank (page 4-3).


Drain the engine oil (page 2-2).

Remove the engine guard plate by removing the four bolts.




Remove the exhaust pipe joint nuts and loosen the exhaust clamp bolts.

Remove the exhaust pipe.




Disconnect the clutch cable from the clutch arm.



Loosen the drain screw and drain the carburetor. Remove the carburetor top.


Loosen the connecting tube band, remove the carburetor mounting nuts, then remove the carburetor.




Remove the spark plug cap from the spark plug.

Disconnect the crankcase breather tube from the breather cover.

Disconnect the alternator and pulse generator wire couplers and connector.




Remove the left footpeg bolts, the footpeg, the gearshift pedal and the drive sprocket cover.



Loosen the drive chain (page 3-10).


Remove the two drive sprocket bolts and the drive sprocket.

Remove the right footpeg and rear brake pedal (page 14-20).



Place a floor jack or other adjustable support under the engine. Remove the top, front and rear engine hanger plates and the lower engine mounting bolt.

Remove the engine from the right side.



NOTE

 See page 5-0 for the correct location of the hanger plates and mounting bolts.

ENGINE INSTALLATION

Install the engine in the frame and tighten the bolts.

TORQUE VALUES:

TOP ENGINE HANGER PLATE BOLT

8 mm bolt 24-30 N·m (2.4-3.0 kg-m, 17-22 ft-lb) 10 mm bolt 60-70 N·m (6.0-7.0 kg-m, 43-51 ft-lb)

FRONT ENGINE HANGER PLATE BOLT


8 mm bolt 30-36 N·m (3.0-3.6 kg-m, 22-26 ft-lb) 10 mm bolt 60-70 N·m (6.0-7.0 kg-m, 43-51 ft-lb)


REAR ENGINE HANGER PLATE BOLT

8 mm bolt 30-36 N·m (3.0-3.6 kg-m, 22-26 ft-lb) 10 mm bolt 60-70 N·m (6.0-7.0 kg-m, 43-51 ft-lb)

ENGINE LOWER MOUNTING BOLT

10 mm bolt 60-70 N·m (6.0-7.0 kg-m, 43-51 ft-lb)





Install the set plate and drive sprocket onto the countershaft and tighten the bolts.

TORQUE: 10-14 N·m (1.0-1.4 kg-m, 7.2-10 ft-lb)

Align the punch marks, install the gearshift pedal onto the gearshift spindle and tighten the bolt.

TORQUE: 14-18 N·m (1.4-1.8 kg-m, 10-13 ft-lb)

Install the left footpeg and tighten the bolts.

TORQUE: 60-70 N·m (6.0-7.0 kg-m, 43-51 ft-lb)

(1) BOLTS

(3) DRIVE SPROCKET

(2) SET PLATE

Install the rear brake pedal and right footpeg (page 14-20). Install the exhaust pipe (page 15-3).


Install the engine guard plate and tighten the bolts.

TORQUE: 30-35 N·m (3.0-3.5 kg-m, 22-25 ft-lb)


Install the removed parts in the reverse order of removal.

Route the cables and wires properly (page 1-10). Adjust the clutch lever (page 3-15), the throttle lever (page 3-4) and the drive chain (page 3-10).

Fill the engine with the recommended oil (page 2-2).



MEMO



6. CYLINDER HEAD/VALVES

| SERVICE INFORMATION TROUBLESHOOTING | 6-1 6-2 | VALVE SEAT INSPECTION AND REFACING | 6-9 |
|-------------------------------------|------------|------------------------------------|------|
| CYLINDER HEAD COVER REMOVAL | 6-3 | CYLINDER HEAD ASSEMBLY | 6-11 |
| CYLINDER HEAD COVER | 6-3 | CYLINDER HEAD INSTALLATION | 6-12 |
| DISASSEMBLY | | CAMSHAFT INSTALLATION | 6-13 |
| CAMSHAFT REMOVAL | 6-5 | CYLINDER HEAD COVER ASSEMBLY | 6-15 |
| CYLINDER HEAD REMOVAL | 6-5 | CYLINDER HEAD COVER INSTALLATION | 6-15 |
| CYLINDER HEAD DISASSEMBLY | 6-6 | INSTALLATION | |
| VALVE GUIDE REPLACEMENT | 6-8 | | |

SERVICE INFORMATION

REMOVAL

- This section covers maintenance of the cylinder head, valves, camshaft and rocker arms.
- The cylinder head can be serviced with the engine installed in the frame.
- Camshaft and rocker arm lubrication oil is fed through oil passages. Be sure the passages are not clogged.

SPECIFICATIONS

| ITEM | | | STANDARD mm (in) | SERVICE LIMIT mm (in) | |
|-----------------------------------|-----------------------|-----------|-----------------------------|--|-----------------|
| Compression | pressure | | | $1,300 \pm 100 \text{ kPa} (13.0 \pm 1.0 \text{ kg/cm}^2, 184 \pm 14 \text{ psi})$ | |
| Camshaft | Cam he | ight | IN | 34.683 (1.3655) | 34.503 (1.3584) |
| | | | EX | 34.557 (1.3605) | 34.377 (1.3534) |
| Rocker arm | Rocker | arm I.D. | | 12.000-12.018 (0.4724-0.4731) | 12.05 (0.474) |
| | Shaft O | .D. | | 11.966-11.984 (0.4711-0.4718) | 11.93 (0.470) |
| Valve | Valve Valve stem O.D. | | IN | 5.475-5.490 (0.2156-0.2161) | 5.45 (0.215) |
| | | EX | 5.455-5.470 (0.2148-0.2154) | 5.43 (0.214) | |
| Valve guide I.D. Stem-to-guide IN | | | 5.500-5.512 (0.2165-0.2170) | 5.52 (0.217) | |
| | | IN | 0.010-0.037 (0.0004-0.0015) | 0.12 (0.005) | |
| | clearan | ce | EX | 0.030-0.057 (0.0012-0.0022) | 0.14 (0.006) |
| | Valve | Inner | Yellow | 31.69 (1.248) | 29.5 (1.16) |
| | spring | | White | 32.50 (1.280) | 30.5 (1.20) |
| | free length | Outer | Yellow | 38.54 (1.517) | 36.5 (1.44) |
| | .55 | | White | 36.90 (1.453) | 35.0 (1.38) |
| | Valve s | eat width | 1 | 1.1 (0.043) | 1.4 (0.055) |
| Cylinder hea | d warpage | 9 | | | 0.10 (0.004) |

TORQUE VALUES

| Cylinder head 6 mm cap nut | 10-14 N·m (1.0-1.4 kg-m, 7-10 ft-lb) |
|------------------------------|--|
| 8 mm nut | 28-30 N·m (2.8-3.0 kg-m, 20-22 ft-lb) |
| Camshaft bearing holder bolt | 10-14 N·m (1.0-1.4 kg-m, 7.2-10 ft-lb) |
| Cylinder head cover bolt | 10-14 N·m (1.0-1.4 kg-m, 7.2-10 ft-lb) |
| Breather cover bolt | 10-14 N·m (1.0-1.4 kg-m, 7.2-10 ft-lb) |
| Top engine hanger plate bolt | 24-30 N·m (2.4-3.0 kg-m, 17-22 ft-lb) |

TOOLS

Special

Valve guide reamer, 5.5 mm 07984-2000000 or 07984-200000A (U.S.A. only)

Common

 Valve guide remover, 5.5 mm
 07742-0010100 or 07942-3290100

 Valve spring compressor
 07757-0010000 or 07957-3290001

 Inner driver
 07746-0020100 - Not available in U.S.A.

 Attachment, 15 mm
 07746-0020200 - Not available in U.S.A.

Valve seat cutters (Valve seat cutters are commercially available in the U.S.A.)

TROUBLESHOOTING

Engine top-end problems usually affect engine performance. These can be diagnosed by a compression test, or by tracing noises with a sounding rod or stethoscope.

Low compression

- Valves
 - Incorrect valve adjustment
 - Burned or bent valves
 - Incorrect valve timing
 - Broken valve spring
- Cylinder head
 - Leaking or damaged head gasket
 - Warped or cracked cylinder head
- · Cylinder and piston (section 7)
- · Decompressor out of adjustment

Compression too high

Excessive carbon build-up on piston or combustion chamber

Excessive noise

- · Incorrect valve adjustment
- Sticking valve or broken valve spring
- · Damaged or worn camshaft
- Loose or worn cam chain
- · Worn or damaged cam chain tensioner
- · Worn cam sprocket teeth
- · Worn rocker arm and/or shaft

CYLINDER HEAD COVER REMOVAL


Slide the release lever to the left and remove the seat/rear fender.

Remove the fuel tank (page 4-3).

Disconnect the crankcase breather hose from the breather cover.

Remove the bolts and breather cover.


Remove the O-rings from the oil orifice bosses on the cylinder head cover.




Remove the spark plug cap.

Disconnect the decompressor cable from the decompressor arm.

Remove the valve adjuster cover.




Loosen the valve adjuster lock bolts. Remove the bolts and the cylinder head cover. Remove the dowel pins.




CYLINDER HEAD COVER DISASSEMBLY

Remove the rubber gasket from the cylinder head cover. Remove the valve adjuster lock bolts, the rocker arm shafts and rocker arms from the head cover.




CYLINDER HEAD/VALVES

Remove the circlip and decompressor cam from the decompressor shaft.



Remove the decompressor arm/shaft and return spring from the cylinder head cover.



INSPECTION


Inspect the rocker arms for wear or damage to the camshaft contact surface or for a clogged oil hole.

Measure the I.D. of each rocker arm.

SERVICE LIMIT: 12.05 mm (0.474 in)


Inspect the shaft for wear or damage. Measure each rocker arm shaft O.D.

SERVICE LIMIT: 11.93 mm (0.470 in)



CAMSHAFT REMOVAL

Remove the two cam chain tensioner mounting bolts and the tensioner.




Remove the two camshaft bearing holder bolts and the bearing holder.

Remove the camshaft.

Suspend the cam chain with a piece of wire to keep it from falling into the crankcase.

NOTE

· Be careful not to drop the bolts into the crankcase.




INSPECTION

Check each cam lobe for wear or damage. Measure the cam lobe height.

SERVICE LIMITS:

INTAKE: 34.503 mm (1.3584 in) EXHAUST: 34.377 mm (1.3534 in)



Turn the left and right camshaft bearings by hand and check for noise, damage or excessive play.

For left camshaft bearing replacement, remove the snap ring and timing indicator plate, then remove the bearing using a bearing puller.

Drive a new left camshaft bearing onto the camshaft.

TOOLS:

Inner driver 07746-0020100 Attachment, 15 mm 07746-0020200


Install the timing indicator plate onto the camshaft aligning the tab with the groove on the camshaft.


Install the snap ring in the groove in the camshaft securely. If the right bearing is lousy, replace the camshaft.

CYLINDER HEAD REMOVAL

Remove the following:


- carburetor (page 4-6)
- exhaust pipe (page 15-2)
- spark plug cap
- top engine hanger plates






Remove the two cylinder head cap nuts, four cylinder head nuts and washers.

Remove the cylinder head.




Remove the cylinder head gasket and two dowel pins.



CYLINDER HEAD DISASSEMBLY

Remove the intake pipe and the spark plug from the cylinder head.



Remove the valve spring cotters, retainers, springs, spring seats and valves with a valve spring compressor.

TOOL:

Valve spring compressor

07757-0010000 or 07957-3290001

CAUTION


• To prevent loss of tension, do not compress the valve springs more than necessary to remove the cotters.

NOTE

Mark all disassembled parts to ensure correct reassembly.

Remove the valve stem seals.


Remove carbon deposits from the combustion chamber.



INSPECTION

Check the spark plug hole and valve areas for cracks. Check the cylinder head for warpage with a straight edge and feeler gauge.

SERVICE LIMIT: 0.10 mm (0.004 in)



Measure the free length of the inner and outer valve springs.

SERVICE LIMITS:

INNER (IN, EX): Yellow: 29.5 mm (1.16 in)


White: 30.5 mm (1.20 in)

OUTER (IN, EX): Yellow: 36.5 mm (1.44 in)

White: 35.0 mm (1.38 in)

NOTE

 The valve springs are marked with either white or yellow paint. When replacing the valve spring, use the one with same paint mark.




Inspect each valve for bending, burning, scratches or abnormal stem wear.

Check valve movement in the guide and measure and record each valve stem O.D.

SERVICE LIMITS:

IN: 5.45 mm (0.215 in) EX: 5.43 mm (0.214 in)




NOTE

- Ream the guides to remove any carbon build-up before checking clearances.
- Always rotate the reamer clockwise, never counterclockwise.

TOOL:

Valve guide reamer

07984-2000000 or 07984-200000A (U.S.A. only)



Measure and record each valve guide I.D.

SERVICE LIMIT: 5.52 mm (0.217 in)

Subtract each valve stem O.D. from the corresponding guide I.D. to obtain the stem-to-guide clearance.

SERVICE LIMITS: IN: 0.12 mm (0.005 in)

EX: 0.14 mm (0.006 in)

If the stem-to-guide clearance exceeds the service limits, determine if a new guide with standard dimensions would bring the clearance within tolerance. If so, replace any guides as necessary and ream to fit.

If the stem-to-guide clearance exceeds the service limits with new guides also, replace the valves.

NOTE

 Reface the valve seats whenever the valve guides are replaced.



Heat the cylinder head to $100^{\circ}-150^{\circ}$ C ($212^{\circ}-300^{\circ}$ F) with a hot plate or oven.

WWARNING

 To avoid burns, wear heavy gloves when handling the heated cylinder head.

CAUTION

 Do not use a torch to heat the cylinder head; it may cause warping.

Support the cylinder head and drive out the old guides from the combustion chamber side of the cylinder head.

TOOL:

Valve guide remover

07742-0010100 or 07942-3290100

CAUTION

Avoid damaging the cylinder head.


Place a new O-ring on the new valve guide. Drive in the guide from the top of the head.


TOOL:


Valve guide remover

07742-0010100 or 07942-3290100

Inspect the valve guide for damage.







Ream the new valve guide after installation.

TOOL:

Valve guide reamer

07984-2000000 or 07984-200000A (U.S.A. only)

NOTE

- · Use cutting oil on the reamer during this operation.
- Always rotate the reamer clockwise, never counterclockwise.

Clean the cylinder head thoroughly to remove any metal particles.

Reface the valve seat.

VALVE SEAT INSPECTION/REFACING

Clean the intake and exhaust valves thoroughly to remove carbon deposits.

Apply a light coating of Prussian Blue to the valve seats. Lap the valves and seats using a rubber hose or other hand-lapping tool.

Remove and inspect the valves.


CAUTION


• The valves cannot be ground. If a valve face is burned or badly worn or if it contacts the seat unevenly, replace the valve.


Inspect the width of each valve seat.

STANDARD: 1.1 mm (0.043 in) SERVICE LIMIT: 1.4 mm (0.055 in)

If the seat is too wide, too narrow or has low spots, the seat must be ground.








VALVE SEAT CUTTERS

Honda Valve Seat Cutters, a grinder or equivalent valve seat refacing equipment are recommended to correct a worn valve seat.

NOTE

Follow the refacer manufacturer's operating instructions.




CYLINDER HEAD/VALVES

VALVE SEAT REFACING


Use a 45 degree cutter to remove any roughness or irregularities from the seat.

NOTE


• Reface the seat with a 45 degree cutter when a valve guide is replaced.




Use a 32 degree cutter to remove the top 1/4 of the existing valve seat material.



Use a 60 degree cutter to remove the bottom 1/4 of the old seat. Remove the cutter and inspect the area you have refaced.



Install a 45 degree finish cutter and cut the seat to the proper width. Make sure that all pitting and irregularities are removed. Refinish if necessary.




Apply a thin coating of Prussian Blue to the valve seat. Press the valve through the valve guide and onto the seat to make a clear pattern.


NOTE

 The location of the valve seat in relation to the valve face is very important for good sealing.

If the contact area is too high on the valve, the seat must be lowered using a 32 degree flat cutter.



If the contact area is too low on the valve, the seat must be raised using a 60 degree inner cutter.




Refinish the seat to specifications, using a 45 degree finish cutter.

After cutting the seat, apply lapping compound to the valve face, and lap the valve using light pressure.

After lapping, wash all residual compound off the cylinder head and valve.

NOTE

Do not allow lapping compound to enter the guides.




CYLINDER HEAD ASSEMBLY

Install the valve spring seat and a new stem seal.

Lubricate the valve stems with molybdenum disulfide grease and insert the valve into the valve guide.

To avoid damage to the stem seal, turn the valve slowly when inserting.

Install the valve springs with the tightly wound coils facing the cylinder head.



CYLINDER HEAD/VALVES

Install the valve spring retainers and compress the valve springs using the valve spring compressor, then install the valve cotters.


TOOL:

Valve spring compressor

07757-0010000 or 07957-3290001

CAUTION


• To prevent loss of tension, do not compress the valve spring more than necessary.



Tap the valve stems gently with a plastic hammer to firmly seat the cotters.


CAUTION

• Support the cylinder head above the work bench surface to prevent possible valve damage.




Install a new O-ring in the intake pipe groove and install the intake pipe with two bolts.

Install the spark plug.



CYLINDER HEAD INSTALLATION

Make sure that the cam chain guide is positioned properly. Install the dowel pins and a new cylinder head gasket.




Install the cylinder head.

Install the two 6 mm cap nuts, four washers and 8 mm nuts, and tighten them in the sequence shown in 2 or 3 steps.

TORQUE VALUES:


6 mm cap nut: 10-14 N·m (1.0-1.4 kg-m, 7-10 ft-lb) 8 mm nut: 28-30 N·m (2.8-3.0 kg-m, 20-22 ft-lb)



Install the top engine hanger plates and bolts. Tighten the bolts

TORQUE: 24-30 N·m (2.4-3.0 kg-m, 17-22 ft-lb)

Install the spark plug cap. Install the exhaust pipe (page 15-3). Install the carburetor (page 4-10).




CAMSHAFT INSTALLATION

Remove the timing hole cap.

Turn the crankshaft and align the "T" mark on the flywheel with the index mark on the left crankcase cover.


CAUTION

 When turning the crankshaft, make sure the cam chain does not jam at the cam chain tensioner or crankshaft.



Apply a thin coating of molybdenum disulfide grease to the cam lobes.

Lubricate the camshaft bearings with clean engine oil. Place the camshaft in the cylinder head. Align the index lines on the cam sprocket with the top of the cylinder head and install the cam chain over the sprocket.




Install the camshaft bearing holder and tighten the holder.


TORQUE: 10-14 N·m (1.0-1.4 kg-m, 7.2-10 ft-lb)

NOTE

· Be careful not to drop the bolts into the crankcase.



Turn the crankshaft 360° and align the "T" mark on the flywheel with the index mark on the left crankcase cover. Make sure that the index lines on the cam sprocket align with the top of the cylinder head.




Remove the sealing bolt and washer from the cam chain tensioner.


Check the cam chain tensioner for smooth operation. Turn the tensioner shaft clockwise with a small screwdriver to

NOTE

The tensioner shaft will be projected by spring force when it is released.




Wedge the tensioner shaft with a piece of wire as shown to hold it in place.




Install the cam chain tensioner and tighten the mounting bolts securely.

Remove the holder piece to release the shaft.




Install the sealing washer and bolt, and tighten the bolt securely.



CYLINDER HEAD COVER ASSEMBLY

Install the return spring onto the decompressor arm/shaft and install the shaft into the cylinder head cover.


Install the decompressor cam on the shaft and secure it with the circlip.



Apply a thin coating of molybdenum disulfide grease to the rocker arm's contact surface on the camshaft.

Install new O-rings on the rocker arm shafts and coat the rocker arm shafts with engine oil.


Install the rocker arms and shafts into the cylinder head cover. Install the valve adjuster lock bolts loosely.




CYLINDER HEAD COVER INSTALLATION

Fill the oil pocket in the cylinder head with clean engine oil to provide initial lubrication for the camshaft when the engine is started.

Install the dowel pins.




Install a new rubber gasket in the cylinder head cover groove.



Install the cylinder head cover and tighten the bolts.


TORQUE: 10-14 N·m (1.0-1.4 kg-m, 7.2-10 ft-lb)

Install new O-rings into the oil orifice bosses of the cylinder head cover.



Blow compressed air through the oil passage in the breather cover.

Install a new rubber gasket in the breather cover groove.



Install the breather cover and valve adjuster cover, and tighten the bolts.

TORQUE: 10-14 N·m (1.0-1.4 kg-m, 7.2-10 ft-lb)

Connect the crankcase breather hose to the cover.


Connect the decompressor cable to the decompressor arm.


Adjust the valve clearance (page 3-8).

Adjust the decompressor cable (page 3-9).

Install the fuel tank (page 4-3).

Grease the seat latch and install the seat/rear fender.





Ę

7. CYLINDER/PISTON

| SERVICE INFORMATION | 7-1 | PISTON | 7-3 |
|---------------------|-----|------------------------------|-----|
| TROUBLESHOOTING | 7-1 | PISTON/CYLINDER INSTALLATION | 7-5 |
| CYLINDER | 7-2 | | |

SERVICE INFORMATION

SPECIFICATIONS

| ITEM | | STANDARD mm (in) | SERVICE LIMIT mm (in) | | |
|--|--------------------------------------|-------------------------------|-------------------------------|-------------------------------|---------------|
| Cylinder | I.D. | | | 65.000-65.010 (2.5590-2.5594) | 65.10 (2.563) |
| Taper | | | | | 0.10 (0.004) |
| Out-of-round Warpage acros | | | | 0.10 (0.004) | |
| | Warpage acros | top | | | 0.10 (0.004) |
| Piston, Piston O.D. | | | | 64.962-64.982 (2.5576-2.5583) | 64.90 (2.555) |
| piston pin, piston rings Piston pin bore Piston pin O.D. Piston-to-pin clea | | | 15.002-15.008 (0.5906-0.5909) | 15.04 (0.592) | |
| | Piston pin O.D. | | | 14.994-15.000 (0.5903-0.5906) | 14.96 (0.589) |
| | Piston-to-pin cl | Piston-to-pin clearance | | 0.002-0.014 (0.0001-0.0006) | 0.02 (0.001) |
| | Piston ring-to-r | ng | ТОР | 0.005-0.045 (0.0002-0.0018) | 0.09 (0.004) |
| | groove clearance Piston ring end gap | ce | SECOND | 0.015-0.045 (0.0006-0.0018) | 0.09 (0.004) |
| | | ТО | P/SECOND | 0.20-0.40 (0.008-0.016) | 0.50 (0.020) |
| | | OIL | - | 0.20-0.80 (0.008-0.031) | |
| Cylinder-to-piston clearance | | 0.018-0.048 (0.0007-0.0019) | 0.10 (0.004) | | |
| Connecting rod small end I.D. | | 15.010-15.028 (0.5909-0.5917) | 15.06 (0.593) | | |
| Connecting rod-to-piston pin clearance | | 0.010-0.034 (0.0004-0.0013) | 0.05 (0.002) | | |

TROUBLESHOOTING

Low or unstable compression

- Worn cylinder or piston rings
- · Cylinder head and valves (section 6)

Excessive smoke

- · Worn cylinder, piston, or piston rings
- Improper installation of piston rings
- · Scored or scratched piston or cylinder wall

Overheating

Excessive carbon build-up on piston or combustion chamber wall

Knocking or abnormal noise


- · Worn piston and cylinder
- Excessive carbon build-up

CYLINDER

RFMOVAL

Remove the cylinder head (section 6).

Remove the cam chain guide and the cylinder.



Remove the cylinder gasket and dowel pins.

Clean off any gasket material from the cylinder surface.

NOTE

Be careful not to damage the gasket surface.

INSPECTION

Inspec the cylinder walls for scratches and wear.

Measure and record the cylinder I.D. at three levels in both an X and Y axis for a total of six measurements. Take the maximum reading to determine the cylinder wear.

SERVICE LIMIT: 65.10 mm (2.563 in)

Calculate the piston-to-cylinder clearance by taking the maximum reading and subtracting the piston O.D.

Refer to page 7-4 for measurement of the piston O.D.

SERVICE LIMIT: 0.10 mm (0.004 in)

Calculate the cylinder taper by taking the readings at the three levels and subtracting the minimum from the maximum reading.

SERVICE LIMIT: 0.10 mm (0.004 in)

Calculate the cylinder out-of-round by checking for a difference between the X and Y readings at each of the three levels. If there is any difference, use the maximum reading to determine the out-of-round.


SERVICE LIMIT: 0.10 mm (0.004 in)


The cylinder must be rebored and oversize piston fitted if the service limits are exceeded.


The following oversize pistons are available:

0.25 mm (0.010 in), 0.50 mm (0.020 in) and 0.75 mm (0.030 in), 1.00 mm (0.039 in)

The cylinder must be rebored so that the clearance to an oversize piston is 0.018-0.048 mm (0.0007-0.0019 in).








Inspect the top of the cylinder for warpage.

SERVICE LIMIT: 0.10 mm (0.004 in)



PISTON


REMOVAL

Remove the piston pin clips with pliers.

NOTE

· Do not let the clips fall into the crankcase.

Press the piston pin out of the piston and remove the piston.




Remove the piston rings.

NOTE

• Do not damage the piston rings during removal.

Inspect the piston for damage and the ring grooves for wear.




INSPECTION

Measure the piston ring-to-groove clearance.

SERVICE LIMITS:

Top/Second: 0.09 mm (0.004 in)

Inspect the piston for wear or damage.



CYLINDER/PISTON


Insert each piston ring squarely into the cylinder and measure the ring end gap.

NOTE

 Push the rings into the cylinder with the top of the piston to be sure they are squarely in the cylinder.

SERVICE LIMIT:

Top/Second: 0.50 mm (0.020 in)



Measure the O.D. of the piston 10 mm from the bottom and 90° to the piston pin hole.

SERVICE LIMIT: 64.90 mm (2.555 in)


Compare this measurement against the service limit and calculate piston-to-cylinder clearance.

Refer to page 7-2 for measuring the cylinder.



Measure the piston pin hole I.D.

SERVICE LIMIT: 15.04 mm (0.592 in)




Measure the O.D. of the piston pin.

SERVICE LIMIT: 14.96 mm (0.589 in)

Calculate the piston-to-piston pin clearance.

SERVICE LIMIT: 0.02 mm (0.001 in)




Measure the connecting rod small end I.D.

SERVICE LIMIT: 15.06 mm (0.593 in)

Calculate the connecting rod-to-piston pin clearance.

SERVICE LIMIT: 0.05 mm (0.002 in)



PISTON/CYLINDER INSTALLATION

PISTON RING INSTALLATION

Clean the piston ring grooves thoroughly and install the piston rings.

NOTE

- · Avoid piston and piston ring damage during installation.
- · Install the piston rings with the markings facing up.
- · Do not mix the top and second rings.

Space the piston ring end gaps 120 degrees apart. Do not align the gaps in the oil rings (side rails).


After installation, the rings should be free to rotate in the grooves. (3) TOP RING (4) SECOND RING _ (1) TOP RING (2) SECOND RING (5) State Branch SIDE RAIL (8) OIL RING 9) 20 mm (3/4 in) \$ **SPACER** OR MORE (GOOD WE SIDE RAIL (9) 20 mm (3/4 in) (10) SPACER END OR MORE

PISTON INSTALLATION

Position the piston "IN" mark on the intake valve side, and install the piston and piston pin.
Install new piston pin clips.

NOTE

- Do not align the piston pin clip end gap with the piston cutout
- · Do not let the clips fall into the crankcase.




CYLINDER INSTALLATION


Clean off any gasket material from the crankcase surface.

NOTE

· Be careful not to damage the gasket surface.




Install the dowel pins and a new gasket.



Stagger the piston ring end gaps 120° a part. Coat the cylinder bore and piston rings with engine oil and install the cylinder.


NOTE


- · Avoid piston ring damage during installation.
- Do not let the cam chain fall into the crankcase.



Install the cam chain guide.

Install the cylinder head (page 6-12).





| SERVICE INFORMATION | 8-1 | CLUTCH | 8-9 |
|-----------------------|-----|-------------------|------|
| TROUBLESHOOTING | 8-2 | KICK STARTER | 8-15 |
| RIGHT CRANKCASE COVER | 8-3 | GEARSHIFT LINKAGE | 8-19 |
| OIL PUMP | 8-6 | | |

SERVICE INFORMATION

GENERAL

• This section covers removal and installation of the right crankcase cover, clutch, oil pump, kick starter and gearshift linkage. These services can be performed with the engine in the frame.

SPECIFICATIONS

| ITEM | | STANDARD mm (in) | SERVICE LIMIT mm (in) | |
|--|-------------------------|-------------------------------|-------------------------------|-----------------|
| Clutch Spring free length Disc thickness Plate warpage | Spring free length | ′86 | 37.2 (1.45) | 35.0 (1.38) |
| | | After '86 | 32.7 (1.29) | 31.0 (1.22) |
| | Disc thickness | | 2.93-3.08 (0.115-0.121) | 2.60 (0.102) |
| | | | 0.20 (0.008) | |
| Clutch outer I.D. | | | 25.000-25.021 (0.9842-0.9851) | 25.070 (0.9870) |
| Clutch outer guide | Clutch outer guide | I.D. | 20.000-20.020 (0.7874-0.7882) | 20.070 (0.7902) |
| | O.D. | 24.959-24.980 (0.9826-0.9835) | 24.900 (0.9803) | |
| | | Length | 30.05-30.15 (1.183-1.187) | 30.00 (1.181) |
| Rotor tip clearance | Pump end clearance | | | 0.20 (0.008) |
| | Rotor tip clearance | | | 0.40 (0.02) |
| | Rotor-to-body clearand | ce | | 0.25 (0.010) |
| (After '86) Kick stater pi gear collar | Kick starter spindle | O.D. | 21.995-22.018 (0.8660-0.8668) | 21.95 (0.864) |
| | Kick stater pinion | O.D. | 27.934-27.955 (1.1000-1.1006) | 27.89 (1.098) |
| | gear collar | I.D. | 22.035-22.065 (0.8675-0.8687) | 22.10 (0.870) |
| | Kick stater pinion gear | I.D. | 27.976-27.989 (1.1014-1.1019) | 28.03 (1.104) |

TORQUE VALUES

| Kick starter arm pinch bolt | 30-35 N·m (3.0-3.5 kg-m, 22-25 ft-lb) |
|-----------------------------|--|
| Clutch center lock nut | 50-60 N·m (5.0-6.0 kg-m, 36-43 ft-lb) |
| Oil filter rotor lock nut | 50-60 N·m (5.0-6.0 kg-m, 36-43 ft-lb): Left hand threads |
| Drum stopper bolt | 10—14 N•m (1.0—1.4 kg-m, 7.2—10 ft-lb) |
| Shifter plate bolt | 10—14 N·m (1.0—1.4 kg-m, 7.2—10 ft-lb) |
| Gearshift pedal bolt | 14-18 N·m (1.4-1.8 kg-m, 10-13 ft-lb) |
| | |

TOOLS

Special

Clutch center holder 07923-9580000

Common

Pin driver, 3 mm 07744-0010200 or equivalent commercially available in U.S.A.

Gear holder 07724-0010100 Not available in U.S.A.

TROUBLESHOOTING

Faulty clutch operation can usually be corrected by adjusting the clutch.

Clutch slips when accelerating

- · Faulty clutch lifter
- Discs worn
- · Weak spring

Clutch will not disengage

- · Faulty clutch lifter
- · Plates warped

ATC creeps with clutch disengaged

· Plates warped

Clutch operation feels rough

· Outer drum slots rough

Hard to shift

- · Incorrect clutch adjustment
- · Faulty clutch lifter

Low oil pressure

- · Faulty oil pump
- · Oil pump drive gear broken

Hard shifting

- · Damaged gearshift plate or drum shifter
- Shift spindle bent
- Faulty stopper

Kick starter slips

- · Worn or damaged starter ratchet and/or pinion gear
- Kick starter ratchet out of ratchet guide

Kick starter pedal does not return

- · Weak or damaged kick return spring
- Return spring hook out of place

Gearshift pedal does not return

- · Bent gearshift spindle
- Broken shift spindle return spring

RIGHT CRANKCASE COVER


REMOVAL

Drain the engine oil (page 2-2).

Remove the right footpeg and brake pedal (page 14-20). Disconnect the decompressor cable from the cam follower shaft arm.

Disconnect the clutch cable from the clutch lifter arm.

Remove the kick starter pinch bolt and the arm.




Remove the right crankcase cover bolts and the cover.

NOTE


Loosen the bolts in a criss-cross pattern in 2 or 3 progressive steps.

Remove the gasket and dowel pins.



CLUTCH LIFTER REMOVAL

Remove the clutch lifter piece.




Drive in the spring pin until it is flush with the lifter shaft surface and remove the lifter arm shaft and return spring.

TOOL:

Pin driver, 3 mm


07744-0010200 or equivalent commercially available in U.S.A.



Drive out the spring pin from the lifter arm shaft and discard it. **TOOL**:


Pin driver, 3 mm

07744-0010200 or equivalent commercially available in U.S.A.




DECOMPRESSOR CAM FOLLOWER SHAFT DISASSEMBLY

Remove the snap ring, cam follower, spring and cam follower shaft.




RIGHT CRANKASE COVER INSPECTION

Check the oil seals for wear or damage and replace if necessary.



Check the kick starter spindle and cam follower shaft bearings for wear or damage.




DECOMPRESSOR CAM FOLLOWER SHAFT ASSEMBLY

Hook the spring to the cam follower.

Install the cam follower by aligning the flats on the shaft and cam follower.

Hook the spring end to the right crankcase cover as shown. Install the snap ring in the groove in the shaft securely.



CLUTCH LIFTER INSTALLATION


Install the spring and lifter arm shaft.

Drive a new spring pin into the arm shaft hole.

TOOL:


Pin driver, 3 mm

07744-0010200 or equivalent commercially available in U.S.A.




Hook the end of the spring to the spring pin.

Align the cut-out in the lifter arm shaft with the lifter piece hole in the cover and install the lifter piece into the hole.




INSTALLATION

Install the dowel pins and a new gasket.



Turn the cam follower shaft arm clockwise to align the cam follower with the cam and install the right crankcase cover.

Tighten the cover bolts in a crisscross pattern in 2 or 3 steps.



Connect the clutch cable to the clutch lifter arm.


Connect the decompressor cable to the cam follower shaft arm

Align the punch marks and install the kick starter arm onto the kick starter spindle.

Tighten the kick starter pinch bolt.

TORQUE: 30-35 N·m (3.0-3.5 kg-m, 22-25 ft-lb)

Install the rear brake pedal and right footpeg (page 14-20). Fill the crankcase with the recommended oil (page 2-2). Adjust the clutch cable (page 3-15) and the decompressor cable (page 3-9).




OIL PUMP

REMOVAL


Drain the engine oil (page 2-2).

Remove the right crankcase cover (page 8-3).


Remove the oil pump driven sprocket cover.



Remove the snap ring and the oil pump driven sprocket from the shaft.





Remove the oil pump mount bolts and the pump.



DISASSEMBLY

Remove the screw and oil pump cover.






INSPECTION

Install the outer and inner rotors into the oil pump body and insert the oil pump driven gear shaft.


Measure the pump rotor tip clearance.

SERVICE LIMIT: 0.20 mm (0.008 in)



Measure the pump body-to-rotor clearance.


SERVICE LIMIT: 0.40 mm (0.02 in)



Remove the oil pump shaft.

Measure the pump end clearance.


SERVICE LIMIT: 0.25 mm (0.010 in)



ASSEMBLY


Install the outer and inner rotors into the pump body. Align the flats on the oil pump shaft and inner rotor, and install the shaft into the rotor.

Install the oil pump cover and tighten the screw securely. Check the oil pump for smooth operation.




INSTALLATION


Align the dowel pins on the oil pump with the dowel pin holes on the crankcase and install the oil pump onto the crankcase.




Install the oil pump mount bolts and tighten them.



Install the drive chain on the driven sprocket.
Install the driven sprocket by aligning the flats on the shaft with the sprocket.
Install the snap ring in the oil pump shaft groove.



Install the oil pump driven sprocket cover.
Install the right crankcase cover (page 8-5).
Fill the engine with the recommended oil (page 2-2).



CLUTCH


REMOVAL

Drain the engine oil (page 2-2).


Remove the right crankcase cover (page 8-3).

Remove the screws, oil filter rotor cover and the lifter bearing.

Check the lifter bearing for excessive play, wear or damage.



Unstake the oil filter rotor lock nut with a drill or grinder. Be careful not to damage the crankshaft threads.



Hold the primary drive gear with the gear holder as shown.

TOOL:

Gear holder

07724-0010100 (Not available in U.S.A.)


Remove the oil filter rotor lock nut.


NOTE

The rotor lock nut has left-hand threads.

Remove the gear holder.

Remove the washer and oil filter rotor from the crankshaft.





Hold the primary drive gear with the gear holder as shown.

TOOL:

Gear holder

07724-0010100 (Not available in U.S.A.)


Remove the bolts, lifter plate and clutch springs.

NOTE


· Loosen the bolts in a crisscross pattern in 2 or 3 steps.

Remove the gear holder.

Turn the clutch outer so the cut-out faces the crankshaft, then remove the primary drive gear.



Unstake the clutch lock nut with a drill or grinder. Be careful not to damage the shaft threads.




Hold the clutch center with the clutch center holder and remove the clutch lock nut.


TOOL:

Clutch center holder

07923-9580000



Remove the washer, clutch center, plates, discs and pressure plate.



Remove the thrust washer and clutch outer.

Remove the clutch outer guide from the mainshaft.



INSPECTION

Check the slots of the clutch outer for damage or wear made by the clutch discs. Replace the outer if necessary.

Measure the I.D. of the clutch outer.


SERVICE LIMIT: 25.070 mm (0.9870 in)


Measure the O.D., I.D. and length of the clutch outer guide.

SERVICE LIMIT: I.D. 20.070 mm (0.7902 in) O.D. 24.900 mm (0.9803 in) length 30.000 mm(1.181 in)

Measure the clutch spring free length.

SERVICE LIMIT: '86: 35.0 mm (1.38 in) After '86: 31.0 mm (1.22 in)






Replace the clutch discs if they show signs of scoring or discoloration.


Measure the disc thickness.

SERVICE LIMIT: 2.60 mm (0.102 in)




Check for plate warpage on a surface plate using a feeler gauge.

SERVICE LIMIT: 0.20 mm (0.008 in)




INSTALLATION

Install the clutch outer guide.




Install the clutch outer and washer.




Install the pressure plate, discs, plates and clutch center.

NOTE

- Stack the discs and plates alternately.
- · Coat new discs with clean engine oil.



Install the washer.



Hold the clutch center with the clutch center holder.

TOOL:


Clutch center holder

07923-9580000


Install a new lock nut and tighten it.

TORQUE: 50-60 N·m (5.0-6.0 kg-m, 36-43 ft-lb)

Remove the clutch center holder.



Stake the end of the lock nut into the groove in the mainshaft with a punch. Be careful not to damage the shaft threads.



Turn the clutch outer so the cut-out faces the crankshaft, then install the primary drive gear.

Hold the primary drive gear with the gear holder as shown.


TOOL:

Gear holder


07724-0010100 (Not available in U.S.A.)

Install the spring, lifter plate and bolts.

Tighten the bolts in a crisscross pattern in 2 or 3 steps.



Install the oil filter rotor and washer onto the crankshaft.



Hold the primary drive gear with the gear holder as shown.

TOOL:

Gear holder

07724-0010100 (Not available in U.S.A.)

Install a new lock nut and tighten it.


TORQUE: 50-60 N·m (5.0-6.0 kg-m, 36-43 ft-lb)


NOTE

· The oil filter rotor lock nut has left-hand threads.


Remove the gear holder.

Stake the end of lock nut into the groove of the crankshaft with a punch. Be careful not to damage the shaft threads.





Install a new bearing into the clutch lifter plate. Install the oil filter rotor cover using the three screws. Install the right crankcase cover (page 8-5). Fill the engine with the recommended oil (page 2-2).




KICK STARTER

REMOVAL


Drain the engine oil (page 2-2). Remove the right crankcase cover (page 8-3). Remove the clutch (page 8-9).

Temporarily install the kick starter arm on the kick starter shaft and remove the shaft assembly by turning the arm clockwise to free the ratchet from the ratchet guide.




DISASSEMBLY

Remove the washer, decompressor cam, spring, spring seat and snap ring from the kick starter shaft.




Remove the collar, return spring, spring seat, spring and ratchet.

Remove the snap ring, thrust washers and starter pinion gear from the kick starter shaft.



INSPECTION


Check the kick starter shaft bearing in the right crankcase for wear or damage.



'86:

Check the starter pinion gear ratchet surface for wear or damage.


Check the starter pinion needle bearing for excessive play, wear or damage.



After '86:

Measure the kick stater spindle O.D.

SERVICE LIMIT: 21.95 mm (0.864 in)



Check the starter pinion gear ratchet surface for wear or damage.


Measure the pinion gear I.D.

SERVICE LIMIT: 28.03 mm (1.104 in)

Measure the pinion gear bushing O.D. and I.D.

SERVICE LIMIT:


O.D.: 27.89 mm (1.098 in) I.D. : 22.10 mm (0.870 in)




ASSEMBLY

Install the snap ring in the groove in the shaft.

Install the thrust washer, pinion gear, thrust washer and snap ring onto the shaft.




Install the ratchet over the shaft aligning its wide groove with the punch mark on the shaft.




Install the spring and spring seat.

Install the return spring and insert its end into the hole in the shaft.

Install the collar, aligning its groove with the end of the return spring.




Install the snap ring in the groove in the shaft. Install the spring seat and spring onto the shaft.




Install the decompressor cam over the shaft aligning its wide groove with the punch mark on the shaft.

Install the thrust washer.




INSTALLATION

Temporarily install the kick starter arm onto the staft. Hook the return spring in the crankcase.




Install the kick starter shaft assembly by turning it clockwise and aligning its ratchet with the ratchet guide.

Remove the kick starter arm.



Make sure that the punch mark on the shaft faces up.


Install the clutch (page 8-13). Install the right crankcase cover (page 8-5). Fill the engine with the recommended oil (page 2-2).




GEARSHIFT LINKAGE

REMOVAL


Drain the engine oil (page 2-2). Remove the right crankcase cover (page 8-3). Remove the clutch (page 8-9). Remove the bolt and the gearshift pedal.




Unhook the spring and remove the gearshift spindle and washer.



Remove the gearshift guide plate and gearshift plate.




Remove the drum stopper, drum shifter and dowel pin.




INSPECTION

Check the gearshift spindle for bent, damage or wear.




INSTALLATION

Install the dowel pin into the drum shifter. Install the drum shifter aligning the dowel pin with the hole on the shift drum.




Install the drum stopper, spring and bolt. Tighten the bolt.

TORQUE: 10-14 N·m (1.0-1.4 kg-m, 7.2-10 ft-lb)




Install the gearshift plate, gearshift guide plate and bolt. Tignten the bolt.


TORQUE: 10-14 N·m (1.0-1.4 kg-m, 7.2-10 ft-lb)



Install the washer over the gearshift spindle. Install the gearshift spindle into the crankcase.



Hook the spring to the gearshift plate.




CLUTCH/OIL PUMP/KICK STARTER/GEARSHIFT LINKAGE


Align the punch marks and install the gearshift pedal onto the spindle, then tighten the bolt.

TORQUE: 14-18 N·m (1.4-1.8 kg-m, 10-13 ft-lb)

Install the clutch (page 8-13). Install the right crankcase cover (page 8-5). Fill the engine with the recommended oil (page 2-2).



MEMO



| SERVICE INFORMATION LEFT CRANKCASE COVER REMOVAL | 9-1 9-2 | LEFT CRANKCASE COVER INSTALLATION | 9-4 |
|--|------------|-----------------------------------|-----|
| ALTERNATOR | 9-2 | | |

SERVICE INFORMATION

GENERAL

• This section covers removal and installation of the alternator. Refer to Section 16 for alternator inspection.

• The right crankcase cover must be removed to remove the flywheel.

TORQUE VALUES

| Flywheel bolt | 45-55 N·m (4.5-5.5 kg-m, 33-40 ft-lb) |
|-----------------------|---------------------------------------|
| Gearshift pedal bolt | 14-18 N·m (1.4-1.8 kg-m, 10-13 ft-lb) |
| Footpeg bolt | 60-70 N·m (6.0-7.0 kg-m, 43-51 ft-lb) |
| Pulse generator screw | 8-12 N·m (0.8-1.2 kg-m, 5.8-9 ft-lb) |
| Stator mounting bolt | 8-12 N·m (0.8-1.2 kg-m, 5.8-9 ft-lb) |

TOOLS

Common


Gear holder 07724-0010100

Rotor puller 07733-0020001 or 07933-2160000

LEFT CRANKCASE COVER REMOVAL


Drain the engine oil (page 2-2).

Disconnect the alternator and pulse generator wire couplers and the connector.




Remove the following parts:

- gearshift pedal bolt and pedal
- left footpeg bolts and footpeg
- drive sprocket cover bolts and cover
- left crankcase cover bolts, cover, cover gasket and dowel pins.



Check the gearshift shaft oil seal on the left crankcase cover for wear or damage; replace if necessary.




ALTERNATOR

STATOR/PULSE GENERATOR REMOVAL

Remove the pulse generator mounting screws and remove the pulse generator.

Remove the three stator bolts and the stator.



FLYWHEEL REMOVAL


Remove the right crankcase cover (page 8-3).

Hold the primary drive gear with the gear holder and remove the flywheel bolt and washer.

TOOL:

Gear holder

07724-0010100




Remove the flywheel with the puller, then remove the woodruff key from the crankshaft.

TOOL:

Rotor puller

07733-0020001 or 07933-2160000



FLYWHEEL INSTALLATION

Install the woodruff key aligning it with the key way in the crankshaft.

Clean the tapered hole in the flywheel of any burrs and other faults; repair if necessary.

Install the flywheel by aligning the keyway in the flywheel with the key on the crankshaft.

NOTE

 Check for debris inside the flywheel before installation. The magnets tend to attract steel filings and other ferrous debris.

Install the washer and the flywheel bolt.

Hold the primary drive gear with the gear holder and tighten the flywheel bolt.


TORQUE: 45-55 N·m (4.5-5.5 kg-m, 33-40 ft-lb)


TOOL:

Gear holder

07724-0010100

Install the right crankcase cover (page 8-5).





STATOR/PULSE GENERATOR INSTALLATION


Install the pulse generator using the two screws and place its wire grommet in the groove.

TORQUE: 8-12 N·m (0.8-1.2 kg-m, 5.8-9 ft-lb)

Install the stator in the left crankcase cover and place the wire grommet in the groove.


Tighten the three stator mounting bolts.

TORQUE: 8-12 N·m (0.8-1.2 kg-m, 5.8-9 ft-lb)



LEFT CRANKCASE COVER INSTALLATION

Install the dowel pins and a new gasket.



Install the left crankcase cover and tighten the cover bolts.

NOTE

 Use copper washers where indicated by the "▲" marks on the left crankcase cover.

Install the drive sprocket cover and tighten the cover bolts. Align the punch marks and install the gearshift pedal onto the gearshift shaft, then tighten the bolt.

TORQUE: 14-18 N·m (1.4-1.8 kg-m, 10-13 ft-lb).


Install the left footpeg and tighten the bolts.

TORQUE: 40-50 N·m (4.0-5.0 kg-m, 29-33 ft-lb)


Connect the pulse generator and stator wire couplers and connector.

Fill the engine with the recommended oil (page 2-2). Check the ignition timing (page 3-8).





MEMO



10

10. CRANKCASE/TRANSMISSION/CRANKSHAFT

| SERVICE INFORMATION TROUBLESHOOTING | 10-1 10-3 | CRANKSHAFT BEARING REPLACEMENT | 10-10 10-12 |
|-------------------------------------|--------------|--------------------------------|----------------|
| CRANKCASE SEPARATION TRANSMISSION | 10-4 10-5 | CRANKCASE ASSEMBLY | 10-15 |

SERVICE INFORMATION

GENERAL

• Remove the following parts before separating the crankcase:

Cylinder head
 Cylinder/piston
 Clutch/oil pump/kick starter/gearshift linkage
 Alternator
 Section 8
 Section 9

• For crankshaft and transmission repair, the crankcase must be separated.

SPECIFICATIONS

| | ITEM | | STANDARD mm (in) | SERVICE LIMIT mm (in) |
|-----------------|----------------------|-------------------------------|--------------------------------|--------------------------|
| Shift fork, | Shift fork I.D. | | 13.000-13.021 (0.5118-0.51264) | 13.05 (0.514) |
| Shift fork | Shift fork claw this | ckness | 4.93-5.00 (0.194-0.197) | 4.88 (0.192) |
| shaft | Shift fork shaft O. | D. | 12.966-12.984 (0.5105-0.5112) | 12.94 (0.509) |
| Transmission | Gear I.D. | M5, M6 | 23.000-23.021 (0.9055-0.9063) | 23.04 (0.907) |
| | | C1 | 20.500-20.521 (0.8071-0.8079) | 20.54 (0.809) |
| | C2, C3, C4 | 26.000-26.021 (1.0236-1.0244) | 26.04 (1.025) | |
| Bushing I.D. | M5 | 20.000-20.021 (0.7874-0.7882) | 20.04 (0.789) | |
| | C1 | 18.000-18.018 (0.7087-0.7094) | 18.04 (0.710) | |
| | | C2, C4 | 22.000-22.021 (0.8662-0.8670) | 22.04 (0.868) |
| | Bushing O.D. | M5, M6 | 22.959-22.980 (0.9039-0.9047) | 22.94 (0.903) |
| Gear-to-bushing | C1 | 20.459-20.480 (0.8055-0.8063) | 20.44 (0.805) | |
| | C2, C3, C4 | 25.959-25.980 (1.0220-1.0228) | 25.94 (1.021) | |
| | M5, M6 | 0.020-0.062 (0.0008-0.0024) | 0.10 (0.004) | |
| | clearance | C1, C2, C3, C4 | 0.020-0.062 (0.0008-0.0024) | 0.10 (0.004) |

CRANKCASE/TRANSMISSION/CRANKSHAFT

| ITEM | | STANDARD mm (in) | SERVICE LIMIT mm (in) | |
|--------------|---|---------------------------|-------------------------------|---------------|
| Transmission | Mainshaft O.D. | M5, clutch outer guide | 19.959-19.980 (0.7858-0.7866) | 19.94 (0.785) |
| | Countershaft | C1 | 17.966-17.984 (0.7073-0.7080) | 17.94 (0.706) |
| | O.D. | C2, C4 | 21.959-21.980 (0.8645-0.8654) | 21.94 (0.864) |
| | Bushing-to-shaft clearance | M5 | 0.020-0.062 (0.0008-0.0024) | 0.10 (0.004) |
| | | C1, C2, C4 | 0.020-0.062 (0.0008-0.0024) | 0.10 (0.004) |
| Crankshaft | Crankshaft Runout | | | 0.03 (0.0012) |
| | Connecting rod big end axial clearance | | 0.05-0.50 (0.002-0.02) | 0.8 (0.03) |
| | Connecting rod big end radial clearance | | 0.004-0.012 (0.0002-0.0005) | 0.05 (0.002) |

TORQUE VALUES

Bearing holder plate bolt

10-14 N·m (1.0-1.4 kg-m, 7.2-10 ft-lb)

Crankcase bolt

10-14 N·m (1.0-1.4 kg-m, 7.2-10 ft-lb)

TOOLS

Special

Universal bearing puller 07631-0010000 or equivalent commercially available in U.S.A.

Assembly collar 07965-VM00100

Assembly shaft 07965-VM00200 or 07931-ME4000A (U.S.A. only)
Thread adaptor 07GMF-HB50100 or 07965-HB3000A (U.S.A. only)

Bearing remover set, 15 mm 07936-KC10000 not available in U.S.A.

- Bearing remover, 15 mm 07936-KC10500

- Remover weight 07741-0010201 or 07936-3710200

Common

| Driver | 07749-0010000 |
|------------------------|---------------|
| Attachment, 62 X 68 mm | 07746-0010500 |
| Pilot, 28 mm | 07746-0041100 |
| Attachment, 42 X 47 mm | 07746-0010300 |
| Pilot, 20 mm | 07746-0040500 |
| Attachment, 32 X 35 mm | 07746-0010100 |
| Pilot, 15 mm | 07746-0040300 |
| Pilot, 22 mm | 07746-0041000 |

TROUBLESHOOTING

Crankshaft noisy

- · Worn connecting rod big end bearing
- · Bent connecting rod
- · Worn crankshaft main journal bearing

Jumps out of gear


- · Shift fork bent or damaged
- Shift fork shaft bent
- · Shift claw bent
- Gear engagement dogs or slots worn
- · Shift drum cam grooves damaged

Hard to shift


- · Incorrect clutch adjustment
- · Shift fork bent or damaged
- · Shift fork shaft bent

CRANKCASE SEPARATION

Remove the cam chain and cam chain tensioner slipper.




Remove the left crankcase bolts.



Remove the right crankcase bolts.

NOTE

 Loosen the bolts in a crisscross pattern in 2 or 3 steps to prevent crankcase distortion.




Place the engine with the left crankcase down and remove the right crankcase while tapping the cases at several locations with a soft hammer.

CAUTION


 Do not pry the crankcase halves apart with the end of a screwdriver.

Remove the gasket and dowel pins.



Check the cam chain tensioner slipper and guide for wear or damage.


Replace them if they are excessively worn or damaged.




TRANSMISSION

REMOVAL

Separate the crankcase halves (page 10-4). Pull the shift fork shaft out and remove the shift forks and shift drum.



Remove the mainshaft and countershaft.




INSPECTION

Check that the shift forks are not bent, worn or damaged.

Measure the shift fork claw thickness.


SERVICE LIMIT: 4.88 mm (0.192 in)



CRANKCASE/TRANSMISSION/CRANKSHAFT

Measure the I.D. of the shift fork.


SERVICE LIMIT: 13.05 mm (0.514 in)



Check that the fork shaft is not bent, worn or damaged.

Measure the fork shaft O.D.

SERVICE LIMIT: 12.92 mm (0.509 in)




Inspect the shift drum grooves and replace the drum if they are damaged or show excessive wear.



Inspect each gear for wear or damage and replace if necessary.

Check the gear teeth for wear or damage.

Check the gear engagement dogs for wear or damage.



Measure the I.D. of each gear.

SERVICE LIMIT: M5, M6 23.04 mm (0.907 in)

C1 20.54 mm (0.809 in) C2, C3, C4 26.04 mm (1.025 in)

Measure the I.D. and O.D. of each bushing.

SERVICE LIMIT: I.D.


M5 20.04 mm (0.789 in)
C1 18.04 mm (0.710 in)
C2, C4 22.04 mm (0.868 in)
O.D.

M5, M6 22.94 mm (0.903 in) C1 20.44 mm (0.805 in) C2, C3, C4 25.94 mm (1.021 in)

Calculate the gear-to-bushing clearance.

SERVICE LIMIT: M5, M6 0.10 mm (0.004 in)

C1, C2, C3, C4 0.10 mm (0.004 in)



 $\label{eq:measure the O.D. of the main shaft.}$

SERVICE LIMIT: M5, clutch outer guide

19.94 mm (0.785 in)

Measure the O.D. of the countershaft.


SERVICE LIMIT: C1 17.94 mm (0.706 in)

C2, C4 21.94 mm (0.864 in)

Calculate the bushing-to-shaft clearance.

SERVICE LIMIT: M5 0.10 mm (0.004 in)

C1, C2, C4 0.10 mm (0.004 in)



INSTALLATION


Coat all parts with oil.

Assemble the transmission shafts and gears, noting the loca-


tions of the thrust washers and snap rings.

Make sure that the snap rings are seated properly.


After installing, check for smooth movement.




Align the bushing oil hole with the oil hole in the shaft as shown.



Align the lock washer tabs with the grooves in the spline washer as shown.




Install the mainshaft and countershaft together into the left crankcase.



Install the shift forks with their marks facing down.

NOTE

 The shift forks are marked L for left, C for center and R for right.




Install the shift drum and align each shift fork guide pin with its guide groove in the drum.

Insert the shift fork shaft through the forks into the hole in the left crankcase.

After installing, check for smooth operation.

Assemble the crankcase (page 10-15).



CRANKSHAFT

REMOVAL

Separate the crankcase halves (page 10-4). Remove the transmission (page 10-5).


Remove the crankshaft from the left crankcase.


NOTE

• If the crankshaft cannot be removed by hand, use a hydraulic press to remove it.

Turn the right bearing by hand and check that it moves smoothly and quietly.

The bearing must be replaced if it is noisy or has excessive play.





If the left crankshaft bearing remains on the crankshaft, thread the flywheel bolt into the crankshaft and remove the bearing with the bearing puller.

TOOLS:

Universal bearing puller

07631-0010000 or equivalent commercially available in U.S.A.

If the left crankshaft bearing remains in the left crankcase, remove it.

Discard the left crankshaft bearing.


NOTE


 Always replace the left crankshaft bearing with a new one whenever the crankshaft is removed from the left crankcase.

INSPECTION

Set the crankshaft on a stand or V-blocks and read the runout using dial indicators.


SERVICE LIMIT: 0.03 mm (0.0012 in)






Measure the axial clearance of the connecting rod big end.

SERVICE LIMIT: 0.8 mm (0.03 in)



Measure the connecting rod radial clearance at two points in the directions indicated by the arrows.

SERVICE LIMIT: 0.05 mm (0.002 in)



INSTALLATION

Drive a new left crankshaft bearing into the left crankcase.

TOOLS:

Driver

Attachment, 62 x 68 mm


Attacimient, 02 x 00 mm

Pilot, 28 mm

07749-0010000

07746-0010500

 $07746\!-\!0041100$



Install the crankshaft into the left crankcase using the special tools.

Install the transmission and assemble the crankcase.

TOOLS:

Assembly collar

07965-VM00100

Assembly shaft

07965-VM00200 or


07931-ME4000A

(U.S.A. only)

Thread adaptor

07GMF-HB50100 or 07965-HB3000A

(U.S.A. only)




BEARING REPLACEMENT


RIGHT CRANKCASE

Turn the inner race of each bearing with your finger.
The bearings should turn smoothly and quietly. Also check that the bearing outer-race fits tightly in the case.

Remove and discard the bearings if the races do not turn smoothly, quietly, or if they fit loosely in the case.



Remove the bearing holder plate and the mainshaft bearing. Drive out the countershaft and shift drum bearings.



Drive new bearings into the right crankcase using the following tools:

TOOLS:

MAINSHAFT BEARING


Attachment, 42 x 47 mm

| WANTED IN COLUMN TO | |
|------------------------|---------------|
| Driver | 07749-0010000 |
| Attachment, 42 x 47 mm | 07746-0010300 |
| Pilot, 20 mm | 07746-0040500 |
| COUNTERSHAFT | |
| Driver | 07749-0010000 |
| Attachment, 32 x 35 mm | 07746-0010100 |
| Pilot, 15 mm | 07746-0040300 |
| SHIFT DRUM BEARING | |
| Driver | 07749-0010000 |
| | |

Install the mainshaft bearing holder plate and tighten the holder bolt.

07746-0010300


TORQUE: 10-14 N·m (1.0-1.4 kg-m, 7.2-10 ft-lb)




LEFT CRANKCASE

Turn the inner race of each bearing with your finger.
The bearings should turn smoothly and quietly. Also check that the bearing outer race fits tightly in the case.

Remove and discard the bearings if the races do not turn smoothly, quietly, or if they fit loosely in the case.



Remove the snap ring, countershaft oil seal and drive out the bearing.



Remove the mainshaft bearing with the bearing remover.

TOOLS:

Bearing remover set, 15 mm

- Bearing remover, 15 mm


- Remover weight

07936-KC10000 not


available in U.S.A. 07936—KC10500

07741-0010201 or

07936-3710200




Remove the oil plate and check that it is not clogged and damaged. Replace the oil plate with a new one if necessary.



CRANKCASE/TRANSMISSION/CRANKSHAFT


Place a new mainshaft bearing with the sealed end facing down.



Drive in a new mainshaft bearing with the sealed end facing down.

TOOLS:

07749-0010000 Driver 07746-0010100 Attachment, 32 X 35 mm




Drive in a new countershaft bearing.


TOOLS:

Driver 07749-0010000 Attachment, 42 x 47 mm 07746-0010300

07746-0041000 Pilot, 22 mm




Install a new countershaft oil seal and snap ring.



CRANKCASE ASSEMBLY


Install a new gasket and dowel pins.


Install the right crankcase onto the left crankcase.



Tighten the crankcase bolts.

TORQUE: 10-14 N·m (1.0-1.4 kg-m, 7.2-10 ft-lb)







Install the cam chain.

Install the washer, cam chain tensioner slipper, collar and nut; tighten the nut.

Install the removed parts in the reverse order of removal (page 10-1).





11. FRONT WHEEL/SUSPENSION/STEERING

| SERVICE INFORMATION | 11-1 | FRONT WHEEL | 11-7 |
|---------------------|------|---------------|-------|
| TROUBLESHOOTING | 11-2 | FRONT FORK | 11-15 |
| HANDLEBAR | 11-3 | STEERING STEM | 11-21 |
| THROTTLE HOUSING | 11-6 | | |

SERVICE INFORMATION

GENERAL

- This section covers maintenance of the front wheel, front fork, steering system and tire removal/repair.
- A jack or other support is required to support the ATC.

SPECIFICATIONS

| ITEM | | STANDARD mm (in) | SERVICE LIMIT mm (in) | |
|-------------------------|------------|----------------------------|--------------------------|--|
| Axle runout | | | 0.5 (0.02) | |
| Fork spring free length | Upper | 71.0 (2.80) | 67.3 (2.65) | |
| Lower | | 465.9 (18.34) | 456.6 (17.98) | |
| Fork tube runout | | | 0.2 (0.008) | |
| Wheel rim runout | | | 4.0 (0.16) | |
| | Axial | | 4.0 (0.16) | |
| Fork oil capacity | ′86: | 216-221 cc (7.3-7.5 US oz) | | |
| Tork on capacity | After '86: | 226-231 cc (7.6-7.8 US oz) | | |
| Fork oil level | ′86: | 178 mm (7.0 in) | | |
| TOIR OII IEVEI | After '86: | 160 mm (6-1/4 in) | | |

TORQUE VALUES

| Handlebar upper holder bolt Brake disc nut Front axle Front axle holder nut Wheel nut Fork tube cap bolt Fork socket bolt Fork pinch bolt Fork boot band screw Steering bearing adjustment nut Steering stem nut Brake hose stay nut Brake hose clamp bolt Steering stem cover | Initial Final | 18-30 N·m (1.8-3.0 kg-m, 13-22 ft-lb) 20-30 N·m (2.0-3.0 kg-m, 15-22 ft-lb) 70-110 N·m (7.0-11.0 kg-m, 51-80 ft-lb) 10-14 N·m (1.0-1.4 kg-m, 7.2-10 ft-lb) 60-70 N·m (6.0-7.0 kg-m, 43-51 ft-lb) 15-30 N·m (1.5-3.0 kg-m, 11-22 ft-lb) 15-25 N·m (1.5-2.5 kg-m, 11-18 ft-lb) 18-25 N·m (1.8-2.5 kg-m, 13-18 ft-lb) 0.6-1.2 N·m (0.06-0.12 kg-m, 0.4-0.9 ft-lb) 25-35 N·m (2.5-3.5 kg-m, 18-25 ft-lb) 7-8 N·m (0.7-0.8 kg-m, 5.1-5.8 ft-lb) 90-120 N·m (9.0-12.0 kg-m, 65-87 ft-lb) 24-30 N·m (2.4-3.0 kg-m, 17-22 ft-lb) 10-14 N·m (1.0-1.4 kg-m, 7.2-10 ft-lb) 1-2 N·m (0.1-0.2 kg-m, 0.7-1.4 ft-lb) |
|---|------------------|---|
| Steering stem cover | | 1-2 N·m (0.1-0.2 kg-m, 0.7-1.4 ft-lb) |

TOOLS

Special

Snap ring pliers 07914—3230001 or equivalent commercially available in U.S.A.

 Steering stem socket
 07916−3710100

 Ball race remover
 07953−3330000

 Ball ∤ace driver
 07946−3290000

Steering stem driver 07946-4300101 or 07946-MB00000 with GN-HT-54

Universal bead breaker GN-AH-958-BB1 (U.S.A. only)

Common

Bearing remover shaft 07746-0050100 or equivalents commercially available in U.S.A.

 Bearing remover head, 15 mm
 07746-0050400

 Driver
 07749-0010000

 Attachment, 42 X 47 mm
 07746-0010300

 Pilot, 15 mm
 07746-0040300

Tire bead breaker set 07772-0050000 or GN-AH-958-BB1 Universal bead breaker

 -Breaker arm compressor
 07772-0050100

 -Breaker arm
 07772-0050200

Fork seal driver 07747-0010100-ror 07947-3330000

Fork seal driver attachment (D) 07747-0010501

Extension 07716-0020500 or equivalent commercially available in U.S.A. Lock nut wrench, 30 X 32 mm 07716-0020400 or equivalent commercially available in U.S.A.

TROUBLESHOOTING

Hard steering

- · Steering stem nut too tight.
- · Faulty steering stem bearings.
- Damaged steering stem ball race and/or cone race.
- · Insufficient tire pressure.

Steers to one side or does not track straight

- Bent front forks.
- Bent front axle, wheel installed incorrectly.
- Unequal rear tire pressure or circumference.

Front wheel wobbling

- · Bent rim.
- · Worn front wheel bearing.
- · Faulty tire.
- · Axle not tightened properly.

Soft suspension

- · Weak fork springs.
- Insufficient fluid/air in front forks.

Hard suspension

- · Incorrect fluid/air in front forks.
- · Fork damaged.


Front suspension noise

- Slider binding.
- · Loose front fork fasteners.
- · Insufficient fluid in forks.

HANDLEBAR

REMOVAL


Remove the throttle housing and front brake master cylinder from the handlebar.



Remove the clutch/parking brake lever bracket and switch housing from the handlebar.


Remove the switch wire bands.

Remove the left and right grips.



'86:

Remove the handlebar upper holders and the handlebar.




After '86:

Release lugs on the handlebar cover cap by turning the cap with a coin or equivalent tool which fits into the groove in the cap, and remove the cap by inserting the same coin or tool in the clearance between the cap and cover.

NOTE


- · Do not use the screwdriver because it will scratch the cap.
- The cap is not screw type. Do not push down on the cap or it will damage the cap.

Remove the handlebar cover attaching screws and the cover.




FRONT WHEEL/SUSPENSION/STEERING

Remove the handlebar upper holders and the handlebar.




INSTALLATION

Place the handlebar onto the lower holders, aligning the punch mark on the handlebar with the top of the lower holder.




'86:

Install the handlebar upper holders with the punch marks facing forward.



Tighten the front bolts first, then tighten the rear bolts.

TORQUE: 18-30 N·m (1.8-3.0 kg-m, 13-22 ft-lb)



After '86:

Install the handlebar upper holders with the punch marks facing forward.

NOTE

 The handlebar upper holders have marks: L for left side and R for right side.

Tighten the front bolts first, then tighten the rear bolts.

TORQUE: 18-30 N·m (1.8-3.0 kg-m, 13-22 ft-lb)

After '86

(1) PUNCH MARKS


Install the handlebar cover onto the upper holders.

Tighten the attaching screws securely.

Align the lugs on the handlebar cover cap with the grooves in the cover, and install the caps.

Insert the fuel tank breather tube into the hole of the handlebar cover and steering stem nut.

Push the tube in far enough so that the white mark on it is not visible above the surface of the handlebar cover.



Apply Honda Bond A or Honda Grip Cement (U.S.A. only) to the inside surface of the left and right grips and to the clean surface of the handlebar.

Wait 3-5 minutes and install the grips. Rotate the grips for even application of the adhesive.

NOTE

Allow the adhesive to dry for an hour before using.


Align the switch housing locating pin with the hole in the handlebar and install the switch housing.


Tighten the upper screw first, then tighten the lower screw.

Install the handlebar switch wire bands.

Place the clutch/parking brake lever bracket on the handlebar and install the holder with the "UP" mark facing up.

Align the bracket holder end with the punch mark on the handlebar and tighten the upper screw first, then tighten the lower screw.






FRONT WHEEL/SUSPENSION/STEERING

Place the front brake master cylinder on the handlebar and install the holder with the "UP" mark facing up.

Align the master cylinder holder end with the punch mark on the handlebar and tighten the upper screw first, then tighten the lower screw.




Position the throttle housing on the handlebar and install it using the throttle housing holder and two screws.

Align the ridge of the housing with the mating surface of the master cylinder and holder, and tighten the forward screw first, then tighten the rear screw.

Inspect the following after installing the handlebar:


- Clutch lever free play (page 3-15).
- Throttle lever free play and return (page 3-4).
- Operation of parking brake lever (page 3-13).
- · Function of handlebar switch.
- Operation of front brake lever.



THROTTLE HOUSING

DISASSEMBLY


Remove the three throttle housing cover screws and the cover. Remove the gasket.



Loosen the throttle cable adjuster and remove the lock nut.

Disconnect the throttle cable from the throttle arm.

Remove the throttle arm, spring and throttle lever from the throttle housing.




ASSEMBLY

Connect the throttle cable to the throttle arm and install the spring.

Install the throttle lever in the housing.


Install the arm onto the lever by aligning their flats.



Install the lock nut and tighten it.

Install a new cover gasket and secure the throttle housing cover using the three screws.

Adjust throttle lever free play (page 3-4).



FRONT WHEEL

REMOVAL

Loosen the axle holder nut, axle and wheel nuts.

Raise the front wheel off the ground by placing a block or safety stand under the skid plate.

Remove the wheel nuts and slide the wheel away from the brake disc.

Place a small wooden wedge between the brake pads to keep them from being forced out at the caliper.

NOTE


 Do not loosen the brake hose. Whenever the brake hose is loosened, it is necessary to bleed air from the brake. Refer to page 14-3 for bleeding procedures.


Remove the axle and the front wheel.

INSPECTION

Set the axle in V-blocks, rotate it and measure the runout.

SERVICE LIMIT: 0.5 mm (0.02 in)





FRONT WHEEL/SUSPENSION/STEERING


Turn the inner race of each wheel bearing with your finger. The bearings should turn smoothly and quietly.

Also check that the bearing outer race fits tightly in the wheel hub.

Remove and discard the bearings if they do not turn smoothly, quietly, or if they fit loosely in the wheel hub.


NOTE

· Replace the wheel hub bearings in pairs.




WHEEL BEARING REPLACEMENT

Remove the side collars and dust seals from the wheel hub.



Remove the front brake disc from the wheel hub.



Remove the wheel bearings with a bearing remover.

TOOLS:

Bearing remover shaft

 $\begin{array}{ll} 07746-0050100 \ \text{or} \\ \text{equivalent commercially} \end{array}$


available in U.S.A.

Bearing remover head, 15 mm

07746 – 0050400 or equivalent commercially available in U.S.A.

NOTE

 Never reinstall old bearings; once the bearings have been removed, they must be replaced with new ones.




Pack the new bearings with grease.

First, drive a new left bearing in squarely until it is fully seated, install the spacer, then drive a new right bearing in squarely.

TOOLS:


Driver 07749-0010000 Attachment, 42 x 47 mm 07746-0010300 Pilot, 15 mm 07746-0040300



Install the front brake disc with the "DRIVE" mark facing out (arrow points the normal rotating direction).

Tighten the brake disc nuts.

TORQUE: 20-30 N·m (2.0-3.0 kg-m, 15-22 ft-lb)



Apply grease to the dust seal lips and install the seals into the hub.

Install the side collars into the hub.

NOTE

· The longer collar is for the left side.

(1) RIGHT SIDE COLLAR (2) LEFT SIDE COLLAR (3) DUST SEALS

TIRE REPAIR

NOTE


- Use the manufacturer's instructions for the tire repair kit you are using.
- If your kit does not have instructions use the procedures provided here.

Check the tire for puncturing objects. Chalk mark the punctured area and remove the puncturing object.

Inspect and measure the injury. Tire repairs for injuries larger than 15 mm (5/8 in) should be a section repair.

Section repairs should be done by a professional tire repair shop.

If the injury is smaller than 15 mm (5/8 in), proceed with the repair as described here.



FRONT WHEEL/SUSPENSION/STEERING

Install a rubber plug into the injury as follows:

Apply cement to a plug inserting needle and work the needle into the injury to clean and lubricate it. Do this three times. Do not let the cement dry.

Insert and center a rubber plug through the eye of the inserting needle.

Apply cement to the rubber plug.

Push the inserting needle with plug into the injury until the plug is slightly above the tire. Twist the needle and remove it from the tire, the plug will stay in the tire.

NOTE

 Be careful not to push the plug all the way into the tire to prevent it from falling inside.

Trim the plug to 6 mm (1/4 in) above the tire surface.

Repeat the above procedure if the puncture is large. Do not use more than two plugs per injury.

Allow the repair to dry. Drying time will vary with air temperature. Refer to the tire repair kit manufacturer's recommendations.

Inflate the tire and test the seal by dabbing a small amount of cement around the plug. Escaping air will cause a bubble in the cement. If there is leakage, remove the tire (page 11-11) and apply a cold patch to the inside of the tire as described.

If a plug has been inserted, trim it even with the inner tire surface


Temporarily place a rubber patch that is at least twice the size of the puncture over the injury. Make a mark around the patch, slightly larger than the patch itself. Remove the patch.


Roughen the area marked inside the tire with a tire buffer or a wire brush. Clean the rubber dust from the buffed area.


Apply cement over the area marked and allow it to dry. Remove the lining from the patch and center it over the injury. Press the patch against the injury using a special roller.


NOTE

- Allow cement to dry until tacky before applying patch.
- Do not touch the cement with dirty or greasy hands.









TIRE REMOVAL

NOTE

This service requires the Universal Bead Breaker (GN-AH-958-BB1) available in U.S.A. only.

Remove the core from the valve stem.

CAUTION

- Use of the Bead Breaker tool is required for tire removal.
- Do not damage the bead seating area of the rim.
- Use a Coats 220 Tire Changer or equivalent to remove the tire from the rim. If a tire changer is not available, rim protectors and tire irons may be used.

Install the proper size blade onto the breaker arm assembly.

Short blade - 7''/8'' rims. Long blade $-9^{\prime\prime}/11^{\prime\prime}$ rims.

CAUTION


Use of an improper size blade may result in damage to the rim, tire or blade.

Place the proper size adapter onto the threaded shaft and then put the wheel over the threaded shaft and adapter.

Apply water to the bead area, pressing down on the tire sidewall/bead area in several places, to allow the water to run into and around the bead. Also apply water to the area where the breaker arm will contact the sidewall of the tire.

WARNING


during riding.




While holding the breaker arm assembly at an approximate 45° position, insert the blade of the breaker arm between the tire and rim. Push the breaker arm inward and downward until it is in the horizontal position with its press block in contact with the rim.

NOTE

· It may be necessary to tap the breaker arm with a brass hammer to install it the last 3 mm. While doing so, be sure to hold the arm down in the horizontal position.





FRONT WHEEL/SUSPENSION/STEERING

With the breaker arm in the horizontal position, place the breaker press head assembly over the breaker arm press block. Make sure the press head bolt is backed out all the way and then position the nylon buttons on the press head against the inside edge of the rim.

Insert the threaded shaft through the appropriate hole in the breaker press head assembly and then tighten the lever nut until both ends of the breaker press head assembly are in firm contact with the rim.

NOTE

 Insert bolts through the holes in the rim hub mounting tabs and the adapter to position the adapter properly.

Tighten the press head bolt until the reference mark on the press block is aligned with the top edge of the press head.

If the rest of the bead cannot be pushed down into the center of the rim by hand, loosen the press head bolt and the lever nut. Rotate the breaker arm assembly and breaker press head assembly 1/8 to 1/4 the circumference of the rim. Tighten the lever nut and then tighten the press head bolt as described. Repeat this procedure as necessary until the remainder of the bead can be pushed down into the center of the rim.

Assemble the Universal Bead Breaker on the other side of the wheel and break the bead following the same procedures.

Remove the tire from the rim using a tire changer machine or tire irons and rim protectors.

Remove the front tire from the valve stem side and the rear tires from the side opposite the valve stem.

TIRE REMOVAL (EXCEPT U.S.A.)

NOTE

 This service requires the Tire Bead Breaker Set (07772— 0050000) not available in U.S.A.

CAUTION

- Do not apply water, soap water, oil etc. to the tire, rim and tool
 when removing the tire. The tool breaker arm may slip off the
 tire and the bead cannot be broken off the tire.
- Do not damage the bead seating area of the rim.
- Follow the breaker manufacturer's instructions.


Insert the narrow end (A side) of the breaker arm between the tire and the rim.


Position the breaker arm compressor onto the rim center as shown.


TOOLS:


Tire bead breaker set 07772-0050000 not available in U.S.A.

- Breaker arm 07772 - 0050200
- Breaker arm compressor 07772 - 0050100











Keep the breaker arm horizontal and align the end of the compressor bolt with the arm hole.



Screw in the breaker arm compressor bolt to break the bead from the tire.

If the rest of the bead cannot be pushed down into the center of the rim, remove and reposition the compressor and arm 1/8 to 1/4 the circumference of the rim. Tighten the compressor bolt to break the bead. Repeat this procedure as necessary until the remainder of the bead can be pushed down into the center of the the rim.



If the bead breaking is difficult with the narrow end (A side) of the breaker arm, use the wide end (B side) of the arm and repeat the procedure above.

TIRE ASSEMBLY

After removing the tire from the rim, cut the valve off the rim. Install a new valve into the valve hole in the rim securely.

NOTE

- Be careful not to damage the valve hole.
- Be sure to replace the valve with a new one whenever the tire is removed from the rim.


Clean the rim bead seat and flanges.


Apply clean water to the rim flanges, bead seat and base. Install the tire on the rim.

WWARNING

Use only water as a lubricant when mounting tires.
 Soap or some mounting lubricants may leave a slippery residue which can cause the tire to shift on the rim and lose air pressure during riding.

Inflate the tire to seat the tire bead.





CAUTION

 Do not inflate the tire with more than 150 kPa (1.5 kg/cm², 22 psi) of air.

If the tire does not seat on the rim with 150 kPa (1.5 kg/cm², 22 psi) of air pressure, release the air from the tire and apply water to the tire bead and bead seating surface of the rim. Then, inflate the tire with air again.

Deflate the tire. Wait 1 hour, install the valve core in the valve stem and inflate the tire to the specified pressure.

'86

| | Recommended pressure | Standard tire circumference |
|-------|----------------------------------|-----------------------------|
| Front | 25 kPa (0.25 kg/cm², 3.6 psi) | 1,890 mm (74.4 in) |
| Rear | 17 kPa (0.17 kg/cm², 2.5 psi) | 1,720 mm (67.7 in) |

NOTE

 The rear tires must have the same circumference for proper handling.

After '86

| | Recommended |
|-------|-------------------------------------|
| | pressure |
| Front | 25 kPa |
| | (0.25 kg/cm ² , 3.6 psi) |
| Rear | 17.5 kPa |
| | (0.175 kg/cm², 2.5 psi) |

Check for air leaks and install the valve cap.

FRONT WHEEL INSTALLATION

Install the hub on the wheel.

Install the front brake caliper over the disc, being careful not to damage the pads.

Loosely install the wheel nuts with the tapered side facing in.

If the axle holder has been removed, loosely install the holder with the "UP" mark facing up.

Insert the axle into the fork slider leg and hub loosely tighten the axle.

Lower the front wheel on the ground and tighten the wheel nuts.


TORQUE: 60-70 N·m (6.0-7.0 kg-m, 43-51 ft-lb)


Tighten the axle.

TORQUE: 70-110 N·m (7.0-11.0 kg-m, 51-80 ft-lb)

Tighten the upper axle holder nuts first, then tighten the lower nuts.

TORQUE: 10-14 N·m (1.0-1.4 kg-m, 7.2-10 ft-lb)






FRONT FORK

REMOVAL

Remove the front wheel (page 11-7).

Remove the front brake hose clamp from the right fork slider.



Remove the headlight case retaining bands and headlight case (page 16-5).


Remove the air valve caps and release the air from each fork tube.

WWARNING


 Be sure to release front fork air pressure before disassembling to prevent parts from becoming projectiles.


Loosen the fork tube caps.

Loosen the brake hose stay nuts and fork top and bottom pinch bolts.



Pull the fork tube out of the bridge and steering stem.





DISASSEMBLY

Hold the fork tube in a vise with soft jaws or a shop towel and remove the fork tube cap.


CAUTION

• Do not damage the fork tube sliding surface.

WARNING


 The fork cap is under spring pressure. Use care when removing the cap to keep it from causing injury.

Remove the spring seat and fork springs.



FRONT WHEEL/SUSPENSION/STEERING

Drain the fork oil by pumping the fork up and down several times.



Hold the fork slider in a vise with soft jaws or shop towel.

CAUTION

• Do not overtighten the slider in the vise. Overtightening will damage the slider.


Remove the socket bolt.


NOTE

 Temporarily install the springs and fork tube cap if difficulty is encountered in removing the socket bolt.

Remove the fork piston and rebound spring.

Remove the dust seal.






Remove the snap ring.

TOOL:


Snap ring pliers

07914-3230001



Pull the fork tube out until resistance from the slider bushing is felt. Then move the tube in and out, tapping the bushing lightly until the fork tube separates from the slider. The slider bushing will be forced out by the tube bushing.


Remove the oil lock piece.



Remove the oil seal, back-up ring and slider bushing from the fork tube.

NOTE

 Do not remove the fork tube bushing unless it is necessary to replace it with a new one.




INSPECTION

Measure the fork springs free length.

SERVICE LIMITS:


UPPER FORK SPRING: 67.3 mm (2.65 in) LOWER FORK SPRING: 456.6 mm (17.98 in)



Check the fork tube, slider and piston for scoring, scratches, or excessive or abnormal wear.

Replace any components which are worn or damaged.


Check the fork piston ring for wear or damage. Check the rebound spring for fatigue or damage.



FRONT WHEEL/SUSPENSION/STEERING

Place the fork tube in V blocks and read the runout.

SERVICE LIMIT: 0.20 mm (0.008 in)





Visually inspect the slider and fork tube bushing. Replace the bushing if there is excessive scoring or scratching, or if the teflon is worn so that the copper surface appears on more than 3/4 of the entire surface.

ASSEMBLY

NOTE

Wash all removed parts in solvent and wipe them off thoroughly before assembly.






Install the piston ring on the piston.

Install the fork tube bushing if a new one is being installed.

Install the rebound spring and piston into the fork tube.

Place the oil lock piece on the end of the piston and insert the fork tube into the slider.



Place the fork slider in a vise with soft jaws or a shop towel.

Clean the socket bolt threads and apply thread lock agent to the threads. Screw the socket bolt into the piston and tighten it.

NOTE

 Temporarily install the fork springs and fork tube cap to tighten the socket bolt.

TORQUE: 15-25 N·m (1.5-2.5 kg-m, 11-18 ft-lb)

Place the slider bushing over the fork tube and rest it on the slider. Put the back-up ring and an old bushing or equivalent tool on the top.

Drive the bushing into place with the fork seal driver and remove the old bushing or equivalent tool.

Wrap tape around the top of the fork tube to prevent damage to the new oil seal.

Coat the new seal with ATF and install it with the seal markings facing up. Drive the seal in, until the snap ring groove is visible, with the fork seal driver.


TOOLS:


Fork seal driver 07747-0010100
Fork seal driver attachment (D) 07747-0010501
or fork seal driver 07947-3330000


Install the snap ring and dust seal.

TOOL:

Snap ring pliers 07914-3230001







FRONT WHEEL/SUSPENSION/STEERING

Fill the fork with ATF.

CAPACITY:

'86: 216-221 cc (7.3-7.5 US oz) After '86: 226-231 cc (7.6-7.8 US oz)

Pump the fork several times.

Compress the fork and measure the ATF level from the top of the tube after the level stabilizes.


SPECIFIED LEVEL:


'86: 178 mm (7.0 in)

After '86: 160 mm (6-1/4 in)


Wipe ATF off the springs thoroughly using a clean cloth.

Install the lower fork spring with the tapered end facing down. Install the spring seat and the upper fork spring.






Loosely install the fork tube cap.



Install the fork boot on the fork tube and slider.



INSTALLATION

Install the front fork into the steering stem and fork bridge, and align the groove of the fork tube with the top of the fork bridge.

Tighten the fork top and bottom pinch bolts.

TORQUE: 18-25 N·m (1.8-2.5 kg-m, 13-18 ft-lb)

Tighten the fork tube cap.

TORQUE: 15-30 N·m (1.5-3.0 kg-m, 11-22 ft-lb)

Tighten the brake hose stay nuts.

TORQUE: 24-30 N·m (2.4-3.0 kg-m, 17-22 ft-lb)

Slide the fork boot up to the steering stem and tighten the boot band.

TORQUE: 0.6-0.12 N·m (0.06-0.012 kg-m, 0.4-0.9 ft-lb)

Install the headlight case retaining bands.

Install the front brake hose clamp onto the right fork slider and tighten the bolt.

TORQUE: 10-14 N·m (1.0-1.4 kg-m, 7.2-10 ft-lb)

Install the front wheel (page 11-14).

STEERING STEM

REMOVAL

Remove the following parts:

- headlight case (page 16-5)
- handlebar (page 11-3)
- front wheel (page 11-7)

Remove the brake hose clamp bolt then remove the brake hose clamp from the right fork slider.

Remove the brake hose stay nuts then remove the brake hose clamp from the steering stem.


'86


Remove the brake hose guide screw and nut from the front fender right side.


After '86:


Remove the brake hose guide screw, nut and collar from the front fender right side.

Remove the brake hose from the brake hose guide.











Remove the front fender.



Remove the cable guide from the fork bridge.



'86:

Remove the steering stem nut and washer.

After '86:

Remove the steering stem nut.

Loosen the fork pinch bolts, and remove the front forks.

Remove the fork bridge.

TOOLS:

Extension 07716-0020500 or

equivalent commercially available in U.S.A.

Lock nut wrench, 30 x 32 mm 07716-0020400 or


equivalent commercially available in U.S.A.


Remove the steering stem cover from the steering stem.

Loosen the steering bearing adjustment nut.

TOOL:

Steering stem socket 07916-3710100






Remove the steering bearing adjustment nut, steering stem, upper cone race and steel balls.

NOTE


• The steel ball bearings are loose and easily dropped. Place shop towels on the floor to catch any that do drop.



Check the cone and ball races for wear or damage and replace if necessary.

NOTE

 Replace the balls and races as a set when any component is damaged.



STEERING BEARING REPLACEMENT

Drive out the upper and lower ball races from the steering head pipe.


NOTE

 If the ATC has been involved in an accident, examine the area around the steering head pipe for cracks.

TOOL:

Ball race remover


07953-3330000



Drive new upper and lower ball races into the steering head pipe.

TOOLS:


Driver Ball race driver 07749-0010000 07946-3290000



FRONT WHEEL/SUSPENSION/STEERING

Install the stem nut onto the stem to prevent the threads from being damaged when removing the lower cone race from the stem. Remove the race with a chisel, being careful not to damage the stem.

Remove the dust seal and washer.





Install the washer and dust seal onto the steering stem and press a new lower cone race over the stem with the tool.

TOOL:

Steering stem driver

07946-4300101 or 07946-MB00000 with GN-HT-54






INSTALLATION

Apply grease to the ball and cone races and install the steel balls in the ball races.

NOTE

 Eighteen (18) steel balls are used for both the upper and lower stem bearings.

Insert the steering stem into the steering head pipe, and install the upper cone race and steering bearing adjustment nut.



Tighten the steering bearing adjustment nut to the initial torque.

TORQUE: 25-35 N·m (2.5-3.5 kg-m, 18-25 ft-lb)

TOOL:

Steering stem socket 07916-3710100

Turn the steering stem all the way to the the right and left 2 or 3 times to seat the bearings, loosen the adjustment nut and retighten it to the final specified torque.

TORQUE: 7-8 N·m (0.7-0.8 kg-m, 5.1-5.8 ft-lb)

Install the steering stem cover onto the steering stem and tighten the bolts.

TORQUE: 1-2 N·m (0.1-0.2 kg-m, 0.7-1.4 ft-lb)

'86:

Install the fork bridge, washer and stem nut.

After '86:

Install the fork bridge and stem nut.

Temporarily install the front forks.

Tighten the steering stem nut.

TORQUE: 90-120 N·m (9.0-12.0 kg-m, 65-87 ft-lb)

TOOLS:

Extension 07716-0020500 or

equivalent commercially


available in U.S.A.


Lock nut wrench, 30 x 32 mm 07716-0020400 or equivalent commercially


available in U.S.A.

Install the front forks (page 11-21).

Install the front fender.







FRONT WHEEL/SUSPENSION/STEERING

Install the brake hose stay onto the steering stem and tighten the nuts.

TORQUE: 24-30 N·m (2.4-3.0 kg-m, 17-22 ft-lb)

Route the brake hose to the front fender brake hose stay.

'86

Install the screw and nut, and tighten the screw securely.

After '86:


Install the collar, screw and nut, and tighten the screw secure-ly.


Install the brake hose clamp onto the right fork slider and tighten the bolt.

TORQUE: 10-14 N·m (1.0-1.4 kg-m, 7.2-10 ft-lb)


Install the cable guide onto the fork bridge. Install the following parts:

- -headlight case.
- -handlebar (page 11-4).
- -front wheel (page 11-14).





MEMO



12. REAR WHEELS

| SERVICE INFORMATION | 12-1 | REAR AXLE | 12-2 |
|---------------------|------|--------------------|------|
| TROUBLESHOOTING | 12-1 | REAR AXLE BEARINGS | 12-8 |
| REAR WHEEL | 12-2 | | |

SERVICE INFORMATION

GENERAL

- This section covers maintenance of the rear wheel and drive mechanism.
- A jack or block is required to support the ATC.
- When using the lock nut wrench tool, use a deflecting beam type torque wrench 20 inches long. The lock nut wrench increases the torque wrench's leverage, so the wrench reading will be less than the torque actually applied.
 The torque scale reading is given with the actual torque specifications.
- For tire repair and removal, see pages 11-9, 11.

SPECIFICATIONS

| ITEM | | STANDARD mm (in) | SERVICE LIMIT mm (in) | |
|------------------|--------|------------------|-----------------------|--|
| Axle runout | | | 3.0 (0.12) | |
| Wheel rim runout | Radial | | 4.0 (0.16) | |
| | Axial | | 4.0 (0.16) | |

TORQUE VALUES

| Wheel nut | 60-70 N·m (6.0-7.0 kg-m, 43-51 ft-lb) |
|--------------------------------|--|
| Brake disc nut | 20-30 N·m (2.0-3.0 kg-m, 15-22 ft-lb) |
| Axle outer lock nut | 80-100 N·m (8.0-10.0 kg-m, 58-72 ft-lb) |
| Axle inner lock nut | 100-120 N·m (10.0-12.0 kg-m, 72-87 ft-lb) |
| Brake caliper mounting bolt | 20-30 N·m (2.0-3.0 kg-m, 14-22 ft-lb) |
| Driven sprocket nut | 30-40 N·m (3.0-4.0 kg-m, 22-29 ft-lb) |
| Bearing holder stopper bolt | 8-11 N·m (0.8-1.1 kg-m, 5.8-8 ft-lb) |
| Drive chain adjuster lock bolt | 18-24 N·m (1.8-2.4 kg-m, 13-17 ft-lb) |
| Rear axle nut | 120-170 N·m (12.0-17.0 kg-m, 87-123 ft-lb) |

TOOLS

Special

Lock nut wrench, 45 mm 07916-1870101 (2 piece) or equivalent commercially available in U.S.A.

Common

 Driver
 07749-0010000

 Attachment, 62 x 68 mm
 07746-0010500

 Pilot, 35 mm
 07746-0040800

TROUBLESHOOTING

Wheel wobble or vibration in vehicle

- Bent rim.
- Loose axle bearings.
- · Faulty axle bearing holder.
- · Faulty tire.
- · Loose axle.
- · Worn or damaged swingarm pivot bearings.

REAR WHEEL

REMOVAL

Raise the rear wheels off the ground by placing a jack or block under the engine.

Remove the rear wheel nuts and the wheels.

DISASSEMBLY

For tire disassembly, assembly and repair, refer to Pages 11-9 to 11-14.

INSTALLATION

Install both rear wheels with the tire valve facing out. Tighten the wheel nuts.

TORQUE: 60-70 N·m (6.0-7.0 kg-m, 43-51 ft-lb)

RÉAR AXLE


REMOVAL


Remove the rear wheels.


Remove the cotter pins, axle nuts and wheel hubs from the axle.

Loosen the drive chain adjuster (page 3-10).


Remove the drive chain retaining clip, master link and drive chain.









Move the ends of the axle back and forth, and up and down to check the wheel bearing play. If the play is excessive replace the wheel bearings (page 12-9).



Remove the nuts, chain guide plate, bolts and sprocket from the sprocket hub.



Remove the brake caliper mounting bolts and remove the caliper from the brake disc.



Loosen the axle inner lock nut while holding the outer lock nut.


NOTE

· The lock nut has left-hand threads.

TOOL:

Lock nut wrench, 45 mm

07916 – 1870101 (2 piece) or equivalent commercially available in U.S.A.



Temporarily install the left wheel hub and wheel.

Loosen the outer lock nut until the snap ring can be removed.


NOTE

The lock nut has left-hand threads.

TOOL:


Lock nut wrench, 45 mm

07916—1870101 or equivalent commercially available in U.S.A.




REAR WHEELS


Remove the snap ring, collar, outer lock nut, lock nut thread and inner lock nut from the axle.




Remove the left wheel and hub. Remove the brake disc with the hub from the axle.



Remove the O-ring from the groove in the disc hub.




Remove the brake disc nuts and disc from the disc hub.




Install the axle nut onto the right axle end.

Drive the axle out of the axle bearings from the right side with a plastic hammer.




Remove the O-ring from the axle.



INSPECTION


Place the axle in V-blocks and measure the runout.

SERVICE LIMIT: 3.0 mm (0.12 in)



INSTALLATION

Place a new O-ring on the axle and install the axle from the left side.




REAR WHEELS

Install the disc on the hub with its "DRIVE" mark facing out. Tighten the brake disc nuts.


TORQUE: 20-30 N·m (2.0-3.0 kg-m, 15-22 ft-lb)

WARNING

 Grease or oil on the disc will reduce stopping power. Clean the disc with a high quality brake degreaser if oil or grease gets on the disc.




Install a new O-ring in the groove in the brake disc hub. Install the brake disc hub on the axle.



Apply a thread locking agent to the inner lock nut threads.

Thread the inner and outer lock nuts over the lock nut thread and install them onto the axle.

Install the snap ring collar and snap ring.



Temporarily install the left rear wheel hub and wheel.

Tighten the outer lock nut to the specified torque against the snap ring collar while holding the left rear wheel.

TORQUE: 80-100 N·m (8.0-10.0 kg-m, 58-72 ft-lb)

NOTE


· The inner and outer lock nuts have left-hand threads.

TOOL:

Lock nut wrench, 45 mm

07916 – 1870101 or equivalent commercially available in U.S.A.

Remove the left rear wheel and wheel hub.




Tighten the inner lock nut against the outer lock nut.

TORQUE: 100-120 N·m (10.0-12.0 kg-m, 72-87 ft-lb)

TOOL:


Lock nut wrench, 45 mm

07916 – 1870101 (2 piece) or equivalent commercially available in U.S.A.



Install the brake caliper over the disc and tighten the caliper mounting bolts.

TORQUE: 20-30 N·m (2.0-3.0 kg-m, 14-22 ft-lb)




Install the driven sprocket onto the hub with its teeth number mark facing out.


Install the bolts into the driven sprocket and align the grooves of the driven sprocket with the flats of the bolt heads. Install the chain guide plate and nuts.

Tighten the nuts.

TORQUE: 30-40 N·m (3.0-4.0 kg-m, 22-29 ft-lb)



Install the drive chain with the master link and retaining clip. Face the closed end of the retaining clip in the rotating direction of the chain.



REAR WHEELS

Apply grease to the splines on both ends of the axle.


Install the wheel hubs and axle nuts. Tighten the axle nuts.

TORQUE: 120-170 N·m (12.0-17.0 kg-m, 87-123 ft-lb)

Install new cotter pins and spread the ends.

Install the rear wheels (page 12-2).

Adjust drive chain slack (page 3-10).




REAR AXLE BEARINGS

BEARING HOLDER REMOVAL


Remove the rear wheels and axle (page 12-2).

Remove the snap ring and the brake caliper mounting plate.




Remove the two bolts and rubber seals from the swingarm.

Remove the stopper bolt.




Remove the bearing holder from the swingarm. Remove the O-rings from the bearing holder.



BEARING REPLACEMENT

Remove the dust seals from the bearing holder.




Remove the bearings, spacers and center spacer from the bearing holder.

TOOLS:

Adjustable bearing puller

07736 – A01000A (U.S.A. only) with commercially available slide hammer



Install the spacer into the bearing holder.

Drive a new right bearing into the bearing holder with common tools.

Install the center spacer.

Install the spacer into the bearing holder.


Drive a new left bearing into place with the same tools.

TOOLS:

 Driver
 07749-0010000

 Attachment, 62 x 68 mm
 07746-0010500

 Pilot, 35 mm
 07746-0040800




Apply grease to the lip of new dust seals and drive the dust seals into the bearing holder until their outside surfaces are flush with the end surfaces of the holder.



BEARING HOLDER INSTALLATION

Install new O-rings in the grooves of the bearing holder.

Apply grease to the outside surfaces of the bearing holder and install it in the swingarm.



Install the bearing holder into the swingarm as shown in the figure.

Install the rubber seals and stopper bolt. Tighten the stopper bolt.

TORQUE: 8-11 N·m (0.8-1.1 kg-m, 5.8-8 ft-lb)

Apply grease to the caliper mount plate installation surface of the bearing holder.

Temporarily install the lock bolts.

NOTE

 Tighten the lock bolts to the specified torque after adjusting the drive chain.

TORQUE: 18-24 N·m (1.8-2.4 kg-m, 13-17 ft-lb)


Install the caliper mount plate.


Install the snap ring with its "OUTSIDE" mark facing out and with its ends positioned as shown.

Install the rear axle (page 12-5).


Install the rear wheels (page 12-2).

Adjust the drive chain (page 3-10).









13

13. REAR SUSPENSION

| SERVICE INFORMATION | 13-1 | SHOCK ABSORBER | 13-3 |
|---------------------|------|----------------|------|
| TROUBLESHOOTING | 13-2 | SWINGARM | 13-9 |

SERVICE INFORMATION

GENERAL

- This section deals with rear shock absorber and swingarm repairs.
- A jack or block is required to support the ATC.
- Use only genuine Honda bolts for the shock absorber pivot and mounting; ordinary bolts lack adequate strength for these applications. Also take note of the installation direction of these bolts since they must be installed correctly.

WWARNING

- The shock absorber contains nitrogen gas under high pressure. Do not allow fire or heat near the shock absorber.
- Before disposal of the shock absorber, release the nitrogen by pressing the valve core. Then remove the valve from the shock absorber.
- The shock absorber has a gas-filled reservoir. Use only nitrogen to pressurize the shock absorber. The use of an unstable gas can cause a fire or explosion resulting in serious injury.

SPECIFICATIONS

| | ITEM | STANDARD mm (in) | SERVICE LIMIT mm (in) |
|---|--|--|--------------------------|
| Rear | Rear shock absorber spring free length | 194.0 (7.64) | 190.0 (7.48) |
| Spring installation load length Damper rod compression force, 10 mm (0.4 in) | Spring installation load length | standard length 190.0 (7.48) | |
| | | min-max length 185.5—191.5 (7.30—7.54) | |
| | , , | 26-36 kg (57.3-79.4 lb) | |
| | Nitrogen pressure | 2,000 – 2,300 kPa (20 – 23 kg/cm², 284 – 327 psi) | |

TORQUE VALUES

| Shock absorber upper mount bolt | 40-50 N·m (4.0-5.0 kg-m, 29-36 ft-lb) |
|-----------------------------------|---|
| Shock absorber lower mount bolt | 40-50 N·m (4.0-5.0 kg-m, 29-36 ft-lb) |
| Swingarm pivot bolt | 70-110 N·m (7.0-11.0 kg-m, 51-80 ft-lb) |
| Shock absorber adjusting lock nut | 80-100 N·m (8.0-10.0 kg-m, 58-72 ft-lb) |
| Oil hose joint | 20-25 N·m (2.0-2.5 kg-m, 14-18 ft-lb) |
| Shock absorber adjusting lock nut | 80-100 N·m (8.0-10.0 kg-m, 58-72 ft-lb) |

TOOLS

Special

Bearing remover set, 20 mm 07936-3710001 not available in U.S.A. - Spindle assy, 20 mm 07936-3710600

- Spindle assy, 20 mm 07936-3710600 - Remover handle 07936-3710100

- Remover weight 07741-0010201 or 07936-3710200

Common

 Driver
 07749-0010000

 Attachment, 32 x 35 mm
 07746-0010100

 Pilot, 20 mm
 07746-0040500

Optional

 Pin spanner
 89201 – KA4 – 820

 Pin spanner
 89202 – KA4 – 820

TROUBLESHOOTING

Wobble or vibration in ATC

- · Bent rim.
- Loose axle bearing(s).
- · Damaged tire.
- · Axle not tightened properly.
- · Swingarm pivot bearing worn.
- · Bent frame or swingarm.

Soft suspension

- Spring preload adjustment is improper for rider's weight-See Owner's Manual.
- Compression damping adjustment improper-See Owner's Manual.
- · Weak shock spring.

Hard suspension

- Spring preload is improper for rider's weight-See Owner's Manual.
- Compression or rebound damping is misadjusted-See Owner's Manual.
- · Bent shock damper rod.
- · Swingarm pivot bearings damaged.
- · Frame or swingarm bent.

Suspension noise

- · Faulty rear damper.
- · Loose fasteners.

SHOCK ABSORBER

REMOVAL

Raise the rear wheels off the ground by placing a jack or block under the engine.

Remove the seat/rear fender.

Loosen the connecting tube band screws and remove the connecting tube (air cleaner-to-carburetor).

Remove the following:

- reservoir from the frame by removing the two mount bolts.
- oil hose from the rear engine hanger plate clamp.
- rear wheels (page 12-2).
- shock absorber cover from the swingarm.
- shock absorber upper and lower mount bolts and remove the shock absorber.
- upper and lower mount collars from the shock absorber.



Check the upper and lower mount collars and the upper mount bushing for wear or damage.

Check the lower mount bushing for wear, deterioration or damage.

Replace the parts as required.

Apply a paste grease with 40% or more molybdenum disulfide to the inside of the bushing and dust seal lips when replacing the upper and lower mount bushings.


NOTE


Some sources of MoS_2 paste grease with 40% or more molybdenum are:


- Molykote[®] G-n Paste manufactured by Dow Corning, U.S.A.
- Honda Moly 45 (U.S.A.).
- Rocol Paste manufactured by Sumico Lubricant, Japan.
- · Rocol ASP manufactured by Rocol Limited, U.K.

Any other manufacturer's paste grease equivalent to the above may also be used.

(1) CONNECTING TUBE (2) RESERVOIR







SPRING REMOVAL

Hold the lower shock mount in a vise with soft jaws or a shop towel and loosen the lock and adjusting nuts.

TOOLS:

Pin spanners


89201-KA4-820 and 89202-KA4-820

CAUTION

• Be careful not to damage the hose connection with the vise.


NOTE

The pin spanners are optional tools.



REAR SUSPENSION


Remove the spring seat stopper, spring seat and spring.



SPRING INSPECTION

Measure the spring free length.

SERVICE LIMIT: 190.0 mm (7.48 in)



DAMPER UNIT INSPECTION

Visually inspect the damper unit for dents, oil leaks or other damage. Replace the damper unit if necessary. Place the damper rod on a scale and measure the force required to compress the damper unit 10 mm (0.14 in).

Remember to subtract the weight of the damper unit from your reading.

SPECIFIED FORCE: 26-36 kg (57.3-79.4 lb)

If the force required is less than the applicable range shown here, gas is leaking.

Examine the damper rod and replace the damper if the rod is bent or scored.


DISASSEMBLY


Remove the reservoir valve cap.

Release the nitrogen from the reservoir by depressing the valve core. Do not remove the valve until pressure is released.

WARNING

- Point the valve away from you to prevent debris getting in your eyes.
- Before disposal of the shock absorber, release the nitrogen from the reservoir and then remove the valve.







Disconnect the oil hose from the reservoir and damper unit.

CAUTION

• Do not disassemble the damper unit.


Drain the oil from the reservoir, hose and damper unit.





Hold the upper shock mount in a vise with soft jaws or a shop towel. Point the hole straight up.

Pull out the damper rod all the way and fill the damper with $\ensuremath{\mathsf{ATF}}.$




REAR SUSPENSION

Bleed air from the damper by moving the damper rod with short strokes, in and out several times slowly.

Fill the damper with ATF as required.

NOTE


• The damper should be as free of air as possible.




Fill the reservoir with ATF.

NOTE

Make sure that there is no gas pressure in the reservoir.



Install the O-rings onto the hose joint. Fill the hose with ATF.




Connect the oil hose to the damper unit. Tighten the oil hose joint.

TORQUE: 20-25 N·m (2.0-2.5 kg-m, 14-18 ft-lb)

Very slowly push the damper rod in until ATF begins to overflow from the hose.

Pull the damper rod out all the way and fill the hose with ATF.



Connect the oil hose to the reservoir.

NOTE

Do not allow air to enter the reservoir.

Tighten the oil hose joint.

TORQUE: 20-25 N·m (2.0-2.5 kg-m, 14-18 ft-lb)

Make sure that there is no air in the damper by operating the damper before charging the reservoir with gas.

If damper force is uneven, bleed air from the damper.

Fill the reservoir with 2,000-2,300 kPa $(20-23 \text{ kg/cm}^2, 284-327 \text{ psi})$ of nitrogen.

WWARNING

 The shock absorber is fitted with a gas-filled reservoir. Use only nitrogen gas to pressurize the shock absorber. The use of an unstable gas can cause a fire or explosion resulting in serious injury.

Check the damper compression force is within specification (page 12-4).

SPECIFIED FORCE: 26-36 kg (57.3-79.4 lb)

Install the valve cap.

SPRING INSTALLATION

Install the spring, spring seat and spring seat stopper.

Turn the adjusting nut to obtain the correct spring length.


Measure the spring length.


STANDARD SPRING LENGTH: 190.0 mm (7.48 in)
MINIMUM SPRING LENGTH: 185.5 mm (7.30 in)
MAXIMUM SPRING LENGTH: 191.5 mm (7.54 in)


NOTE


 One turn of the adjusting nut changes the spring length by 1.5 mm (0.06 in).

Use this standard spring preload length as a baseline. See the Owner's Manual for detailed instructions on adjusting preload for rider weight and setting damping for riding conditions and rider skill.









Tighten the lock nut while holding the adjusting nut.


TORQUE: 80-100 N·m (8.0-10.0 kg-m, 58-72 ft-lb)

TOOLS:

Pin spanners

89201-KA4-820 and

89202-KA4-820



Apply a paste grease with 40% or more molybdenum disulfide to the upper and lower mount collars and dust seals and install them into the upper and lower mounts.

NOTE

Some sources of MoS₂ paste grease with 40% or more molybdenum are:

- Molykote[®] G-n Paste manufactured by Dow Corning, U.S.A.
- Honda Moly 45 (U.S.A.)
- · Rocol Paste manufactured by Sumico Lubricant, Japan.
- · Rocol ASP manufactured by Rocol Limited, U.K.

Any other manufacturer's paste grease equivalent to the above may also be used.

GREASE HIMOSZ (FASTE)

MoS₂ (PASTE)

INSTALLATION

Install the shock absorber cover onto the lower mount.

Install the shock absorber with its oil hose joint facing forward and the damping adjuster at the lower mount facing rearward.

Install the upper and lower mount bolts from the right side.


Tighten the upper and lower mount bolts.


TORQUE: $40-50 \text{ N} \cdot \text{m} (4.0-5.0 \text{ kg-m}, 29-36 \text{ ft-lb})$

Route the oil hose to the rear engine hanger plate clamp.

Install the following:

- reservoir on the frame using the band and two bolts.
- connecting tube (air cleaner case-to-carburetor).
- rear wheels (page 12-2).
- seat/rear fender.






SWINGARM

REMOVAL


Remove the following:

- rear wheels and axle (page 12-2).
- rear axle bearing holder (page 12-8).
- the brake hose (from the clamps).
- the shock absorber lower mount bolt.
- the swingarm pivot nut, bolt and swingarm.



Remove the following:


- skid plate bolts and skid plate.
- chain slider.
- dust seals and pivot collar.



INSPECTION


Check the swingarm for damage and replace if necessary.

Check the swingarm pivot needle bearings, collars, and dust seals for wear or damage.



PIVOT BEARING REPLACEMENT

Remove the pivot side collars with a drift.



REAR SUSPENSION

Remove the needle bearings using the special tool.

TOOLS:

Bearing remover set, 20 mm 07936-3710001

not available in U.S.A.

- Spindle assy, 20 mm

07936-3710600


- Remover handle

07936-3710100

- Remover weight

07741-0010201 or

07936-3710200



Press new needle bearings in with the side collars as shown.

TOOLS:


Driver 07749-0010000 Attachment, 32 x 35 mm 07746-0010100 Pilot, 20 mm

07746--0040500

CAUTION

Install the needle bearings with their marked ends facing out.


Apply grease to the needle bearings.




INSTALLATION

Apply grease to the pivot collar and lips of the dust seals.

Install the pivot collar and dust seals onto the swingarm pivot.



Install the chain slider onto the swingarm. Install the skid plate with the bolts.



Place the swingarm into the frame and install the pivot bolt and nut. Tighten the pivot nut.

TORQUE: 70-110 N·m (7.0-11.0 kg-m, 51-80 ft-lb)

Install the shock absorber lower mount bolt and tighten it.


TORQUE: 40-50 N·m (4.0-5.0 kg-m, 29-36 ft-lb)


Install the brake hose onto the clamps and tighten the bolts.

TORQUE: 10-14 N·m (1.0-1.4 kg-m, 7.2-10 ft-lb)

Install the following:

- rear axle bearing holder (page 12-10).
- rear axle (page 12-5).
- rear wheels (page 12-2).





14. HYDRAULIC BRAKES

| SERVICE INFORMATION | 14-1 | REAR CALIPER | 14-12 |
|--------------------------|-------|-----------------------|-------|
| TROUBLESHOOTING | 14-2 | PARKING BRAKE | 14-15 |
| BRAKE FLUID REPLACEMENT/ | | FRONT MASTER CYLINDER | 14-17 |
| BLEEDING | 14-3 | REAR MASTER CYLINDER | 14-19 |
| BRAKE PAD REPLACEMENT | 14-5 | REAR BRAKE PEDAL | 14-20 |
| BRAKE DISC | 14-9 | | |
| FRONT CALIPER | 14-10 | | |
| | | | |

SERVICE INFORMATION

GENERAL

- The front and rear brakes can be removed without disconnecting the hydraulic system.
- Once the hydraulic systems have been opened, or if the brakes feel spongy, the system must be bled.
- Do not allow foreign material to enter the system when filling the reservoir.
- Brake fluid will damage painted, plastic, and rubber parts. Whenever handling brake fluid, protect the painted, plastic, and rubber parts by covering them with a rag. If fluid does get on these parts, wipe it off with a clean cloth.
- Always check brake operation before riding the ATC.

SPECIFICATIONS

| | ITEM | STANDARD mm (in) | SERVICE LIMIT mm (in) |
|-----------------------|-------------------------------|-------------------------------|--------------------------|
| Front Thickness 3.8 | | 3.8-4.2 (0.15-0.17) | 3.0 (0.12) |
| disc Runout | | 0.3 (0.012) | |
| Front master | Cylinder I.D. | 12.700-17.743 (0.5000-0.5017) | 12.755 (0.5022) |
| cylinder | Piston O.D. | 12.657-12.684 (0.4983-0.4994) | 12.645 (0.4978) |
| Front | Piston O.D. | 33.878-33.928 (1.3338-1.3357) | 33.870 (1.3335) |
| caliper Cylinder I.D. | Cylinder I.D. | 33.960-34.010 (1.3370-1.3390) | 34.020 (1.3394) |
| Rear | Thickness | 3.8-4.2 (0.15-0.17) | 3.0 (0.12) |
| disc Runout | Runout | | 0.3 (0.012) |
| Rear master | Cylinder I.D. | 14.000-14.043 (0.5512-0.5529) | 14.055 (0.5533) |
| cylinder Piston O.D. | 13.957—13.984 (0.5495—0.5506) | 13.945 (0.5490) | |
| Rear | Cylinder I.D. | 33.960-34.010 (1.3370-1.3390) | 34.020 (1.3394) |
| caliper | Piston O.D. | 33.878-33.928 (1.3338-1.3357) | 33.870 (1.3335) |

HYDRAULIC BRAKES

TORQUE VALUES

Air bleed valve $4-7 \text{ N} \cdot \text{m} (0.4-0.7 \text{ kg-m}, 3-5 \text{ ft-lb})$ Brake pad pin bolt $15-20 \text{ N} \cdot \text{m} (1.5-2.0 \text{ kg-m}, 11-15 \text{ ft-lb})$ Caliper mounting bolt 20-30 N·m (2.0-3.0 kg-m, 15-22 ft-lb) Front, rear caliper socket bolt 15-20 N·m (1.5-2.0 kg-m, 11-15 ft-lb) Oil bolt 25-35 N·m (2.5-3.5 kg-m, 18-25 ft-lb) Parking brake base bolt 20-25 N·m (2.0-2.5 kg-m, 15-18 ft-lb) Rear master cylinder mounting bolt 10-14 N·m (1.0-1.4 kg-m, 72-10 ft-lb) Front wheel nut 60-70 N·m (6.0-7.0 kg-m, 43-51 ft-lb)

TOOL

Special

Snap ring pliers

07914-3230001

TROUBLESHOOTING

Brake lever/pedal soft or spongy

- Air bubbles in hydraulic system
- Low fluid level
- · Hydraulic system leaking

Brake lever/pedal too hard

- · Sticking piston(s)
- · Clogged hydraulic system
- Pads glazed or worn excessively

Brake drags

- Hydraulic system sticking
- Sticking piston(s)

Brakes grab

- · Pads contaminated
- Disc or wheel misaligned

Brake chatter or squeal

- · Pads contaminated
- Excessive disc runout
- Caliper installed incorrectly
- Disc or wheel misaligned

BRAKE FLUID REPLACEMENT/BLEEDING

BRAKE FLUID DRAINING

WWARNING


A contaminated brake disc or pad reduces stopping power. Discard contaminated pads and clean a contaminated disc with a high quality brake degreasing agent.

CAUTION

- Do not allow foreign material to enter the system when filling the reservoir.
- Avoid spilling fluid on painted, plastic, or rubber parts. Place a rag over these parts whenever the system is serviced.

With the fluid reservoir parallel to the ground, remove the reservoir cap and diaphragm.







Connect a hose to the bleed valve.

Loosen the caliper bleed valve and pump the brake lever (or pedal) until no more fluid flows out of the bleed valve.

Close the bleed valve.





BRAKE FLUID FILLING/BLEEDING

Fill the reservoir with DOT 3 or 4 brake fluid from a sealed container.

CAUTION

• Do not mix different types of fluid. They are not compatible.

Connect the commercially available brake bleeder to the bleed valve.

Pump the brake bleeder and loosen the bleed valve. Add fluid when the fluid level in the master cylinder reservoir is low.

NOTE

- Check the fluid level often while bleeding the brakes to prevent air from being pumped into the system.
- When using a brake bleeding tool, follow the manufacturer's operating instructions.

Repeat the above procedures until air bubbles do not appear in the plastic hose.

NOTE

 If air is entering the bleeder from around the bleed valve threads, seal the threads with teflon tape.

Close the bleed valve and operate the brake lever or pedal. If it feels spongy, repeat the BLEEDING procedure.

If a brake bleeder is not available, perform the following procedure:

Pump up the system pressure with the lever (or pedal) until there are no air bubbles in the fluid flowing out of the reservoir small hole and lever resistance is felt.

1. Squeeze the brake lever (or depress the brake pedal), open the bleed valve 1/2 turn and then close the valve.


NOTE


- Do not release the brake lever (or pedal) until the bleed valve has been closed.
- 2. Release the brake lever (or pedal) slowly and wait several seconds after it reaches the end of its travel.


Repeat steps 1 and 2 until bubbles cease to appear in the fluid coming out of the bleed valve.


Tighten the bleed valve.

TORQUE: 4-7 N·m (0.4-0.7 kg-m, 3-5 ft-lb)











Fill the fluid reservoir to the upper level mark.

Reinstall the diaphragm and reservoir cap.

WARNING

A contaminated brake disc or pad reduces stopping power. Discard contaminated pads and clean a contaminated disc with a high quality brake degreasing agent.





BRAKE PAD REPLACEMENT


NOTE


- Always replace the brake pads in pairs to assure even disc pressure.
- Always use new pads marked "N18FF" (FRONT and REAR).

FRONT BRAKE


Raise the front wheel off the ground by placing a block or safety stand under the skid plate.
Remove the wheel nuts.

Remove the caliper mounting bolts.






Bend down the lock washer tabs and loosen the pad pin bolts.




HYDRAULIC BRAKES

Remove the pad pin bolts, lock washer and brake pads.

Clean the brake caliper.



Position the pad spring in the caliper as shown.




Install new brake pads, a new lock washer and the pad pin bolts.

Install the shim onto the inner pad.

NOTE


· Always use pads marked "N18FF".



Tighten the pad pin bolts.

TORQUE: 15-20 N·m (1.5-2.0 kg-m, 11-15 ft-lb)


Bent up the lock washer tabs against the bolt heads.



Push the caliper piston in all the way.

CAUTION

- Be careful that the master cylinder does not overflow when the caliper piston is compressed.
- Brake fluid can cause damage to painted, plastic, or rubber surfaces.




Install the caliper to the front fork so the disc is positioned between the pads, being careful not to damage the pads. Tighten the caliper mounting bolts.

TORQUE: 20-30 N·m (2.0-3.0 kg-m, 15-22 ft-lb)

Install the front wheel nuts.


TORQUE: 60-70 N·m (6.0-7.0 kg-m, 43-51 ft-lb)




REAR BRAKE

Slide the release lever to the left and remove the seat/rear fender.


Bend down the lock washer tabs and loosen the pad pin bolts.




Remove the caliper mounting bolts.



Remove the pad pin bolts, lock washer and brake pads.



Position the pad spring in the caliper as shown.




Install new brake pads, a new lock washer and the pad pin bolts.

Install the shim onto the inner pad.

Align the pad pin bolt holes by depressing the pads against the caliper, and install the pad pin bolts.

NOTE


Always use pads marked "N18FF".



Push the caliper piston in all the way, being careful not to damage the pads.


CAUTION

- Be careful that the master cylinder does not overflow when the caliper piston is compressed.
- Brake fluid can cause damage ot painted, plastic, or rubber surfaces.



Lower the caliper so the disc is positioned between the pads, being careful not to damage the pads. Install and tighten the caliper mounting bolts.

TORQUE: 20-30 N·m (2.0-3.0 kg-m, 15-22 ft-lb)




Tighten the pad pin bolts.

TORQUE: 15-20 N·m (1.5-2.0 kg-m, 11-15 ft-lb)

Bend up the lock washer tabs against the bolt heads.

Adjust the parking brake (page 3-11). Install the seat/rear fender.



BRAKE DISC


THICKNESS INSPECTION

Measure the brake disc thickness with a micrometer.

SERVICE LIMITS:

FRONT: 3.0 mm (0.12 in) REAR: 3.0 mm (0.12 in)

Replace the disc that is worn beyond the service limit.




WARPAGE INSPECTION

Remove the front brake disc (page 11-7). Remove the rear brake disc (page 12-4).

Measure the each disc for warpage.

SERVICE LIMIT: 0.30 mm (0.012 in)



FRONT CALIPER

REMOVAL

Drain the brake fluid from the front hydraulic system. Remove the oil bolt and the brake hose from the caliper. Remove the rubber cap and loosen the socket bolt.


CAUTION


 Avoid spilling fluid on painted, plastic, or rubber parts. Place a rag over these parts whenever the system is serviced.

Remove the caliper mounting bolts and the caliper from the fork leg.

DISASSEMBLY

Remove the socket bolt, washer and caliper bracket. Remove the pivot boots. Remove the brake pads (page 14-5).






Position the caliper with the piston down and apply small spurts of air pressure to the fluid inlet to remove the piston.

WWARNING


- Do not use high pressure air or bring the nozzle too close to the inlet.
- Place a shop towel over the piston to prevent the piston from becoming a projectile.



Push the dust and piston seals in and lift them out. Clean the seal grooves with clean brake fluid.

CAUTION

• Be careful not to damge the piston sliding surfaces.




INSPECTION

Check the caliper cylinder for scratches, scoring or other damage.

Measure the cylinder inside diameter.


SERVICE LIMIT: 34.020 mm (1.3394 in)



Check the piston for scratches, scoring or other damage.

Measure the piston outside diameter.

SERVICE LIMIT: 33.870 mm (1.3335 in)



ASSEMBLY

Coat new dust and piston seals with clean brake fluid and install them in the seal grooves in the caliper with their smaller diameter ends facing in.


Lubricate the cylinder and piston with clean brake fluid and install the piston into the cylinder with the piston pad end facing the pad side.


Apply silicone grease to the pivot boots and install the boots making sure that they are seated in the caliper grooves properly.

Install the pad spring.

Install the caliper bracket, washer and socket bolt.

Install the brake pads (page 14-6).





INSTALLATION

Install the caliper onto the right fork leg and tighten the caliper mounting bolts.

TORQUE: 20-30 N·m (2.0-3.0 kg-m, 15-22 ft-lb)

Connect the front brake hose to the caliper with the oil bolt and two new sealing washers, and tighten the oil bolt.

TORQUE: 25-35 N·m (2.5-3.5 kg-m, 18-25 ft-lb)

Tighten the socket bolt and install the rubber cap.


TORQUE: 15-20 N·m (1.5-2.0 kg-m, 11-15 ft-lb)

Fill the front brake reservoir and bleed the front brake system (page 14-4).

REAR CALIPER

REMOVAL

Drain the brake fluid from the rear hydraulic system. Loosen the parking brake adjusting bolt lock nut, and remove the bolt and arm.



3) ADJUSTING BOLT

(1) OIL BOLT

(2) MOUNTING BOLTS


Remove the oil bolt and brake hose from the rear caliper.

CAUTION

 Avoid spilling fluid on painted, plastic, or rubber parts. Place a rag over these parts whenever the system is serviced.

Loosen the socket bolt.


Remove the caliper mounting bolts and the caliper.



DISASSEMBLY

Remove the socket bolt, washer, caliper bracket and pivot boots.


Remove the brake pads (page 14-7).



Position the caliper with the piston down and apply small spurts of air pressure to the fluid inlet to remove the piston.

WARNING


- Do not use high pressure air or bring the nozzle too close to the inlet.
- Place a shop towel over the piston to prevent the piston from becoming a projectile.



Push the dust and piston seals in and lift them out. Clean the seal grooves with clean brake fluid.

CAUTION

Be careful not to damage the piston sliding surface.




INSPECTION

Check the caliper cylinder for scratches, scoring or other damage.

Measure the cylinder inside diameter.


SERVICE LIMIT: 34.020 mm (1.3394 in)



Check the piston for scratches, scoring or other damage.

Measure the outside diameter.

SERVICE LIMIT: 33.870 mm (1.3335 in)



ASSEMBLY

Coat new dust and piston seals with clean brake fluid and install them in the seal grooves in the caliper with their small diameter ends facing in.

Lubricate the cylinder and piston with brake fluid, and install the piston with the piston pad end facing the pad.


Apply silicone grease to the boots.


Install the boots making sure that they are seated in the caliper grooves properly.

Install the pad spring.

Install the caliper bracket, washer and socket bolt.

Install the brake pads (page 14-8).





INSTALLATION

Place the caliper over the brake disc being careful not to damage the pads.

Install the caliper mounting bolts and tighten them.

TORQUE: 20-30 N·m (2.0-3.0 kg-m, 15-22 ft-lb)

Tighten the socket bolt.


TORQUE: 15-20 N·m (1.5-2.0 kg-m, 11-15 ft-lb)


Connect the rear brake hose using the oil bolt and two sealing washers after making sure that the sealing washers are in good condition.

Tighten the oil bolt.

TORQUE: 25-35 N·m (2.5-3.5 kg-m, 18-25 ft-lb)

Connect the parking brake cable to the parking brake arm and install the arm on the shaft by aligning the punch marks on the shaft and arm.





Install the lock nut and parking brake adjusting bolt.

Fill and bleed the rear brake system (page 14-4).


Adjust the parking brake (page 3-11).


PARKING BRAKE

REMOVAL


Loosen the parking brake adjusting bolt lock nut and remove the bolt and brake arm.

Remove the parking brake base bolts and the base.






Remove the boot and parking brake shaft from the brake base.



INSPECTION

Check the boot for deterioration or damage. Check the shaft and base threads for wear or damage.



INSTALLATION

Apply grease to the parking brake shaft, position the shaft so that the punch mark is within the index marks on the parking brake base and thread the shaft into the parking brake base.

NOTE


· The parking brake shaft has left hand threads.


Screw the parking brake shaft in fully, back it about 1/8 turn and make sure that the punch mark on the shaft is within the index marks on the base.

Install the boot over the shaft and base, making sure that the boot is seated in the groove in the shaft and base properly.

Install the boot over the shaft and base, making sure that the boot is seated in the groove in the shaft and base properly.


Install a new O-ring in the groove in the base and install the base onto the caliper.





Tighten the bolts.


TORQUE: 20-25 N·m (2.0-2.5 kg-m, 14-18 ft-lb)



Connect the parking brake cable to the parking brake arm and install the arm on the shaft, by aligning the punch marks.

Install the lock nut and parking brake adjusting bolt.

Fill and bleed the rear brake system (page 14-4). Adjust the parking brake (page 3-11).



FRONT MASTER CYLINDER

REMOVAL

Drain brake fluid from the front hydraulic system.


Remove the front brake lever and disconnect the brake hose from the master cylinder.


CAUTION

- Avoid spilling fluid on painted, plastic, or rubber parts. Place a rag over these parts whenever the system is serviced.
- When removing the oil bolt, cover the end of the hose to prevent contamination.

Loosen the throttle housing holder screws and remove the housing.

Remove the master cylinder holder screws and the master cylinder





DISASSEMBLY

Remove the piston boot and the snap ring from the master cylinder body.


TOOL:

Snap ring pliers:

07914-3230001

Remove the piston and spring from the master cylinder.

Clean the master cylinder, reservoir and piston in clean brake fluid.




INSPECTION

Check the master cylinder for scratches, scoring or other damage.

Measure the master cylinder inside diameter.

SERVICE LIMIT: 12.755 mm (0.5022 in)



HYDRAULIC BRAKES


Check the piston for scratches, scoring or other damage. Check the primary and secondary cups for wear, deterioration or damage.

Measure the piston outside diameter.

SERVICE LIMIT: 12.645 mm (0.4978 in)

NOTE

 The piston, piston cups and spring must be replaced as a set.



ASSEMBLY


Coat the piston, primary and secondary cups with clean brake fluid, then install the piston spring and piston.

Install the snap ring.

CAUTION

Do not allow the lips of the cups to turn inside out and be certain the snap ring is firmly seated in the groove.

Install the boot.



INSTALLATION

Place the front brake master cylinder on the handlebar and install its holder with the "UP" mark facing up.

Align the end of the holder with the punch mark on the handlebar and tighten the upper screw first, then tighten the lower screw.

Align the ridge of the throttle lever housing with the mating surface of the master cylinder and holder, and tighten the forward screw first, then tighten the rear screw.

Make sure that the oil bolt sealing washers are in good condition.

Connect the brake hose to the master cylinder using the oil bolt and two sealing washers so the hose joint neck is positioned in the stoppers on the master cylinder body.


Tighten the oil bolt.


TORQUE: 25-35 N·m (2.5-3.5 kg-m, 18-25 ft-lb)

Install the brake lever onto the master cylinder and tighten the pivot bolt and nut.

Install the rubber cover.

Fill and bleed the front hydraulic system (page 14-4).





(2) MOUNTING BOLTS

REAR MASTER CYLINDER

REMOVAL

Drain the brake fluid from the rear hydraulic system.

Disconnect the master cylinder push rod from the rear brake pedal by removing the cotter pin and joint pin.

Disconnect the brake hose from the master cylinder.

Remove the hose connector screws and disconnect the reservoir hose.

Remove the rear master cylinder mounting bolts.

DISASSEMBLY

Remove the rubber boot, snap ring and push rod.

TOOL:

Snap ring pliers:

07914-3230001

Remove the piston and spring.

Clean the piston and the inside of the master cylinder with brake fluid.

(4) COTTER PIN (3) JOINT PIN

(1) CONNECTOR


(5) SCREW

INSPECTION

Check the master cylinder for scratches, scoring or damage.

Measure the master cylinder inside diameter.

SERVICE LIMIT: 14.055 mm (0.5533 in)



(1) SNAP RÍNG PLIERS

Check the primary and secondary cups for wear, deterioration or damage.


Check the piston for scratches, scoring or damage.

Measure the piston outside diameter.

SERVICE LIMIT: 13.945 mm (0.5490 in)

NOTE

 The piston, piston cups and spring must be replaced as a set.




ASSEMBLY

Coat the piston, primary and secondary the cups with clean brake fluid, then install the spring and piston with the cups. Install the push rod and snap ring.

CAUTION

Do not allow the lips of the cups to turn inside out and be certain the snap ring is seated in the groove.

Install the rubber boot.



INSTALLATION

Install the master cylinder in the frame and tighten the mount bolts.

TORQUE: 10-14 N·m (1.0-1.4 kg-m, 7.2-10 ft-lb)

Connect the reservoir hose joint to the master cylinder with a new O-ring and the screws.

Connect the master cylinder push rod and brake pedal with the joint pin and secure it with a new cotter pin.

Make sure that the oil bolt sealing washers are in good condition.

Connect the rear brake hose with the oil bolt and two sealing washers, and tighten the oil bolt.

TORQUE: 25-35 N·m (2.5-3.5 kg-m, 18-25 ft-lb)

Fill and bleed the rear hydraulic system (page 14-4).

REAR BRAKE PEDAL

REMOVAL

Disconnect the master cylinder push rod from the rear brake pedal by removing the cotter pin and joint pin.

Remove the right footpeg.

Remove the rear brake pedal and return spring.

Check the inside of the pedal pivot for dirt and dust.

Check the dust seal and pivot bearing for wear or damage.


INSTALLATION


Apply grease to the brake pedal pivot and pivot shaft. Install the return spring over the rear brake pedal and hook the spring end to the frame.


Install the right footpeg and tighten the bolts.

TORQUE: 60-70 N·m (6.0-7.0 kg-m, 43-51 ft-lb)

Connect the rear brake pedal to the rear master cylinder push rod with the joint pin and secure the joint pin with a new cotter pin.







15

15. REAR FENDER/SEAT/EXHAUST SYSTEM

| SERVICE INFORMATION | 15-1 | EXHAUST SYSTEM | 15-2 |
|---------------------|------|----------------|------|
| REAR FENDER/SEAT | 15-1 | | |

SERVICE INFORMATION

GENERAL

• Refer to section 3 for spark arrester cleaning.


WWARNING

• Do not service the exhaust system while it is hot.

TORQUE VALUES

| Exhaust pipe joint nut | | 10-14 N·m (1.0-1.4 kg-m, 7.2-10 ft-lb) |
|-------------------------------|----------------|--|
| Exhaust muffler clamp bolt | | 18-28 N·m (1.8-2.8 kg-m, 13-20 ft-lb) |
| Exhaust muffler mounting bolt | '86: 8 mm bolt | 40-50 N·m (4.0-5.0 kg-m, 29-33 ft-lb) |
| | 10 mm bolt | 60-70 N·m (6.0-7.0 kg-m, 43-51 ft-lb) |
| | After '86: | 60-70 N·m (6.0-7.0 kg-m, 43-51 ft-lb) |

REAR FENDER/SEAT



REAR FENDER/SEAT/EXHAUST SYSTEM


REMOVAL

Release the seat lock by moving the lever in the direction shown and remove the seat/rear fender.

INSTALLATION

Apply grease to the seat catch.


Install the seat and fender in the reverse order of removal.



EXHAUST SYSTEM

WWARNING

• Do not service the exhaust pipe or muffler while they are hot.




REMOVAL

Remove the seat/rear fender.


Remove the exhaust pipe joint nuts.

Loosen the exhaust pipe clamp bolt and remove the exhaust pipe.



Remove the exhaust muffler mounting bolts and the exhaust muffler.

Check the gasket and pipe seal for wear or damage and replace them if necessary.



INSTALLATION

Install the exhaust muffler and loosely install the mounting bolts.

Install the exhaust pipe and loosely install the joint nuts and clamp bolt.

Tighten the exhaust pipe joint nuts.

TORQUE: 10-14 N·m (1.0-1.4 kg-m, 7.2-10 ft-lb)

Tighten the exhaust pipe clamp bolt.

TORQUE: 18-28 N·m (1.8-2.8 kg-m, 13-20 ft-lb)


Tighten the exhaust muffler mounting bolts.

TORQUE VALUES:

'86:

8 mm bolt: 40-45 N·m (4.0-4.5 kg-m, 29-33 ft-lb) 10 mm bolt: 60-70 N·m (6.0-7.0 kg-m, 43-51 ft-lb) After '86: 60-70 N·m (6.0-7.0 kg-m, 43-51 ft-lb)

After installing, make sure that there are no exhaust leaks. Install the seat/rear fender.



16

16. ELECTRICAL SYSTEM

| SERVICE INFORMATION | 16-1 | PULSE GENERATOR | 16-5 |
|-------------------------|------|------------------------------|-------|
| TROUBLESHOOTING | 16-2 | LIGHTS | 16-6 |
| IGNITION SYSTEM | 16-3 | AC REGULATOR | 16-8 |
| CDIUNIT | 16-3 | IGNITION SWITCH (After '86:) | 16-9 |
| IGNITION COIL | 16-4 | SWITCHES | 16-9 |
| ALTERNATOR EXCITER COIL | 16-5 | WIRING DIAGRAMS | 16-10 |

SERVICE INFORMATION

GENERAL

- Ignition timing does not need to be adjusted since the CDI (Capacitive Discharge Ignition) unit is factory pre-set.
- For spark plug inspection and ignition timing check, refer to section 3.
- For pulse generator, stator coil removal, refer to section 9.
- All plastic connectors have locking tabs that must be released before disconnecting, and must be aligned when reconnecting.
- A continuity check can usually be made without removing the part from the ATC by simply disconnecting the wires and connecting a continuity tester or ohmmeter to the terminals or connections.

SPECIFICATIONS

| ITEM | | STANDARD | | |
|--|---|------------------------------|-----------------------------|------------------------|
| Spark plug | Gap | | 0.6-0.7 mm (0.024-0.028 in) | |
| Recommended plug | | DR8ES-L (NGK), X24ESR-U (ND) | | |
| Ignition coil | Ignition coil Primary coil resistance | | 0.1-0.3 Ω | |
| | Secondary coil resistance | With plug cap | 7.4—11.0 kΩ | |
| | | Without plug cap | $3.7{-}4.5~\text{k}\Omega$ | |
| Exciter coil resistar | nce | | 100-300 Ω | |
| Pulse generator coil resistance | | 290 – 360 Ω | | |
| Ignition timing | Ignition timing Initial ("F" mark) Full advance | | 10° BTDC/1,400 ± 100 rpm | |
| | | | 28° BTDC/3,500 ± 200 rpm | |
| Lighting coil resistance | | | 0.1-1.0 Ω | |
| AC regulator Regulating voltage Resistance | | | 13.5-14.5 V | After '86: 12.5-13.5 V |
| | | 100 kΩ−∞ | | |
| Alternator | | 135W/5,000 rpm | | |
| Headlight | | 12V 60/55 W | | |
| Taillight | | 12V 5 W | After '86: 12 V 8 W | |

TOOL

Special

Sanwa Electric Tester 07308-0020000 or

Kowa Tester TH-5H

Kowa Digital Multi-Tester 07411-0020000 or KS-AHM-32-003 (U.S.A. only)

TROUBLESHOOTING

No spark at plug

- · Faulty spark plug
- · Poorly connected, broken or shorted wires
 - Between alternator and CDI unit
 - Between CDI unit and engine stop switch
 - Between CDI unit and ignition coil
 - Between ignition coil and spark plug
 - Between pulse generator and CDI unit
- · Faulty ignition coil
- · Faulty CDI unit
- · Faulty pulse generator
- Faulty alternator
- Faulty ignition switch (After '86)


Engine starts but runs poorly

- Ignition primary circuit
 - Faulty ignition coil
 - Loose or bare wire
 - Faulty alternator
 - Faulty CDI unit
 - Faulty pulse generator
- · Ignition secondary circuit
 - Faulty spark plug
 - Faulty spark plug wire
 - Faulty ignition coil
- · Improper ignition timing
 - Faulty pulse generator
 - Faulty CDI unit

No lights when engine is running

- · Faulty bulb
- · Poorly connected or loose connectors
- · Faulty alternator

IGNITION SYSTEM



CDI UNIT

SYSTEM INSPECTION

NOTE

- If the ignition timing is incorrect, perform the following inspection.
- · The ignition switch is equipped the after '86 model.


Remove the seat and disconnect the CDI unit coupler.

Check the continuity between the BI/W and G wires with the ignition switch and engine stop switch in each position.

- continuity with the ignition switch and engine stop switch OFF.
- continuity with the ignition switch OFF and engine stop switch to RUN.
- continuity with the ignition switch ON and engine stop switch OFF
- no continuity with the ignition switch ON and engine stop switch to RUN.

If any of the above checks fairs, check the following:

- wiring between the CDI unit and engine stop switch and/or ignition switch for open or short circuit, or loose connection
- ignition switch (page 16-8).
- engine stop switch (page 16-9).



ELECTRICAL SYSTEM

Measure the resistance between the BI/Y and G wire terminals.

STANDARD: $0.1-0.3 \Omega$

If the resistance is not within the standard, check the ignition coil and retest.

Measure the resistance between the Bu/Y and G/W wire terminals.

STANDARD: 290-360 Ω

If the resistance is not within the standard, check the pulse generator (page 16-5) and retest.

Measure the resistance between the BI/R and ground.

STANDARD: $50-200 \Omega$

If the resistance is not within the standard, check the alternator exciter coil (page 3-8) and retest.

If all related systems are in good condition but the ignition timing is incorrect, replace the CDI unit with a new one and recheck the ignition timing (page 3-8).

IGNITION COIL

Disconnect the CDI unit coupler and measure the ignition coil primary coil resistance between the BI/Y and G wire terminals.

STANDARD: $0.1-0.3~\Omega$

If the resistance is not within standard, disconnect the ignition coil primary wires from the ignition coil and measure the resistance.

STANDARD: $0.1-0.3~\Omega$

If the resistance is still not within standard, replace the ignition coil.

If the resistance is within the standard, check the wire harness between the CDI unit and ignition coil (BI/Y and G) and repair or replace the wire harness.

Disconnect the spark plug cap from the spark plug and measure the secondary coil resistance between the coil primary terminal (G) and the spark plug cap.


STANDARD: 7.4-1.1 $k\Omega$


If the secondary coil resistance is not within the standard, remove the spark plug cap from the spark plug wire and measure the resistance without the cap.

STANDARD: $3.7-4.5 \text{ k}\Omega$

If the resistance is still not within the standard, replace the ignition coil.

If the resistance is within the standard, replace the spark plug cap and retest.





ALTERNATOR EXCITER COIL

Remove the seat.

Disconnect the CDI unit coupler and measure the resistance between the BI/R wire terminal and ground.


STANDARD: $50-200 \Omega$

If the resistance is not within the standard, disconnect the exciter coil wire terminal and measure the resistance.

STANDARD: $50-200 \Omega$

If the resistance is still not within the standard, replace the alternator.

If the resistance is within the standard, check the wire harness between the CDI unit and alternator (BI/R) for open or shorted circuit, and repair or replace the wire harness.



PULSE GENERATOR

Remove the seat.

Disconnect the CDI unit coupler and measure the pulse generator resistance between the Bu/Y and G/W wire terminals.


STANDARD: 290 - 360 Ω

If the resistance is not within standard, disconnect the pulse generator wire coupler and measure the resistance between the Bu/Y and G/W wire terminals.

STANDARD: 290-360 Ω

If the resistance is still not within the standard, replace the pulse generator.

If the resistance is within the standard, check the wire harness between the CDI unit and pulse generator (Bu/Y and G/W) for open or shorted circuit and repair or replace the wire harness.




LIGHTS

Apply the parking brake and start the engine.

Check the headlight and taillight by operating the headlight ON-OFF switch.


Operate the dimmer switch and check the headlight vertical beam.

Adjust the vertical beam by turning the adjusting screw.




HEADLIGHT BULB REPLACEMENT


Remove the headlight case from the front fork tubes by releasing the four retaining bands.



Disconnect the headlight coupler and remove the dust cover from the headlight.

Release the retaining clip and remove the headlight bulb.






Replace the faulty bulb with a new one.

CAUTION

- Do not put finger prints on the headlight bulb, they may create hot spots on the bulb.
- If you touch the bulb with your bare hands, clean it with a cloth moistened with alcohol to prevent its early failure.
- Do not try to replace the bulb with the light ON.
- After replacing the bulb, install the rubber boot tightly against the unit.

Install the removed parts in the reverse order of removal.




HEADLIGHT DISASSEMBLY/ASSEMBLY

Remove the headlight.


Remove the adjusting screw and headlight mounting nuts and remove the headlight from the cover.

Assemble the headlight in the reverse order of disassembly.



TAILLIGHT BULB REPLACEMENT

Remove the taillight lens by removing the two screws and nuts.




Remove the taillight bulb by pushing it in and turning it counterclockwise. Replace the faulty bulb with a new one.

Install the removed parts in the reverse order of removal.

NOTE

- Make sure that the taillight lens rubber seal is in good condition
- Be sure to install the washers on both sides of the rubber mounts.




ALTERNATOR LIGHTING COIL

Disconnect the alternator lighting coil coupler (white). Measure the lighting coil resistance between the coupler terminals.

STANDARD: $0.1-1.0~\Omega$

If the resistance is not within the standard, check the wire harness between the lighting switch-to-AC regulator and AC regulator-to-alternator, and replace or repair if necessary. If the wire harness is in good condition, and the resistance still not within standard, replace the alternator.



AC REGULATOR

Disconnect the engine stop switch/lighting switch coupler


Start the engine and measure the voltage between the white/ yellow and green wire terminals at the main harness side of the coupler.


VOLTAGE: '86: 13.5-14.5 V After '86: 12.5-13.5 V

If the voltage is not within specifications, check the AC regulator.

Remove the seat/rear fender.

Disconnect the AC regulator, and remove it.






Measure the resistance between the wire terminals.

RESISTANCE: 100 k Ω - ∞

Replace the AC regulator with a new one if the resistance is not within the specifications.

Install the regulator in the reverse order of removal.



IGNITION SWITCH

After '86:

Remove the seat/rear fender.


Remove the fuel tank (page 4-3).


Disconnet the ignition switch wire connectors.


Check the switch for continuity between the BI/W and G wires.


| COLOR CODE | Di | |
|-----------------|----|---|
| SWITCH POSITION | ВІ | G |
| OFF | 0 | 0 |
| • | | |


The switch is normal if there is continuity with the switch OFF.











REMOVAL

Remove the handlebar cover.

Remove the fuel tank (page 4-3).

Disconnect the ignition switch wire connectors.

Push the lugs on the ignition switch in and remove the switch from the upper cover.

SWITCHES

NOTE

The engine stop switch, lighting switch and dimmer switch must be replaced as an assembly.

Remove the headlight case and disconnect the headlight coupler and the engine stop switch/lighting switch wire coupler and connector.

Continuity should exist between the color coded wires in each chart.

ENGINE STOP SWITCH

| COLOR CODE SWITCH POSITION | BLACK/ WHITE | GREEN |
|----------------------------|-----------------|-------|
| OFF | 0 | —O |
| RUN | | |

LIGHTING SWITCH

| COLOR CODE SWITCH POSITION | WHITE/ YELLOW | BROWN |
|----------------------------|------------------|-------|
| OFF | | |
| ON | 0- | φ |


DIMMER SWITCH

| COLOR CODE | | | |
|-----------------|-------|------|-------|
| SWITCH POSITION | BROWN | BLUE | WHITE |
| HI | 0 | 0 | |
| (N) | 0 | -0- | |
| Lo | 9 | | 0 |
| | | | |


(1) INTERNAL CONNECTION

WIRING DIAGRAMS

'8**6**:



After '86:




17

17. TROUBLESHOOTING

ENGINE DOES NOT START OR IS HARD 17-1 POOR PERFORMANCE AT HIGH SPEEDS

ENGINE LACKS POWER 17-2 POOR HANDLING 17-4
POOR PERFORMANCE AT LOW AND 17-3
IDLE SPEEDS


ENGINE DOES NOT START OR IS HARD TO START



ENGINE LACKS POWER

1. Raise wheels off ground and WHEEL DOES NOT SPIN -→ (1) Brake dragging. spin by hand. **FREELY** (2) Worn or damaged wheel bearing. WHEELS SPIN FREELY (3) Wheel bearing needs lubrication. (4) Drive chain too tight. 2. Check tire pressure with tire PRESSURE TOO LOW-→ (1) Punctured tire. (2) Faulty tire valve. gauge. PRESSURE NORMAL 3. Try rapid acceleration from ENGINE SPEED DOES NOT -(1) Clutch slipping. low to second. CHANGE WHEN CLUTCH IS (2) Worn clutch disc/plate. **RELEASED** (3) Warped clutch disc/plate. ENGINE SPEED LOWERED WHEN **CLUTCH IS RELEASED** 4. Lightly accelerate engine. **ENGINE SPEED DOES NOT-**→ (1) Carburetor choke open. INCREASE SUFFICIENTLY (2) Clogged air cleaner. **ENGINE SPEED INCREASES** (3) Restricted fuel flow. (4) Clogged fuel tank breather tube. (5) Clogged muffler. 5. Check ignition timing. INCORRECT-►(1) Faulty CDI unit. (2) Faulty pulse generator. CORRECT 6. Check valve clearance. INCORRECT -► (1) Improper valve adjustment (2) Worn valve seat. CORRECT 7. Test cylinder compression T00 L0W -► (1) Valve stuck open. using a compression gauge. (2) Worn cylinder and piston rings. (3) Leaking head gasket. NORMAL (4) Improper valve timing. 8. Check carburetor for clogging. CLOGGED-(1) Damaged fuel strainer. (2) Carburetor not serviced NOT CLOGGED frequently enough. 9. Remove spark plug. FOULED OR DISCOLORED -→ (1) Plug not serviced frequently enough. NOT FOULED OR DISCOLORED (2) Use of plug with improper heat range.


Probable Cause



POOR PERFORMANCE AT LOW AND IDLE SPEEDS

| | | Probable Cause |
|---|---------------|---|
| Check ignition timing and valve clearance. | INCORRECT (1) | Improper valve clearance. Improper ignition timing. (Faulty CDI unit) |
| CORRECT 2. Check carburetor pilot screw adjustment. | MOOTH 201 | Fuel-air mixture too lean. Fuel-air mixture too rich. |
| CORRECT 3. Check if air is leaking past intake pipe. | LEAKING — (1) | Deteriorated insulator O-ring. Loose carburetor. |
| NOT LEAKING 4. Try spark test. GOOD SPARK | (2) | · |

POOR PERFORMANCE AT HIGH SPEEDS



MEMO

| A B | 400 | 5 10 | |
|--|-------------|--|--------------|
| Ac Regulator | 16-8 | Fuel System | 4-1 |
| Air Cleaner | 3-5 | Tank | 4-3 |
| Case Davis Tubs | 4-4 | Gearshift Linkage | 8-19 |
| Case Drain Tube | 3-7 | General Information | 1-1 |
| Exciter Coil9- | 16-5 | Safety | 1-1 |
| Bearing Replacement | | HandlebarHigh Altitude Adjustment | 11-3 4-11 |
| Brake Disc | 14-9 | Hydraulic Brakes | 14-1 |
| Brake Fluid | 3-12 | Ignition Coil | 16-4 |
| Replacement/Bleeding | 14-3 | Switch (After '86) | 16-9 |
| Brake Pad Replacement | 14-5 | System | 16-3 |
| Pads | 3-13 | Timing | 3-8 |
| System | 3-13 | Kick Starter | 8-15 |
| Cable & Harness Routing | 1-10 | Left Crankcase Cover Installation | 9-4 |
| Camshaft Installation | 6-13 | Removal | 9-2 |
| Removal | 6-5 | Lights | 16-6 |
| Carburetor Assembly | 4-9 | Lubrication | 2-1 |
| Disassembly | 4-7 | Points | 2-3 |
| Idle Speed | 3-10 | Maintenance | 3-1 |
| Installation | 4-10 | Schedule | 3-2 |
| Removal | 4-6 | Model Identification | 1-2 |
| CDI Unit | 16-3 | Noise Emission Control System (U.S.A. only) | 1-13 |
| Clutch/Oil Pump/Kick Starter/Gearshift Linkage | 8-1 | Nuts, Bolts, Fasteners | 3-16 |
| Clutch | 8-9 | Oil Pump | 8-6 |
| System | 3-15 | Parking Brake | 14-15 |
| Control Cable Lubrication | 2-3 | Pilot Screw Adjustment | 4-10 |
| Crankcase/Transmission/Crankshaft | 10-1 | Piston | 7-3 |
| Crankcase Assembly | | Piston/Cylinder Installation | 7-5 |
| Separation | | Pulse Generator | 16-5 |
| Crankshaft | | Rear Fender/Seat/Exhaust System | 15-1 |
| Cylinder Head/Valves | 6-1 | Rear Suspension | 13-1 |
| Cylinder/Piston | 7-1 | Rear Wheels | 12-1 |
| Cylinder | 7-2 | Rear Axle | 12-2 |
| Compression | 3-8 | Bearings | |
| Head Assembly | 6-11 | Rear Brake Pedal | |
| Cylinder Head Cover Assembly | 6-15 | Caliper | |
| Disassembly | 6-3 | Fender/Seat | |
| Head Cover Installation | 6-15 | Master Cylinder | |
| Removal | 6-3 | Wheel | |
| Cylinder Head Disassembly | 6-6 6-12 | Right Crankcase Cover | 8-3 |
| Removal | 6-5 | | 9-1 |
| Drive Chain | 3-10 | Alternator Clutch/Oil Pump/Kick Starter/Gearshift | 9-1 |
| Slider And Roller | 3-10 | | 8-1 |
| Electrical System | 16-1 | Linkage | 10-1 |
| Engine Removal/Installation | 5-1 | Cylinder Head/Valves | 6-1 |
| Installation | 5-4 | Cylinder/Piston | 7-1 |
| Engine Oil Change | 2-2 | Electrical System | 16-1 |
| Filter Rotor | 2-2 | Engine Removal/Installation | 5-1 |
| Level | | Front Wheel/Suspension/Steering | 11-1 |
| Strainer Screen | 2-2 | Fuel System | |
| Engine Removal | 5-2 | Hydraulic Brakes | 14-1 |
| Exhaust System | 15-2 | Lubrication | 2-1 |
| Float Level Inspection | 4-9 | Maintenance | 3-1 |
| Front Wheel/Suspension/Steering | 11-1 | Rear Fender/Seat/Exhaust System | 15-1 |
| Caliper | | Rear Suspension | 13-1 |
| Fork | | Rear Wheels | 12-1 |
| Master Cylinder | | Service Rules | 1-1 |
| Wheel | 11-7 | Shock Absorber | 13-3 |
| Fuel Line | 3-4 | Skid Plate, Guard Plate | 3-15 |
| Fuel Strainer Cleaning | 3-4 | Spark Arrester | 3-17 |
| Screen | 3-4 | Plug | 3-7 |
| | | | |

INDEX

| Specifications | 1-3 |
|--|-------|
| Steering Head Bearings | 3-17 |
| Stem | 11-21 |
| Suspension | 3-15 |
| Swingarm | 13-9 |
| Switches | 16-9 |
| Throttle Housing | 11-6 |
| Operation | 3-4 |
| Valve | 4-5 |
| Tools | 1-7 |
| Torque Values | 1-5 |
| Transmission | 10-5 |
| Troubleshooting | |
| Clutch/Oil Pump/Kick Starter/Gearshift | |
| Linkage | 8-2 |
| Crankcase/Transmission/Crankshaft | 10-3 |
| Cylinder Head/Valves | 6-2 |
| Cylinder/Piston | 7-1 |
| Electrical System | 16-2 |
| Front Wheel/Suspension/Steering | 11-2 |
| Fuel System | 4-2 |
| Hydraulic Brakes | 14-2 |
| Lubrication | 2-1 |
| Rear Fender/Seat/Exhaust System | 15-1 |
| Rear Suspension | 13-2 |
| Rear Wheels | 12-1 |
| Valve Clearance | 3-8 |
| Guide Replacement | 6-8 |
| Seat Inspection And Refacing | 6-9 |
| Wheels/Tires | 3-16 |
| Wiring Diagrams | 16-10 |

18-2